Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi ECAM46.860.B

De'Longhi Eletta Cappuccino Evo ECAM46.860.B Automatic Coffee Machine User Manual

Model: ECAM46.860.B

1. Important Safety Information

Please read all instructions carefully before using the appliance. Keep this manual for future reference. Failure to follow these safety instructions may result in fire, electric shock, or injury.

- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage rating on the appliance matches your local power supply.
- Always unplug the machine when not in use, before cleaning, or if a malfunction occurs.
- Keep the appliance out of reach of children.
- Do not operate the machine with a damaged cord or plug.

2. Product Overview

The De'Longhi Eletta Cappuccino Evo ECAM46.860.B is an advanced automatic coffee machine designed to deliver a variety of coffee and milk-based beverages with ease.



Figure 2.1: Front view of the De'Longhi Eletta Cappuccino Evo ECAM46.860.B, showcasing its sleek design and the automatic milk carafe system.

2.1 Key Features

- **One-Touch Beverages:** Prepare 6 different coffee and milk-based drinks with a single touch.
- **LatteCrema System:** Automatic system for creamy, dense, and long-lasting milk foam at the ideal temperature.
- **Intuitive LCD Display:** Easy selection of beverages with colored icons.
- **Integrated Grinder:** Features 13 adjustable grind settings for optimal coffee aroma and powder.
- **Double Espresso Function:** Prepare two espresso cups simultaneously.
- **Programmable:** Customize beverage settings to your preference.
- **Automatic Shut-off:** For energy saving and safety.



Figure 2.2: The machine's user-friendly interface and key functionalities, including one-touch beverage selection and automatic milk frothing.

3. Setup

3.1 Unpacking

1. Remove the appliance from its packaging.
2. Remove all packaging materials, including protective films.
3. Place the machine on a stable, flat surface away from water sources and heat.

3.2 First Use and Rinsing

1. Fill the water tank with fresh water up to the MAX level.
2. Plug the machine into a power outlet.
3. Follow the on-screen instructions for the initial rinsing cycle. This process cleans the internal circuits.

4. Empty the drip tray after the rinsing cycle is complete.

3.3 Grinder Adjustment

The integrated grinder allows you to adjust the fineness of the coffee grounds. A finer grind produces a stronger coffee, while a coarser grind results in a milder taste.



Figure 3.1: Adjusting the grind settings for optimal coffee flavor. The machine features 13 settings for precise control.

- Adjust the grind setting only when the coffee grinder is operating.
- Turn the adjustment knob inside the bean hopper to select your desired grind level.

4. Operating the Coffee Machine

4.1 Making Espresso and Coffee

1. Ensure the water tank is filled and coffee beans are in the hopper.

2. Place one or two cups under the coffee spouts.
3. Select your desired beverage (e.g., Espresso, Coffee) from the intuitive LCD display.
4. The machine will automatically grind the beans, brew, and dispense your coffee.



Figure 4.1: The intuitive user interface with colored icons for easy beverage selection.

4.2 Making Milk-Based Beverages (LatteCrema System)

The automatic LatteCrema system allows for perfect milk foam for cappuccino, latte macchiato, and other milk-based drinks.



Figure 4.2: The LatteCrema system in action, producing rich and creamy milk foam for various beverages, including plant-based options.

1. Fill the milk carafe with fresh milk (cold, preferably skimmed or semi-skimmed). The system is also suitable for plant-based beverages.
2. Attach the milk carafe to the machine.
3. Place a cup under the milk spout and coffee spouts.
4. Select your desired milk-based beverage (e.g., Cappuccino, Latte Macchiato).
5. The machine will automatically froth and dispense the milk, then brew and add the coffee.

4.3 Using Pre-Ground Coffee

This machine also allows the use of pre-ground coffee, ideal for decaffeinated or different blends.

- Open the ground coffee funnel cover.
- Add one level scoop of pre-ground coffee (do not overfill).
- Select the pre-ground coffee option on the display before brewing.

5. Maintenance

Regular cleaning and maintenance ensure optimal performance and longevity of your coffee machine.

5.1 Daily Cleaning

- **Drip Tray:** Empty and clean the drip tray daily. Remove the grid and rinse with warm water.
- **Coffee Grounds Container:** Empty the coffee grounds container when prompted by the machine, or at least once a day. Rinse with warm water.
- **Milk Carafe:** After each use, perform the automatic cleaning cycle for the milk carafe. Disassemble and wash all components of the carafe regularly with warm water and mild detergent.

5.2 Brew Unit Cleaning

The brew unit should be cleaned monthly or after approximately 200 coffees.

1. Turn off the machine and unplug it.
2. Open the brew unit access door.
3. Remove the brew unit by pressing the two red release buttons.
4. Rinse the brew unit thoroughly under running water until no coffee residue is visible.
5. Allow the brew unit to air dry completely before reinserting.

5.3 Descaling

The machine will indicate when descaling is required. Use only De'Longhi descaler.

1. Follow the on-screen instructions for the descaling procedure.
2. The process typically involves adding descaling solution to the water tank and running a cycle, followed by rinsing cycles.

5.4 Water Filter Replacement

Replace the water filter approximately every 2 months, or as indicated by the machine.

- Remove the old filter from the water tank.
- Insert a new De'Longhi water filter according to the instructions provided with the filter.

6. Troubleshooting

Problem	Possible Cause	Solution
Coffee is not hot enough	Cups are cold; machine not preheated; low brewing temperature setting.	Warm cups with hot water; allow machine to preheat fully; increase brewing temperature in settings.
No coffee is dispensed	Water tank empty; brew unit clogged; descaling needed.	Fill water tank; clean brew unit; perform descaling cycle.
Milk is not frothing properly	Milk carafe dirty; milk type unsuitable; milk not cold enough.	Clean milk carafe thoroughly; use cold, fresh skimmed or semi-skimmed milk; ensure milk is chilled.
Machine displays an error message	Specific error (e.g., 'Empty Grounds', 'Add Water').	Follow the on-screen instructions for the specific error message. Consult the full manual for detailed error codes.

Problem	Possible Cause	Solution

7. Specifications

Feature	Detail
Brand	De'Longhi
Model Number	ECAM 46.860.B
Color	Black
Product Dimensions	53 x 50 x 33 cm
Item Weight	11 Kilograms (approx. 24.25 lbs)
Water Tank Capacity	2 Liters
Power / Wattage	1450 Watts
Voltage	3.6V (*Note: This voltage value seems unusual for a coffee machine. Please refer to the product label for accurate voltage requirements.*)
Material	Stainless Steel
Special Features	Programmable, Automatic Shut-off
Filter Type	Reusable



Figure 7.1: Product dimensions for placement consideration.

8. Warranty and Support

This De'Longhi appliance comes with a manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official De'Longhi website.

For technical support, spare parts, or service inquiries, please contact De'Longhi customer service. Contact information can typically be found on the official De'Longhi website or in the product packaging.

It is recommended to register your product online to facilitate warranty claims and receive important product updates.

© 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08FXDVJ5Z

More documents and user manuals: **https://manuals.plus/**