Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY AMT-RM-YD035

Instruction Manual for ALLIMITY RM-YD035 Remote Control

Model: AMT-RM-YD035

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your ALLIMITY RM-YD035 replacement remote control. This remote is designed to be compatible with various Sony Bravia LCD Digital Color TV models, offering a direct replacement for the original RM-YD035 remote.

Product Overview

The ALLIMITY RM-YD035 is an infrared remote control engineered to replicate the functionality of the original Sony RM-YD035 remote. It features a standard layout of buttons for power, input selection, channel navigation, volume control, menu access, and numerical input.





Image: Front view of the ALLIMITY RM-YD035 remote control, displaying its ergonomic design and button layout.

Compatible Models: This remote control is compatible with a range of Sony Bravia LCD Digital Color TV models, including but not limited to:

- KDL-40EX400, KDL-32EX400, KDL-46EX400
- KDL-40EX401, KDL-32EX301, KDL-22BX300
- KDL-32BX300, KDL-46EX401, KDL-32FA600
- KDL-60EX500, KDL-55EX500, KDL-55EX501
- KDL-46EX500, KDL-46EX501, KDL-40EX500
- KDL-40EX501, KDL-32EX500

If your specific TV model is not listed, please verify compatibility with the manufacturer.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery cover, ensuring it clicks securely into place.



Image: Rear view of the remote control, illustrating the battery compartment and the process of inserting AAA batteries.

2. Initial Use

The ALLIMITY RM-YD035 remote control is designed for immediate use with compatible Sony TVs. No programming is required. Simply install the batteries and point the remote directly at the infrared sensor on your television.

Operating Instructions

To ensure optimal performance, always aim the remote control directly at the infrared sensor on your television. Avoid any obstructions between the remote and the TV sensor.

Key Functions:

- **POWER:** Turns the TV on or off.
- **INPUT:** Selects the video input source (e.g., HDMI 1, AV, Component).
- **THEATER:** Activates Theater mode for optimized picture and sound settings.
- **BRAVIA Sync / PLAY:** Controls BRAVIA Sync compatible devices and playback functions.
- **MENU:** Accesses the TV's main menu.
- **Navigation Buttons (Up/Down/Left/Right/Enter):** Used to navigate menus and confirm selections.
- **RETURN:** Returns to the previous screen or menu.
- **DISPLAY:** Shows on-screen information.
- **VOL (+/-):** Adjusts the volume level.
- **CH (+/-):** Changes TV channels.
- **MUTING:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Directly selects channels or inputs numerical data.
- **CC (Closed Caption):** Toggles closed captions on or off.

Maintenance

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops working. Always use new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries responsibly according to local regulations.

Cleaning:

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Troubleshooting

Problem	Possible Cause	Solution
Remote is not working.	◦ Dead or incorrectly inserted batteries. ◦ Obstruction between remote and TV sensor. ◦ Remote is out of range. ◦ TV sensor is blocked or faulty.	◦ Replace batteries with new AAA alkaline batteries, ensuring correct polarity. ◦ Remove any objects blocking the line of sight to the TV's infrared sensor. ◦ Move closer to the TV. ◦ Ensure the TV's infrared sensor is clean and unobstructed.

Problem	Possible Cause	Solution
Some buttons are not responding.	◦ Low battery power. ◦ Button stuck or dirty. ◦ Compatibility issue with a specific TV function.	◦ Replace batteries. ◦ Gently press and release the button multiple times. Clean around the button if visible debris is present. ◦ Verify your TV model is fully compatible with all functions of the RM-YD035.

If troubleshooting steps do not resolve the issue, please contact ALLIMITY customer support for further assistance.

Specifications

- **Model Number:** AMT-RM-YD035
- **Brand:** ALLIMITY
- **Product Dimensions:** 7 x 2 x 0.65 inches
- **Item Weight:** 3.17 ounces
- **Batteries Required:** 2 x AAA (Alkaline recommended)
- **Color:** Black
- **Special Feature:** Ergonomic design
- **Compatible Devices:** Television (Sony Bravia LCD Digital Color TV models)

Warranty and Support

This product is manufactured by ALLIMITY. Specific warranty details may vary; please refer to the product packaging or contact ALLIMITY directly for warranty information.
For technical support or inquiries, please visit the ALLIMITY official website or contact their customer service department. Keep your purchase receipt for any warranty claims.

© 2025 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08G1HN24S

More documents and user manuals: **https://manuals.plus/**