ZdalaMit RMT-AM330U

ZdalaMit RMT-AM330U Replacement Remote Control Instruction Manual

For Sony Audio Systems

1. Introduction

This manual provides instructions for the ZdalaMit RMT-AM330U replacement remote control. This remote is designed to operate various Sony Audio Systems without the need for programming or pairing. Simply install batteries, and it is ready for use.

2. Setup

2.1 Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

2.2 Initial Use

No programming or pairing is required for this replacement remote control. Once batteries are installed, the remote is ready to operate compatible Sony Audio Systems.

3. Remote Control Layout and Functions

Below is an image of the ZdalaMit RMT-AM330U remote control, followed by a description of its buttons and their functions.



Figure 1: Front view of the ZdalaMit RMT-AM330U Replacement Remote Control. It features a dark gray body with black buttons, clearly labeled for various audio system functions.

3.1 Button Overview

- **POWER**: Turns the audio system on or off.
- **SCORE**: Activates or deactivates the scoring function (if available on the audio system).
- **DISPLAY**: Changes the information displayed on the audio system's screen.
- **SLEEP**: Sets the sleep timer for automatic power off.
- **PLAY MODE**: Selects different playback modes (e.g., normal, shuffle, repeat).
- **REPEAT/FM MODE**: Toggles repeat playback or switches FM radio modes.
- **PARTY LIGHT**: Controls the party lighting feature of the audio system.
- **LIGHT MODE**: Changes the lighting mode or pattern.
- **REC TO USB**: Initiates recording to a USB device.
- **TUNER MENU**: Accesses the tuner menu for radio settings.
- **BACK**: Returns to the previous menu or screen.
- **OPTIONS**: Displays additional options for the current function.
- **Directional Pad (Up, Down, Left, Right, Enter)**: Navigates through menus and confirms selections.
- **FUNCTION**: Selects the input source or function (e.g., CD, USB, FM, Bluetooth).
- **MEGA BASS**: Enhances bass output.
- **SOUND FIELD**: Adjusts the sound field or equalizer settings.
- **TUNING -** / **+**: Adjusts radio frequency or track/chapter skipping.
- **PRESET -** / **+**: Selects preset radio stations.
- **Play/Pause (►/▮▮)**: Starts or pauses playback.
- **Stop (■)**: Stops playback.
- **VOCAL FADER**: Reduces the vocal level of a track for karaoke.
- **KEY CONTROL (#** / ♭**)**: Adjusts the key of the music for karaoke.
- **MIC ECHO**: Adds an echo effect to the microphone input.
- **VOL +** / **-**: Increases or decreases the volume level.

4. Compatibility

This ZdalaMit RMT-AM330U replacement remote control is compatible with the following Sony Audio System models:

- MHC-V50
- MHC-M20
- MHC-V21
- MHC-V77W
- MHC-V71
- MHC-V90W
- SHAKE-X10
- SHAKE-X30
- MHC-V13
- MHC-V02

5. Maintenance

5.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA alkaline).

5.2 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild cleaning solution. Avoid using abrasive cleaners, alcohol, or solvents, as these can damage the remote's surface or labels.

5.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

If you encounter issues with your remote control, please refer to the following common problems and solutions:

Problem	Possible Solution
Remote control does not work.	Ensure batteries are inserted correctly with the correct polarity. Replace old batteries with new AAA alkaline batteries. Check for any obstructions between the remote and the audio system's sensor. Ensure you are within the effective range of the audio system.
Certain buttons do not respond.	Verify that the button's function is supported by your specific Sony Audio System model. Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris. If the issue persists, the remote may be faulty.
Remote works intermittently.	Batteries may be low; replace them. Ensure a clear line of sight to the audio system.

7. Specifications

Feature	Detail
Model	RMT-AM330U
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	4.8 x 1.8 x 0.56 inches (approximately 12.2 x 4.6 x 1.4 cm)
Item Weight	1.41 ounces (approximately 40 grams)
Color	Black
Special Feature	Pre-programmed, no setup required

Feature	Detail
Compatible Devices	Sony Audio Systems (specific models listed in Section 4)

8. Support

If you have any questions or require further assistance regarding your ZdalaMit RMT-AM330U replacement remote control, please contact the seller or manufacturer through your purchase platform. Provide your order details for efficient support.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question