Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit NC184

ZdalaMit NC184 Replacement Remote Control Instruction Manual

For Sanyo DVD Recorder Model FWZV475F

1. Introduction

This instruction manual provides essential information for the proper setup, operation, and maintenance of your ZdalaMit NC184 replacement remote control. This remote is specifically designed to be compatible with the Sanyo DVD Recorder model FWZV475F.

Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

2. Product Overview

The ZdalaMit NC184 is a direct replacement remote control, offering full functionality for your compatible Sanyo DVD Recorder. It requires no programming or pairing; simply insert batteries, and it is ready for use.



Figure 2.1: Front view of the ZdalaMit NC184 replacement remote control. This image displays the full layout of buttons, including power, input select, number pad, navigation, and playback controls.



Figure 2.2: Angled view of the ZdalaMit NC184 replacement remote control. This perspective highlights the ergonomic design and button placement from a side angle.

3. Setup

The ZdalaMit NC184 remote control is designed for immediate use without any complex setup procedures. Follow these steps to begin operation:

1. **Battery Installation:** Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert two (2) 1.5V AA alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.
5. **Ready for Use:** No programming or pairing is required. Once batteries are installed, the remote control is ready to operate your Sanyo DVD Recorder FWZV475F.

Note: Batteries are not included with the remote control.

4. Operating Instructions

This remote control provides all the essential functions for your Sanyo DVD Recorder FWZV475F. Refer to the product overview images for button locations.

- **Power Button (./I):** Turns the DVD recorder on or off.
- **Input Select:** Cycles through available input sources.
- **Number Pad (0-9, ABC-WXYZ):** Used for direct channel selection, time input, or menu navigation.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Display:** Shows on-screen information.
- **Disc Menu** / **Top Menu:** Accesses the menu of a DVD or the main menu.
- **Setup:** Enters the system setup menu.
- **Return:** Returns to the previous screen or menu.
- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind, Skip):** Standard controls for media playback.
- **REC Mode** / **REC (REC):** Controls recording functions.
- **Timer Set:** Configures recording timers.
- **VCR** / **DVD:** Selects between VCR and DVD modes if applicable to your recorder.
- **HDMI:** Selects HDMI input.
- **Audio:** Adjusts audio settings or tracks.
- **Tracking:** Adjusts tracking for VCR playback.

For detailed functions of specific buttons, please refer to your Sanyo DVD Recorder's original instruction manual.

5. Compatibility

This ZdalaMit NC184 replacement remote control is fully compatible with the following Sanyo DVD Recorder model:

- **Sanyo DVD Recorder FWZV475F**

It may also be compatible with other Sanyo models that originally used the NC184 or NC184UH remote control. Please verify your device's original remote model if it is not listed above.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid or aerosol cleaners directly on the remote.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AA alkaline batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Avoid Extreme Conditions:** Keep the remote away from direct sunlight, high temperatures, humidity, and strong magnetic fields.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote control does not work.	◦ Batteries are dead or inserted incorrectly. ◦ Obstruction between remote and DVD recorder. ◦ Remote control is too far from the DVD recorder.	◦ Replace batteries with new 1.5V AA alkaline batteries, ensuring correct polarity. ◦ Remove any objects blocking the line of sight between the remote and the DVD recorder's infrared sensor. ◦ Move closer to the DVD recorder.
Some buttons do not respond.	◦ Batteries are low. ◦ Button malfunction.	◦ Replace batteries. ◦ If the issue persists after battery replacement, contact customer support.

This remote control does not require programming. If it is not functioning, the issue is typically related to batteries or line of sight.

8. Specifications

Model: NC184

Compatible Models: Sanyo DVD Recorder FWZV475F

Power Supply: 2 x 1.5V AA Alkaline Batteries (not included)

Connectivity Technology: Infrared (IR)

Product Dimensions: 5.8 x 1.5 x 0.6 inches

Item Weight: 1.41 ounces

Max Number of Supported Devices: 1

9. Warranty and Support

For any questions, concerns, or support regarding your ZdalaMit NC184 replacement remote control, please contact your retailer or the manufacturer directly.

Please have your purchase information and product model (NC184) available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GCD2191

More documents and user manuals: **https://manuals.plus/**