Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HENCKELS 36450-150

HENCKELS 2.2L Programmable Classic Drip Coffee Maker User Manual

Model: 36450-150

Introduction

Thank you for choosing the HENCKELS 2.2L Programmable Classic Drip Coffee Maker. This manual provides important information for the safe operation, maintenance, and troubleshooting of your new appliance. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Information

- Always unplug the coffee maker from the outlet when not in use and before cleaning.
- Do not immerse the cord, plug, or coffee maker in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended by the manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the appliance for other than intended household use.

Product Overview

Familiarize yourself with the components of your HENCKELS Drip Coffee Maker.



Figure 1: Front view of the HENCKELS 2.2L Programmable Classic Drip Coffee Maker, showcasing its stainless steel finish, digital display, control buttons, and glass carafe.



Figure 2: The coffee maker positioned on a countertop with two filled coffee cups and cookies, illustrating its compact size and aesthetic appeal in a typical kitchen environment.



Figure 3: Side view of the coffee maker, highlighting the clear water level indicator on the side of the unit, which allows for easy monitoring of the water reservoir's contents.



Figure 4: Top-down view of the coffee maker with the lid open, revealing the removable filter basket and the water filling area, demonstrating ease of access for adding water and coffee grounds.



Figure 5: A close-up image of the gold-tone reusable filter basket, designed to remove impurities and enhance coffee flavor, which is included with the coffee maker.



Figure 6: The gold-tone reusable filter basket shown with its approximate dimensions (17.2cm height, 34cm width, 28.7cm depth), providing a clear understanding of its size.

Components:

- Main Unit with Control Panel and Digital Display
- Removable Water Tank
- Glass Carafe (12-cup capacity)
- Removable Filter Basket
- Gold Tone Permanent Filter
- Charcoal Water Filter (replaceable)

Setup

Unpacking and Initial Cleaning:

1. Carefully remove all packaging materials from the coffee maker.
2. Wash the glass carafe, lid, and removable filter basket in warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the coffee maker with a damp cloth.

First Use Cycle:

Before brewing coffee for the first time, it is recommended to run a full brewing cycle with only water to clean the internal components.

1. Fill the water tank with clean water up to the 12-cup mark.
2. Place the empty filter basket into its holder. Do not add coffee grounds.
3. Place the empty glass carafe on the warming plate.
4. Plug the coffee maker into a standard electrical outlet.
5. Press the 'START/STOP' button to begin the cycle.
6. Once the cycle is complete, discard the water from the carafe. Your coffee maker is now ready for use.

Operating Instructions

Brewing Coffee:

1. Ensure the coffee maker is plugged in.
2. Fill the removable water tank with fresh, cold water to your desired number of cups (4-12 cups).
3. Open the top lid and place the gold-tone permanent filter (or a paper filter) into the filter basket.
4. Add the desired amount of ground coffee to the filter. A general guideline is one level tablespoon of coffee grounds per cup. Adjust to taste.
5. Close the top lid securely.
6. Place the glass carafe onto the warming plate.
7. Press the 'START/STOP' button to begin brewing. The indicator light will illuminate.
8. If brewing 4 cups or less, press the '1-4 CUP' button before pressing 'START/STOP' for optimized brewing.
9. The coffee maker will automatically shut off after brewing is complete and the warming plate cycle has ended.

Setting the Clock:

1. Plug in the coffee maker. The display will flash '12:00'.
2. Press the 'h' button to set the hour. Press and hold for faster adjustment.
3. Press the 'min' button to set the minutes. Press and hold for faster adjustment.
4. The clock is set once the flashing stops.

Programming Auto-On Time:

The 24-hour programmable timer allows you to set the coffee maker to start brewing at a specific time.

1. Ensure the current time is set correctly.

2. Press the 'Prog' button. The display will show 'PROG' and the time will flash.
3. Use the 'h' and 'min' buttons to set your desired brew time.
4. Press the 'Auto On' button to activate the programmed brew time. The 'AUTO ON' indicator will light up.
5. To cancel the auto-on function, press the 'Auto On' button again.

Pause and Serve Feature:

This feature allows you to pour a cup of coffee before the brewing cycle is complete. Simply remove the carafe from the warming plate. The flow of coffee will temporarily stop. Return the carafe to the warming plate within 20 seconds to prevent overflow.

Filter Reset:

The 'Filter Reset' button is used to reset the charcoal filter indicator after replacing the charcoal filter. Refer to the Maintenance section for filter replacement instructions.

Maintenance and Cleaning

Daily Cleaning:

1. Always unplug the coffee maker before cleaning.
2. Remove the filter basket and discard used coffee grounds. Wash the filter basket and glass carafe in warm, soapy water. These parts are also top-rack dishwasher safe.
3. Wipe the exterior of the coffee maker and warming plate with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
4. Do not immerse the coffee maker's main unit in water.

Descaling (Mineral Deposit Removal):

Mineral deposits (calcium) can build up in your coffee maker over time, affecting its performance. Descale your coffee maker every 2-3 months, or more frequently if you have hard water.

1. Fill the water tank with a mixture of 1 part white vinegar and 2 parts cold water.
2. Place an empty carafe on the warming plate.
3. Run a full brewing cycle without coffee grounds.
4. After the cycle, turn off the coffee maker and let it sit for 15 minutes.
5. Discard the vinegar solution.
6. Run 2-3 cycles with fresh, cold water only to rinse out any remaining vinegar smell or taste.

Charcoal Water Filter Replacement:

The charcoal water filter helps remove chlorine and impurities from water. It should be replaced approximately every 60 brewing cycles or every 2 months.

1. Remove the old charcoal filter from its holder in the water tank.
2. Soak a new charcoal filter in cold water for 15 minutes.
3. Insert the new filter into the filter holder.
4. Place the filter holder back into the water tank.

5. Press the 'Filter Reset' button on the control panel to reset the filter counter.

Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew.	Coffee maker not plugged in; 'START/STOP' button not pressed; water tank empty; carafe not properly placed.	Ensure unit is plugged in; press 'START/STOP'; fill water tank; ensure carafe is correctly seated on warming plate.
Coffee is too weak or too strong.	Incorrect coffee-to-water ratio; coffee grind too coarse/fine.	Adjust amount of coffee grounds; use medium grind for drip coffee makers.
Water overflows from filter basket.	Too much coffee grounds; filter clogged; carafe removed for too long during brewing.	Reduce coffee grounds; clean filter basket; ensure carafe is returned within 20 seconds during Pause and Serve.
Coffee maker leaks.	Water tank not properly seated; carafe not correctly placed; mineral buildup.	Ensure water tank and carafe are correctly positioned; descale the unit.
Clock/Timer not working.	Power interruption; incorrect setting.	Reset the clock; ensure continuous power supply.

Specifications

Brand: HENCKELS

Model Number: 36450-150

Colour: Silver

Product Dimensions: 28.7D x 34W x 17.2H Centimetres

Capacity: 2.2 liters (12 cups)

Power/Wattage: 1000 watts

Voltage: 120V

Material: Stainless Steel

Special Features: Jug, Programmable, Pause and Serve

Item Weight: 2.42 kg

Filter Type: Paper (or included Gold Tone Permanent Filter)

Coffee Maker Type: Drip Coffee Machine

Warranty and Support

Warranty Information:

This HENCKELS coffee maker comes with a**2-year limited warranty** against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support:

For technical assistance, warranty service, or to order replacement parts, please contact HENCKELS customer support. Refer to the contact information provided on the product packaging or the official HENCKELS website.
Website: www.zwilling.com/ca/ (Please note: HENCKELS is part of the ZWILLING Group)

© 2023 HENCKELS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GCTNSP9

More documents and user manuals: **https://manuals.plus/**