Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NKF BN59-00996A

User Manual for NKF BN59-00996A Remote Control

Model: BN59-00996A
Brand: NKF

Introduction

This manual provides instructions for the NKF BN59-00996A Replacement Remote Control, designed for use with various Samsung LED, LCD, and Plasma Smart TVs. This remote functions as a direct replacement and does not require any programming or pairing. Simply install batteries to begin operation.

Compatible Samsung TV Models include:

- LN32C480, LN32C530, LN32C530F1F, LN32C530F1FXZA, LN32C530F1FXZC, LN32C530F1FXZX, LN32C540, LN32C540F2D, LN32C540F2DXZA, LN32C540F2DXZC, LN32C540F2DXZX, LN32C540F2F, LN32C540F2FXZA
- LN37C530, LN37C530F1F, LN37C530F1FXZA, LN37C530F1FXZX
- LN40C530, LN40C530F1F, LN40C530F1FXZA, LN40C530F1FXZC, LN40C530F1FXZX, LN40C540, LN40C540F2F, LN40C540F2FX, LN40C540F2FXZA, LN40C540F2FXZC, LN40C540F2FXZX
- LN46C530, LN46C530F1F, LN46C530F1FXZA, LN46C530F1FXZC, LN46C530F1FXZX, LN46C540, LN46C540F2F, LN46C540F2FXZA, LN46C540F2FXZC, LN46C540F2FXZX
- LN52C530, LN52C530F1F, LN52C530F1FXZA, LN52C530F1FXZC, LN52C530F1FXZX
- PL50C530, PL50C530C1F, PL50C530C1FXZX, PN50C530, PN50C530C1F, PN50C530C1FXZA, PN50C540, PN50C540G3F, PN50C540G3FXZA, PN50C540G3FXZC
- PN58C500, PN58C500G2F, PN58C500G2FXZA, PN58C530, PN58C530G3F, PN58C540, PN58C540G3F, PN58C540G3FXZA, PN58C540G3FXZC
- PN63C540, PN63C540G3F, PN63C540G3FXZA, PN63C550G1F, PN63C550G1FXZA, PN63C590G4F, PN63C590G4FXZA
- UN19C4000, UN19C4000PD, UN19C4000PDXZA, UN22C4000, UN22C4000PD, UN22C4000PDXZA, UN22C4000PDXZX, UN22C4010
- UN26C4000, UN26C4000PD, UN26C4000PDXZA, UN26C4000PDXZC, UN26C4000PDXZX
- UN32C4000, UN32C4000PD, UN32C4000PDXZA, UN32C4000PDXZC, UN32C4000PDXZP, UN32C4000PDXZX
- BN68-02540A-04, BN68-02540A-04 LC530-ZA

Setup

The BN59-00996A remote control requires two (2) AAA alkaline batteries for operation. Batteries are not included with the remote.

1. **Locate the Battery Compartment:** Turn the remote control over to its back side. The battery compartment cover is located at the bottom of the remote.
2. **Open the Battery Compartment:** Gently slide the battery compartment cover downwards or press the latch (if present) and lift to remove the cover.

3. **Insert Batteries:** Insert two AAA alkaline batteries into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. **Close the Battery Compartment:** Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the battery insertion process.

Once batteries are installed, the remote control is ready for use with your compatible Samsung TV without any additional programming.

Operating Instructions

The BN59-00996A remote control provides full functionality for your Samsung TV. Below are common button functions:



Image: Front view of the remote control, displaying all operational buttons.

- **POWER (Red Button):** Turns the TV on or off.
- **SOURCE:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **Number Buttons (0-9):** Directly select channels.
- **PRE-CH:** Returns to the previously viewed channel.
- **VOL (+/-):** Adjusts the volume level.

- **CH (+/-):** Changes the channel up or down.
- **MUTE:** Mutes or unmutes the TV sound.
- **MENU:** Opens the TV's main menu.
- **TOOLS:** Accesses quick settings or tools menu.
- **INFO:** Displays information about the current program or input.
- **Directional Pad (Up, Down, Left, Right) & ENTER:** Navigates through menus and confirms selections.
- **RETURN:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or function.
- **Colored Buttons (A, B, C, D):** Functionality varies depending on the TV model and current application (e.g., teletext, smart TV features).
- **S.MODE (Sound Mode):** Cycles through sound modes.
- **SLEEP:** Sets a sleep timer for the TV.
- **P.SIZE (Picture Size):** Adjusts the picture aspect ratio.
- **MTS (Multi-channel Television Sound):** Selects audio options (e.g., Stereo, SAP).
- **CC (Closed Caption):** Toggles closed captions on or off.
- **Media Playback Controls (Play, Pause, Stop, Fast Forward, Rewind, Skip):** Controls media playback when using compatible TV functions or connected devices.

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.
- **Liquid Exposure:** Keep the remote away from liquids to prevent damage to the electronics.

Troubleshooting

If you experience issues with your BN59-00996A remote control, consider the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there is a clear line of sight between the remote control and the TV's infrared (IR) receiver. Obstructions can block the signal.
  - Verify that the TV is powered on and not in standby mode.
- **Buttons Not Working:**
  - Clean the remote's surface, especially around the buttons, to remove any dirt or debris that might be obstructing button presses.
  - If only specific buttons are not working, it might indicate internal damage.
- **Remote Range is Limited:**

- Ensure batteries are fresh. Weak batteries can reduce the remote's effective range.
- Minimize sources of infrared interference in the room (e.g., direct sunlight, certain fluorescent lights).

If these steps do not resolve the issue, please refer to the "Warranty and Support" section for further assistance.

Specifications

Model Number	BN59-00996A
Brand	NKF
Compatible Devices	Samsung Television (LED, LCD, Plasma Smart TV)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	7.3 x 2 x 0.67 inches (18.5 x 5.1 x 1.7 cm)
Item Weight	2.9 ounces (82 grams)
Color	Black
Special Feature	Ergonomic design
Country of Origin	China

Warranty and Support

This product is a replacement remote control. While specific warranty details are not provided in this manual, the manufacturer is committed to customer satisfaction.
If you have any questions, concerns, or require assistance with your BN59-00996A remote control, please do not hesitate to contact the seller or manufacturer directly. It is recommended to reach out before leaving feedback or initiating a return, as they are committed to resolving any issues you may encounter.
For support, please refer to the contact information provided by your retailer or the product packaging.

© 2024 NKF. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GH427WH

More documents and user manuals: **https://manuals.plus/**