**ORFELD B08**

# ORFELD Cordless Vacuum Cleaner User Manual

**Model: EV-679 (B08)**

Brand: **ORFELD**

## 1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Keep this manual for future reference.

- Do not use the device to absorb liquids. This can cause electric shock or damage to the appliance.
- Do not handle the plug or appliance with wet hands.
- Do not use the vacuum cleaner without the dust cup and filter in place.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Store the appliance indoors. Put it away after use to prevent accidents.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## 2. Package Contents

Verify that all items are included in your package:

- 1 x ORFELD Cordless Vacuum Cleaner (Main Unit)
- 1 x Floor Nozzle with Brush Roller
- 1 x 2-in-1 Combination Nozzle
- 1 x Extension Tube
- 1 x Wall Mount and Charger

- 1 x User Manual
- 1 x Warranty Card



Image: The ORFELD Cordless Vacuum Cleaner shown with its main unit, extension tube, and floor nozzle, illustrating its versatile configurations.

## 3. Product Overview and Features

The ORFELD EV-679 is a lightweight and powerful cordless vacuum cleaner designed for comprehensive home cleaning.

- **Lightweight Design:** The main body weighs only 1.23 kg, making it easy to handle for extended cleaning sessions and suitable for various users.
- **Powerful Suction:** Equipped with a 'Hurricane' brushless motor, it delivers up to 18,000 Pa suction power in Max mode for deep cleaning of dirt, pet hair, and debris.
- **Long Runtime:** The premium lithium-ion battery provides up to 50 minutes of runtime in standard mode (8000 Pa), covering up to 180 m2 on a single charge.
- **2-in-1 Versatility:** Easily converts from a stick vacuum to a handheld vacuum for cleaning various surfaces, including floors, stairs, upholstery, and car interiors.
- **Efficient Filtration:** Features a T10 filtration system with a stainless steel filter, ensuring fresh air and consistent suction. The HEPA filter is washable for prolonged optimal performance.
- **User-Friendly Features:** Includes LED lighting on the nozzle to illuminate hidden dust, ultra-quiet operation at 72 dB, and a one-button dust container emptying system.



Image: An internal view of the vacuum cleaner's dust collection system, highlighting the cyclonic technology for efficient dust separation.

# 4. Setup

## 4.1 Assembly

1. Insert the extension tube into the main vacuum unit until it clicks into place.
2. Attach the desired cleaning head (floor nozzle or 2-in-1 combination nozzle) to the end of the extension tube.
3. For handheld use, attach the 2-in-1 combination nozzle directly to the main vacuum unit.

## 4.2 Charging the Battery

Before first use, fully charge the vacuum cleaner's battery.

- Connect the charger to a power outlet.
- Plug the charger into the charging port on the main vacuum unit or the wall mount.
- The charge capacity indicator will show the charging status. A full charge typically takes 4-5 hours.
- The vacuum features overload and soft start protection for battery longevity.



Image: A close-up of the main vacuum unit, showing the battery indicator lights which display the current charge level.

# 5. Operating the Vacuum Cleaner

## 5.1 Power On/Off and Suction Modes

- Press the power button to turn the vacuum cleaner on. It will start in standard mode (8000 Pa).
- Press the mode button to switch to Max mode (18,000 Pa) for stronger suction on stubborn dirt.
- Press the power button again to turn the vacuum cleaner off.

## 5.2 Using Different Attachments

- **Floor Nozzle:** Ideal for cleaning hard floors and carpets. The integrated LED lighting helps reveal hidden dust.
- **2-in-1 Combination Nozzle:** Use the brush attachment for delicate surfaces like upholstery or curtains, and the crevice tool for narrow gaps and corners.



Image: A woman using the ORFELD vacuum cleaner on a hard floor, demonstrating its maneuverability and LED light feature.



Image: A woman cleaning stairs with the ORFELD vacuum, highlighting its lightweight design for elevated cleaning.



Image: A woman reaching high blinds with the extended ORFELD vacuum, showcasing its ability to clean elevated surfaces.



Image: The handheld configuration of the ORFELD vacuum being used to clean a car seat, demonstrating its portability and effectiveness in tight spaces.



Image: A woman comfortably cleaning a couch with the handheld ORFELD vacuum, illustrating its ease of use for upholstery.

## 6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

### 6.1 Emptying the Dust Container

- Ensure the vacuum is turned off.
- Press the dust container release button to detach it from the main unit.

- Position the dust container over a trash bin and press the release button to open the bottom flap and empty the contents.
- Close the flap and reattach the dust container to the main unit until it clicks.

## 6.2 Cleaning the HEPA Filter and Accessories

The HEPA filter and other accessories are washable.

- Remove the HEPA filter from the dust container.
- Rinse the HEPA filter and other washable accessories under running water until clean.
- Allow all washed parts to air dry completely for at least 24 hours before reassembling. Do not use the vacuum with wet filters.



Image: Hands demonstrating the detachment of the dustbin from the main vacuum unit, illustrating the easy emptying process.

## 7. Troubleshooting

If you encounter issues with your ORFELD vacuum cleaner, refer to the following common problems and solutions:

- **No Power:** Ensure the battery is fully charged. Check if the power button is pressed correctly.
- **Low Suction Power:**
  - Check if the dust container is full and needs emptying.
  - Inspect the HEPA filter and clean it if it's clogged. Ensure it's completely dry before reinserting.
  - Check for blockages in the extension tube, floor nozzle, or combination nozzle.
- **Vacuum Stops During Use:** This could be due to the overload protection activating. Turn off the vacuum, clear any blockages, and allow it to cool down before restarting. Ensure the battery is not completely depleted.
- **Unusual Noise:** Turn off the vacuum immediately. Check for any foreign objects caught in the brush roller or air pathways.

If the problem persists after following these steps, please contact customer support.

## 8. Specifications

| Feature | Specification |
|---|---|
| Brand | ORFELD |
| Model Number | B08 (EV-679) |
| Color | Blue |
| Product Dimensions (L x W x H) | 109.2 x 24.5 x 27.8 cm |
| Item Weight | 1.98 kg (vacuum + extension tube + brush) |
| Rated Input Power | 200 Watts |
| Voltage | 220 Volts |
| Material | Aluminum + PP + ABS + PA + PC + TPE |
| Noise Level | 72 dB |
| Suction Power Levels | Standard: 8000 Pa, Max: 18000 Pa |
| Battery Capacity | 2200 mAh Lithium-ion |
| Runtime | Up to 50 minutes (Standard mode) / 15 minutes (Max mode) |
| Dust Tank Volume | 0.5 L |

| Feature | Specification |
| --- | --- |
| Filter Type | Washable HEPA Filter, Stainless Steel Filter |
| Special Features | Lightweight, Cordless, Bagless, LED Lighting, Wall Mount, Overload/Overcharge Protection, Soft Start Protection |

## 9. Warranty and Support

Your ORFELD Cordless Vacuum Cleaner comes with a warranty. Please refer to the included Warranty Card for detailed terms and conditions, including the warranty period and coverage.

For technical support, troubleshooting assistance beyond what is provided in this manual, or to inquire about spare parts, please contact ORFELD customer service. Contact information can typically be found on the warranty card or the official ORFELD website.

Always ensure you have your product model number (B08) and purchase details ready when contacting support.

© 2024 ORFELD. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question