BELIFE Sharp TV Remote Control

BELIFE® Replacement Remote Control User Manual

For Sharp TV Models: 55BJ2E, 55BJ2K, 55BJ3E, 65BJ2E, 65BJ3E

1. Product Overview

This BELIFE® replacement remote control is designed to function immediately with the specified Sharp TV models. It provides all essential controls for your television, including power, volume, channel selection, menu navigation, and direct access to popular streaming services.





Image: BELIFE Replacement Remote Control. This image displays the full layout of the remote control, showing all buttons and their labels, including power, mute, number pad, volume, channel, navigation, and dedicated app buttons.

Button Functions:

- **ON/OFF (Red Button):** Powers the TV on or off.
- **MUTE:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Directly select channels or input numerical values.
- **TV GUIDE:** Accesses the electronic program guide.
- **PICTURE, SOUND, SOURCE:** Accesses picture settings, sound settings, and input source selection respectively.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the TV channel up or down.

- **MENU:** Opens the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right):** Navigate through menus and options.
- **OK:** Confirms selections in menus.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or function.
- **FAV:** Accesses favorite channels.
- **INFO:** Displays information about the current program or input.
- **TEXT:** Activates or deactivates Teletext.
- **SUBTITLE:** Toggles subtitles on or off.
- **TV:** Switches to TV mode.
- **YouTube, NETFLIX, NET-:** Direct access buttons for respective streaming applications.
- **Media Control Buttons (Play, Pause, Stop, Fast Forward, Rewind, Next, Previous):** Control media playback.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and context, often used for specific menu options or interactive services.

2. Setup

Setting up your BELIFE® replacement remote control is a straightforward process. No programming is required for the specified Sharp TV models.

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote control is ready for immediate use with compatible Sharp TV models.

3. Operating Instructions

This section provides basic instructions for operating your TV using the BELIFE® replacement remote control.

- **Power On/Off:** Press the **ON/OFF** button once to turn the TV on or off.
- **Channel Selection:** Use the **CH +/-** buttons to cycle through channels. Alternatively, use the **Number Buttons (0-9)** to directly enter a channel number.
- **Volume Adjustment:** Press **VOL +** to increase volume and **VOL -** to decrease volume.
- **Mute Sound:** Press the **MUTE** button to temporarily silence the TV. Press again to restore sound.

- **Accessing Menus:** Press the **MENU** button to open the TV's main menu. Use the **Navigation Buttons** (Up, Down, Left, Right) to move through options and **OK** to select.
- **Changing Input Source:** Press the **SOURCE** button to cycle through available input sources (e.g., HDMI 1, AV, TV).
- **Direct App Access:** Use the dedicated **YouTube** and **NETFLIX** buttons to launch these applications directly (requires internet connection and TV smart features).
- **Media Playback:** When watching content from a connected device or smart TV app, use the **Media Control Buttons** (Play, Pause, Stop, Fast Forward, Rewind, Next, Previous) for playback control.

4. Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new alkaline batteries of the same type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, or immerse it in liquids.

5. Troubleshooting

If you experience issues with your remote control, try the following troubleshooting steps:

1. **Remote Not Responding:**
   - Ensure the batteries are inserted correctly with the correct polarity (+/-).
   - Replace old batteries with new AAA alkaline batteries.
   - Make sure there are no obstructions between the remote control and the TV's infrared sensor.
   - Point the remote directly at the TV's sensor.
2. **Buttons Not Working Consistently (e.g., requires multiple presses):**
   - This often indicates low battery power. Replace the batteries.
   - Ensure the remote is clean and free of debris that might obstruct button presses.
3. **Remote Works for Some Functions, But Not Others:**
   - Verify that your TV model is listed as compatible (55BJ2E, 55BJ2K, 55BJ3E, 65BJ2E, 65BJ3E).
   - Some advanced TV features or specific smart TV functions might require the original TV remote or a TV-specific app.

If the issue persists after trying these steps, consider contacting the seller or manufacturer for further assistance.

6. Specifications

Feature	Detail
Brand	BELIFE
Compatible Devices	Sharp Televisions (Models: 55BJ2E, 55BJ2K, 55BJ3E, 65BJ2E, 65BJ3E)
Connectivity Technology	Infrared
Controller Type	Button Control
Model Name	Sharp TV Remote Control
Maximum Range	10 Meters
Battery Type	Alkaline (AAA, not included)
Number of Colored Buttons	4 (Red, Green, Yellow, Blue)

7. Warranty and Support

Specific warranty details for this BELIFE® replacement remote control are not provided in the available product information. For any warranty claims or technical support, please refer to the seller or the manufacturer's official website.

For general inquiries or further assistance, you may contact the seller directly through the platform where the product was purchased.

© 2024 BELIFE. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question