ALLIMITY AMT-3in1-sam-BN59-01300J

User Manual for ALLIMITY BN59-01300J Voice Remote Control

Model: BN59-01300J

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your new ALLIMITY BN59-01300J Voice Remote Control. This remote is designed as a replacement for various Samsung Smart 4K TV models, offering voice command functionality and standard remote control features.

Package Contents:

- 1 x ALLIMITY BN59-01300J Voice Remote Control
- 1 x User Manual (this document)





Figure 1: ALLIMITY BN59-01300J Voice Remote Control

This image displays the front of the ALLIMITY BN59-01300J Voice Remote Control. It features a minimalist black design with clearly labeled buttons for power, voice control, numerical input, smart hub access, navigation, home, back, play/pause, volume, and channel control. The remote has a smooth, ergonomic shape.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2: Battery Installation

This image shows the rear of the ALLIMITY BN59-01300J Voice Remote Control with its battery cover removed. Two AAA batteries are visible within their respective slots, demonstrating the correct orientation for insertion. The internal circuitry and battery contacts are also visible.

Note: Ensure batteries are inserted with correct polarity. Incorrect installation may prevent the remote from functioning.

3. Operating Instructions

3.1 Basic Operation

To operate the remote control, aim it directly at the infrared sensor on your Samsung Smart 4K TV. Ensure there

are no obstacles between the remote control and the TV sensor to maintain a clear signal.

3.2 Voice Command Functionality

This remote control supports voice commands. To use this feature, press and hold the **Voice** button (microphone icon) and speak clearly into the remote. Release the button when you have finished speaking. The TV will process your command.

3.3 Button Functions

- **Power Button** (*red circle with line*): Turns the TV on or off.
- **Voice Button** (*microphone icon*): Activates voice command input.
- **123/Numeric Pad** (*123 icon*): Displays the on-screen numeric pad for direct channel input or other numerical entries.
- **Smart Hub/Home** (*house icon*): Accesses the Smart Hub or returns to the home screen.
- **Back Button** (*curved arrow*): Returns to the previous screen or menu.
- **Play/Pause** (*play/pause icon*): Controls media playback.
- **Volume (VOL)**: Adjusts the TV volume. Press the top part for volume up, bottom for volume down. Press the center to mute.
- **Channel (CH)**: Changes TV channels. Press the top part for channel up, bottom for channel down.
- **Directional Pad (D-Pad)**: Navigates through menus and selections.
- **Select/Enter Button** (*center of D-Pad*): Confirms selections.

4. Maintenance

4.1 Cleaning the Remote Control

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials, as they may damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.3 Storage

When not in use for extended periods, it is recommended to remove the batteries from the remote control to prevent potential leakage and damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

5.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are correctly installed with proper polarity. Replace with fresh AAA batteries if needed.
- **Line of Sight:** Verify there are no obstructions between the remote control and the TV's infrared sensor.
- **Distance:** Ensure you are within the effective operating range of the TV's sensor.
- **TV Sensor:** Confirm the TV's infrared sensor is not blocked or dirty.

5.2 Voice Command Issues

- **Microphone Blocked:** Ensure the microphone on the remote is not covered.
- **Speak Clearly:** Speak clearly and at a normal volume directly into the microphone.
- **Hold Button:** Remember to press and hold the Voice button while speaking and release it when finished.
- **TV Settings:** Check your TV's settings to ensure voice recognition is enabled and configured correctly.

6. Specifications

Feature	Detail
Model Number	BN59-01300J (Substitutes: BN59-01300F, BN59-01298H, BN59-01300H)
Product Material	Plastic
Connectivity Technology	Bluetooth (Voice Command), Infrared (Standard Control)
Compatible Devices	Samsung Smart 4K TVs (Specific models listed below)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	6 x 2 x 0.7 inches (approx.)
Item Weight	1.8 ounces (approx.)

7. Compatible TV Models

This remote control is compatible with a wide range of Samsung Smart 4K TV models, including but not limited to the following:

- QN49Q6
- QN49Q6FN
- QN49Q6FNAFXZA
- QN49Q6FNAFXZC
- QN55Q6
- QN55Q65FNFXZA
- QN55Q6FN
- QN55Q6FNAFXZA
- QN55Q6FNAFXZC
- QN55Q7
- QN55Q75FNFXZA
- QN55Q7CNAFXZA
- QN55Q7CNAFXZC
- QN55Q7FN
- QN55Q7FNAFXZA
- QN55Q7FNAFXZC
- QN55Q8
- QN55Q8FN
- QN55Q8FNBFXZA
- QN55Q8FNBFXZC
- QN65Q6
- QN65Q65FNFXZA

- QN65Q6FN
- QN65Q6FNAFXZA
- QN65Q6FNAFXZC
- QN65Q7
- QN65Q75FNFXZA
- QN65Q7CNAFXZA
- QN65Q7CNAFXZC
- QN65Q7FN
- QN65Q7FNAFXZA
- QN65Q7FNAFXZC
- QN65Q8
- QN65Q8FN
- QN65Q8FNBFXZA
- QN65Q8FNBFXZC
- QN75Q6
- QN75Q65FNFXZA
- QN75Q6FN
- QN75Q6FNAFXZA
- QN75Q6FNAFXZC
- QN75Q7
- QN75Q75FNFXZA
- QN75Q7FN
- QN75Q7FNAFXZA
- QN75Q7FNAFXZC
- QN75Q8
- QN75Q8FN
- QN75Q8FNBFXZA
- QN75Q8FNBFXZC
- QN82Q6
- QN82Q6FN
- QN82Q6FNAFXZA
- QN82Q6FNAFXZC
- QN82Q8
- QN82Q8FN
- QN82Q8FNBFXZA
- QN82Q8FNBFXZC
- QN49Q65FNFXZA
- QN55Q65FNF
- QN55Q65FNFXZC
- QN55Q75CNF
- QN55Q7FNAF
- QN55Q8FNBF
- QN65Q65FNF
- QN65Q65FNFXZC
- QN65Q75CNF

- QN65Q7FNAF
- QN65Q8FNBF
- QN75Q65FNF
- QN75Q65FNFXZC
- QN75Q7FNAF
- QN75Q8FNBF
- QN82Q65FNBXZA
- QN82Q65FNF
- QN82Q65FNFXZA
- QN85Q900RAF
- QN85Q900RAFXZA

If your specific TV model is not listed, please contact the seller for compatibility verification.

8. Warranty and Support

For any questions, concerns, or issues regarding your ALLIMITY BN59-01300J Voice Remote Control, please contact the seller directly through the platform where the purchase was made. They will be able to provide assistance and information regarding warranty terms and technical support.

Please refer to your purchase documentation for specific warranty details provided by ALLIMITY or the reseller.

© 2024 ALLIMITY. All rights reserved.