ALLIMITY RC-911R

ALLIMITY RC-911R Replacement Remote Control Instruction Manual

For Onkyo AV Receivers

Introduction

This manual provides instructions for the ALLIMITY RC-911R replacement remote control. This remote is designed to function as a direct replacement for various Onkyo AV Receiver models, offering seamless control over your audio-visual system. Please read this manual carefully before use to ensure proper operation and to maximize your experience.

Setup

1. Battery Installation

The RC-911R remote control requires two (2) AAA alkaline batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.





Figure 1: Battery compartment of the RC-911R remote control. Insert two AAA batteries according to polarity markings.

Important: Always use new alkaline batteries for optimal performance. Do not mix old and new batteries, or different types of batteries.

Operating Instructions

General Usage

To operate your Onkyo AV Receiver with the RC-911R remote control, point the remote directly towards the infrared (IR) sensor on your receiver. Ensure there are no obstacles between the remote and the receiver's sensor that could block the signal.





Figure 2: Front view of the RC-911R remote control, displaying its button layout.





Figure 3: Angled view of the RC-911R remote control, showing its profile and button arrangement.

Compatible Onkyo AV Receiver Models

The RC-911R remote control is compatible with the following Onkyo AV Receiver models:

- HT-R695
- HT-S7800
- TX-NR555
- TX-NR575
- TX-NR585
- TX-NR656
- TX-NR686
- TX-NR676
- TX-NR757
- TX-NR777
- TX-NR787
- TX-RZ610
- TX-RZ710
- TX-RZ720
- TX-RZ810
- TX-RZ820
- TX-NR575E
- TX-NR676E

If your specific model is not listed, please refer to the "Support" section for assistance.

Maintenance

Battery Replacement

When the remote control's performance degrades or it stops responding, it is likely time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section. Always replace both batteries simultaneously with new AAA alkaline batteries.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are installed correctly with the correct polarity.
  - Replace the batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the AV receiver's IR sensor.
  - Make sure you are pointing the remote directly at the receiver's sensor.
- **Specific functions not working:**
  - Verify that your Onkyo AV Receiver model is listed in the "Compatible Onkyo AV Receiver Models" section.
  - Some advanced functions might require specific settings on your AV receiver. Refer to your receiver's original manual for details.

Specifications

Feature	Detail
Model Number	RC-911R
Product Material	Plastic
Connective Technology	Infrared (IR)
Product Dimensions	7 x 2 x 0.65 inches
Item Weight	2.8 ounces
Batteries Required	2 AAA batteries
Max Number of Supported Devices	1
Special Feature	Ergonomic design

Support

If your specific Onkyo AV Receiver model number is not listed in this manual, or if you encounter any issues not covered

in the troubleshooting section, please contact the seller for assistance. Providing your receiver's model number will help in identifying the correct solution or confirming compatibility.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question