Incapto Incapto Superautomatic Coffee Machine 19 Bar 1470W

Incapto Superautomatic Coffee Machine User Manual

Model: Incapto Superautomatic Coffee Machine 19 Bar 1470W (B08GSMBHCN)

Introduction

Thank you for choosing the Incapto Superautomatic Coffee Machine. This manual provides essential information for the safe and efficient operation, maintenance, and care of your appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions

- Read all instructions carefully before using the appliance.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Ensure the voltage specified on the appliance matches your local mains voltage.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only accessories recommended by the manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the water tank is filled to the appropriate level before brewing.

Product Overview

The Incapto Superautomatic Coffee Machine is designed for convenience and quality, featuring a compact design, 19 bars of pressure, and a 1470W heating system for quick and consistent coffee.



Figure 1: Incapto Superautomatic Coffee Machine highlighting Thermoblock system for rapid heating, pre-infusion for enhanced aroma, and ultra-fast coffee preparation in 30 seconds.



Figure 2: The compact design of the Incapto Superautomatic Coffee Machine, measuring 31.5 cm high, 18 cm wide, and 40 cm deep.

Setup and First Use

1. Unpacking

- Carefully remove all packaging materials and ensure all components are present.
- Place the machine on a stable, flat, heat-resistant surface.

2. Filling the Water Tank



Figure 3: The removable 1.1L water tank with an included filter, located at the top of the machine.

1. Remove the removable water tank (1.1L capacity) from the top of the machine.
2. Fill the tank with fresh, cold water up to the MAX level indicator.
3. Replace the water tank securely.

3. Adding Coffee Beans



Figure 4: The 160-gram coffee bean container with an adjustable grind setting for fresh coffee.

1. Open the lid of the coffee bean container.
2. Pour fresh coffee beans into the container (capacity: 160 grams).
3. Close the lid securely.

4. Initial Rinse Cycle

Before first use, perform a rinse cycle to clean the internal components.

1. Place a large container under the coffee spout.
2. Turn on the machine. It will automatically perform a short rinse cycle.
3. Discard the water. Your machine is now ready for use.

Operating Instructions

1. Touch Display and Coffee Selection



Figure 5: The intuitive touch interface with options for Short Coffee, Long Coffee, and Hot Water. The spout illuminates the cup during brewing.

The machine features a touch display for easy selection of your desired coffee.

- **Short Coffee:** For a concentrated espresso shot.
- **Long Coffee:** For a larger, milder coffee.
- **Hot Water:** For tea or other hot beverages.

2. Adjusting Grind Level

You can adjust the grind level to suit your preference and the type of coffee beans used. A finer grind typically results in a stronger, more intense flavor, while a coarser grind yields a milder taste.

1. Locate the grind adjustment knob inside the bean container (refer to Figure 4).
2. Turn the knob to select your desired grind setting. Adjustments should be made gradually and only when the grinder

is operating.

3. Brewing Coffee

1. Place a cup under the coffee spout. The spout height is adjustable to accommodate cups up to 160 mm.
2. Select your desired coffee type (Short or Long) from the touch display.
3. The machine will automatically grind the beans, pre-infuse, and brew your coffee. Coffee is ready in approximately 30 seconds due to the Thermoblock heating system.

Maintenance and Cleaning

Regular cleaning and maintenance ensure optimal performance and extend the lifespan of your Incapto coffee machine.



Figure 6: Features for easy maintenance and cleaning, including an automatic descaling program, automatic cleaning, removable brewing group, and a removable drip tray with grounds drawer.

1. Daily Cleaning

- **Drip Tray and Grounds Container:** The drip tray and grounds container are removable and magnetic for easy cleaning. Empty and rinse them daily.
- **Removable Brewing Group:** The brewing group is designed to be easily removable for thorough cleaning. Rinse it under running water regularly.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners.

2. Descaling

The machine features an automatic descaling program and LED indicators to alert you when descaling is required.

1. When the descaling indicator lights up, prepare the descaling solution according to the descaler manufacturer's instructions.
2. Follow the on-screen prompts or refer to the detailed descaling instructions in the full manual (not provided here) to initiate the automatic descaling cycle.

3. Included Accessories for Cleaning



Figure 7: The machine comes with 3 packets of descaling powder, a brush for cleaning the grinder, and a cleaning cloth.

- **Descaling Powders (x3):** Use these for the descaling process.
- **Grinder Cleaning Brush:** Use this brush to clean the coffee grinder area.
- **Cleaning Cloth:** For wiping down the machine's exterior.

Troubleshooting

If you encounter issues with your Incapto coffee machine, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Machine does not turn on	No power supply	Check if the power cord is securely plugged into the outlet and the machine.

Problem	Possible Cause	Solution
No coffee is dispensed	Water tank empty / Coffee beans empty	Refill the water tank / Refill the coffee bean container.
Coffee is too weak or too strong	Incorrect grind setting / Coffee quality	Adjust the grind setting (finer for stronger, coarser for weaker). Use fresh, quality coffee beans.
Water leaks from the machine	Water tank not properly seated / Drip tray full	Ensure the water tank is correctly inserted. Empty and clean the drip tray.
Descaling indicator is on	Machine needs descaling	Perform a descaling cycle as per the instructions in the Maintenance section.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Feature	Detail
Brand	Incapto
Model Number	B08GSMBHCN
Type	Superautomatic Espresso Coffee Machine
Color	Black
Dimensions (D x W x H)	31 cm x 18 cm x 40 cm
Capacity (Water Tank)	1000 Milliliters (1.0 Liter)
Pressure	19 Bars (Italian pump)
Wattage	1470 Watts
Voltage	230 Volts
Operation Mode	Fully Automatic
Coffee Input Type	Coffee Beans
Material	Stainless Steel
Special Features	Adjustable Grind, Touch Display, Thermoblock Heating System, Automatic Descaling Program, Removable Drip Tray, Removable Brewing Group

Warranty and Support

Your Incapto Superautomatic Coffee Machine comes with a**2-year warranty**.
For technical assistance or warranty claims, Incapto provides a Technical Service with over 100 assistance points across the territory. Please refer to your purchase documentation or the official Incapto website for contact details and service center locations.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question