HONWELL H600

HONWELL Wireless LED Picture Light H600 Instruction Manual

Model: H600 | Brand: HONWELL

1. Introduction

Thank you for choosing the HONWELL Wireless LED Picture Light H600. This manual provides detailed instructions for the safe and efficient use of your new picture light. Please read it thoroughly before installation and operation, and retain it for future reference.

Package Contents:

- 1 x HONWELL Wireless LED Picture Light
- 1 x Remote Control (CR2025 button cell battery included)
- 1 x Micro-USB Charging Cable
- 3 x Screws
- 1 x User Manual (this document)

2. Safety Information

- Do not attempt to disassemble or modify the light.
- Keep the device away from water and high humidity.
- Ensure the charging cable is not damaged before use.
- Do not insert screws directly through the artwork or picture frame.
- Verify that the mounting bracket is securely fastened to prevent the light from falling.
- The remote control contains a button cell battery. Keep it out of reach of children.

3. Setup and Installation

The HONWELL Picture Light offers flexible installation options to suit various needs.

Installation Options:

1. **Clip-on Installation:**
   This method is suitable for picture frames with a thickness of 25-35mm. Simply attach the clip-on bracket to the top edge of your frame. Ensure it is firmly secured.

2. **Screw-in Installation:**

   For a more permanent fixture or for mounting directly to a wall above artwork, use the provided screws and anchors. Attach the mounting plate to the desired surface, then secure the light to the plate. Ensure the mounting surface is appropriate for screws.



Figure 1: Installation Options for the HONWELL Picture Light.

Initial Charging:

Before first use, fully charge the picture light. The light is powered by a high-capacity 3.7V 2*2200mAh Li-ion battery. Connect the micro-USB charging cable to the light and to any standard USB charging port (e.g., power bank, laptop, USB wall charger). A full charge takes approximately 5-6 hours. The LED indicator will automatically turn off once charging is complete.



Figure 2: Charging the HONWELL Picture Light. The light head can be detached for convenient charging.

4. Operating Instructions

The HONWELL Picture Light can be operated via its integrated button or the included remote control.

Adjusting Light Direction:

The light features an adjustable design for optimal illumination:

- The light head can be rotated 180° to direct light precisely.
- The flexible gooseneck allows for a 360° adjustment, enabling you to position the light exactly where needed.

Manual Operation (On-Light Button):

Press the button located on the light head to cycle through the lighting modes:

1. Press once for 4300K Natural White light.
2. Press again for 3000K Warm White light.

3. Press a third time for 8000K Cool White light.
4. Press a fourth time to turn the light OFF.



Figure 3: Light Modes and Manual Control.

Remote Control Operation:

The remote control allows for convenient operation from up to 20 feet away. A single remote can control up to 10 HONWELL picture lights.

- **ON/OFF:** Power button to turn the light on or off.
- **Dimmer:**
  - **50%** / **100%:** Directly set brightness to 50% or 100%.
  - **+** / **-:** Adjust brightness incrementally (increase/decrease).
- **Color Temperature:**
  - **Warm White Button:** Activates 3000K Warm White light.

- **Cool White Button:** Activates 8000K Cool White light.
- **Natural White Button:** Activates 4300K Natural White light (often represented by a combined warm/cool icon).

- **Timer Functions:** Set the light to automatically turn off after a specified duration.
  - **15 min:** Auto-off after 15 minutes.
  - **30 min:** Auto-off after 30 minutes.
  - **60 min:** Auto-off after 60 minutes.
  - **120 min:** Auto-off after 120 minutes.



Figure 4: Remote Control Functions.

5. Maintenance

Charging the Battery:

When the light's brightness diminishes, it indicates a low battery. Recharge the light using the provided micro-USB cable

as described in the "Initial Charging" section. A full charge provides illumination for up to 24 hours, though actual runtime may vary based on brightness settings and color temperature used.

Cleaning:

Wipe the light gently with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or electronic components.

Remote Control Battery Replacement:

The remote control uses a CR2025 button cell battery. If the remote's range or responsiveness decreases, replace the battery. Refer to the diagram below for battery replacement steps.



Figure 5: Remote Control Battery Replacement (refer to the bottom right section of the image).

6. Troubleshooting

- **Light does not turn on:**

- Ensure the battery is charged. Connect to a power source and allow it to charge for at least 30 minutes.
- Check if the remote control battery is functional. Replace if necessary.
- Try operating the light using the manual button on the light head.

- **Remote control not working:**
  - Ensure there are no obstructions between the remote and the light.
  - Verify the remote control battery is correctly inserted and has sufficient power. Replace if needed.
  - Ensure you are within the 20-foot operating range.
- **Light flickers or is dim:**
  - The battery level is likely low. Recharge the light fully.

7. Specifications

Feature	Detail
Model Number	H600
Light Source	28 SMD LEDs
Luminous Flux	200 Lumens (±10%)
Wattage	1.5 Watts
Color Temperatures	3000K (Warm White), 4300K (Natural White), 8000K (Cool White)
Battery	3.7V 4400mAh (2*2200mAh) Li-ion
Charging Time	5-6 hours (full charge)
Run Time	Up to 24 hours (depending on brightness/mode)
Control Method	Remote Control, Manual Button
Remote Range	Up to 20 feet
Dimensions (Light Head)	8.4 inches / 21.4 cm (length)
Gooseneck Length	7.1 inches / 18 cm
Product Dimensions (L x W x H)	6 x 22 x 39 cm
Weight	550 grams
Material	Metal, Plastic
Installation Type	Wall Mount, Clip-on



Figure 6: Product Dimensions and Key Specifications.

8. Warranty and Support

Warranty Information:

Specific warranty details for the HONWELL Wireless LED Picture Light H600 are not provided in this manual. Please refer to the product packaging or the retailer's website for warranty terms and conditions.

Customer Support:

For technical assistance, troubleshooting beyond this manual, or inquiries regarding your HONWELL product, please contact the manufacturer or your point of purchase. Contact information can typically be found on the product packaging or the official HONWELL website.

© 2023 HONWELL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question