ONN ONA24HB19T01

ONN ONA24HB19T01 24" Full HD LED Computer Monitor User Manual

Model: ONA24HB19T01 | Brand: ONN

1. Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your ONN ONA24HB19T01 24" Full HD LED Computer Monitor. Designed to maximize your workspace, this slim monitor features clean lines and a sleek V-shape stand, offering a 1920 x 1080 resolution for clear visuals. It includes both an AC adapter and an HDMI cable for versatile connectivity.



Figure 1.1: Front view of the ONN 24" Full HD LED Computer Monitor.

2. Setup Guide

2.1 Unpacking and Assembly

Carefully remove all components from the packaging. Ensure you have the monitor panel, V-shape stand, AC adapter, and HDMI cable. Attach the V-shape stand securely to the monitor panel according to the instructions provided in the quick start guide (not included in this manual).



Figure 2.1: Angled view of the monitor with its V-shaped stand.

2.2 Connecting to a Device

The ONN ONA24HB19T01 monitor offers both HDMI and VGA connectivity options. Choose the appropriate cable for your device (computer, laptop, gaming console, etc.).

- **HDMI Connection:** Connect one end of the provided HDMI cable to the HDMI port on the monitor and the other end to the HDMI output port on your device.
- **VGA Connection:** Connect a VGA cable (not included unless specified) to the VGA port on the monitor and the VGA output port on your device. Secure the screws on the VGA connector if present.



Figure 2.2: Rear view of the monitor showing HDMI, VGA, and power input ports.

2.3 Power Connection

Connect the AC adapter to the DC 12V power input port on the monitor. Plug the other end of the AC adapter into a standard electrical outlet. The power indicator light on the monitor should illuminate.

3. Operating Instructions

3.1 Powering On/Off

Press the power button, usually located on the bottom right bezel or rear of the monitor, to turn the monitor on or off. The power indicator light will change color to indicate its status (e.g., blue for on, amber for standby).

3.2 Input Source Selection

If you have multiple devices connected, use the input source button (often labeled "Source" or with an arrow icon) to cycle through available inputs (HDMI, VGA) until your desired display is shown.

3.3 Display Settings

The monitor features a native resolution of 1920 x 1080 (Full HD) and a refresh rate of 60Hz. For optimal display quality, ensure your connected device's display settings are configured to match these specifications. Access your device's display settings (e.g., Windows Display Settings, macOS System Preferences) to adjust resolution and refresh rate.

3.4 Audio Output

Please note that this monitor does not have built-in speakers. To experience audio, you will need to connect external speakers or headphones to your connected device (computer, laptop, etc.).

4. Maintenance

4.1 Cleaning the Monitor

To clean the monitor screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a non-abrasive screen cleaner. Avoid using alcohol-based cleaners, ammonia, or abrasive materials, as these can damage the screen surface. For the monitor casing, use a soft, dry cloth.

4.2 Storage

When storing the monitor for an extended period, disconnect it from power and all connected devices. Store it in a cool, dry place, ideally in its original packaging to protect it from dust and physical damage.

5. Troubleshooting

If you encounter issues with your ONN monitor, refer to the following common problems and solutions:

- **No Image on Screen:**
  - Ensure the power cable is securely connected to both the monitor and the electrical outlet.
  - Verify that the video cable (HDMI or VGA) is firmly connected to both the monitor and your device.
  - Check if your device (computer) is powered on and not in sleep mode.
  - Press the input source button on the monitor to select the correct input (HDMI or VGA).
- **Image is Blurry or Distorted:**
  - Ensure your device's display resolution is set to 1920 x 1080.

- Check the refresh rate setting on your device; it should be 60Hz.
- If using VGA, ensure the cable is securely fastened.

- **No Audio:**
  - This monitor does not have built-in speakers. Connect external speakers or headphones to your computer or source device.
  - Verify audio settings on your connected device.

- **Power Indicator Light is Off:**
  - Check the power connection to the monitor and the wall outlet.
  - Test the outlet with another device to ensure it is functional.

6. Specifications

Feature	Detail
Brand	ONN
Model Number	ONA24HB19T01
Screen Size	24 Inches
Resolution	1920 x 1080 (Full HD 1080p)
Refresh Rate	60Hz
Aspect Ratio	16:9
Connectivity	1 x HDMI 1.4A, 1 x VGA
Screen Surface Description	Glossy
Product Dimensions	21.1 x 15.6 x 5 inches
Item Weight	7.83 pounds
Date First Available	August 28, 2020

7. Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product packaging or visit the official ONN website. If you require technical assistance or have questions not covered in this manual, please contact ONN customer support through their official channels.
This product is tested and certified to look and work like new. The refurbishing process includes functionality testing, basic cleaning, inspection, and repackaging. The product ships with all relevant accessories, and may arrive in a generic box.

© 2024 ONN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question