Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

REDMOND AF008

REDMOND AF008 14.8QT Air Fryer Oven User Manual

Model: AF008

Introduction

Thank you for purchasing the REDMOND AF008 14.8QT Air Fryer Oven. This appliance is designed to provide a versatile cooking experience, combining the functions of an air fryer, rotisserie, dehydrator, pizza grill, and toaster oven. Please read this manual thoroughly before operation to ensure safe and efficient use of your new appliance. Keep this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- Extreme caution should be exercised when using containers constructed of other than metal or glass.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not cover the drip tray or any part of the oven with metal foil. This will cause overheating of the oven.

Product Overview

The REDMOND AF008 Air Fryer Oven is a multi-functional kitchen appliance designed for various cooking methods. It features a 14.8-quart capacity, a 1700W heating element, and an LED digital touchscreen for easy operation.

Components and Accessories

The appliance comes with several accessories to enhance your cooking experience:

- **Main Unit:** The primary air fryer oven with digital controls.
- **Skewer Rotisserie:** For roasting whole chickens or other large cuts of meat.
- **Roasting Basket:** Ideal for fries, vegetables, and other items that require tumbling for even cooking.
- **Drip Tray:** Collects excess oil and food particles for easier cleaning.
- **Fetch Rack:** Tool for safely removing hot accessories from the oven.
- **Dehydrating Racks (Mesh Racks):** For dehydrating fruits, vegetables, and jerky.
- **Chicken Fork:** Used with the rotisserie skewer to secure poultry.



Image: Overview of the REDMOND Air Fryer Oven and its included accessories, such as the rotisserie basket, chicken fork, drip tray, mesh racks, and fetch rack.



Image: Detailed view of the air fryer oven's design features, including its stainless steel components, internal lighting, non-slip base, integrated wire storage, and double-layered glass door.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials, stickers, and labels from the appliance and its accessories.
2. **Cleaning:** Wipe the exterior of the appliance with a damp cloth. Wash all removable accessories (rotisserie basket, drip tray, racks, etc.) with warm, soapy water. Rinse thoroughly and dry completely before use.
3. **Placement:** Place the air fryer oven on a stable, heat-resistant surface, away from walls and other appliances to allow for proper air circulation. Ensure there is at least 6 inches of space on all sides.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Initial Burn-in (Optional but Recommended):** Before cooking food, run the appliance empty for about 10-15 minutes at 350°F (175°C) to burn off any manufacturing residues. A slight odor or smoke may be present during this process; this is normal. Ensure good ventilation.

Operating Instructions

The REDMOND AF008 features an intuitive LED digital touchscreen for selecting cooking modes, adjusting temperature, and setting time.

Control Panel Overview

The digital touchscreen allows you to easily select from 12 preset cooking options or manually adjust settings.



Image: The digital control panel of the air fryer oven, displaying 12 preset cooking modes for various food types.

Basic Operation

1. **Power On:** Plug in the appliance. The display will light up.
2. **Select Mode:** Use the preset icons on the touchscreen to select your desired cooking mode (e.g., Air Fry, Roast,

Dehydrate). Each preset has a default time and temperature.

3. **Adjust Time/Temperature:** If needed, use the '+' and '-' buttons to adjust the cooking time and temperature. The temperature range is 180°F to 400°F.
4. **Start Cooking:** Press the Start/Pause button to begin the cooking cycle.
5. **Pause/Resume:** You can pause the cooking cycle at any time by pressing the Start/Pause button. Press again to resume.
6. **Internal Light:** Press the light bulb icon to turn the internal light on or off to monitor cooking progress.
7. **Rotisserie Function:** If using the rotisserie, ensure the rotisserie skewer is properly installed. Press the rotisserie icon to activate the rotation.
8. **End of Cycle:** The appliance will beep when the cooking cycle is complete. Carefully remove food using heat-resistant mitts and the fetch rack.

Using the Rotisserie

The rotisserie function is ideal for cooking whole chickens or roasts evenly.

1. Assemble the chicken fork onto the rotisserie skewer, securing your food item.
2. Insert the assembled rotisserie skewer into the designated slots inside the oven. Ensure it is securely seated.
3. Select the appropriate cooking mode (e.g., Chicken, Roast) and adjust time/temperature as needed.
4. Press the rotisserie icon on the control panel to activate rotation.
5. Monitor cooking through the glass door.
6. Once cooking is complete, use the fetch rack to carefully remove the hot rotisserie assembly.

Your browser does not support the video tag.

Video: Demonstration of the REDMOND Air Fryer Oven's rotisserie function, showing a whole chicken being cooked. This video illustrates the process of placing the chicken on the rotisserie spit and the oven's operation.

Dehydration Function

The dehydrate function allows you to make dried fruits, vegetables, and jerky.

1. Prepare your food items by slicing them thinly and evenly.
2. Arrange the food on the dehydrating racks, ensuring not to overlap pieces for optimal air circulation.
3. Insert the racks into the oven.
4. Select the "Dehydrate" preset or manually set a low temperature (e.g., 130°F - 160°F) for an extended period.
5. Check food periodically until desired dryness is achieved.



Image: Dehydrated lemon and apple slices arranged on mesh racks within the air fryer oven, demonstrating its dehydration capability.

Care and Maintenance

Proper cleaning and maintenance will extend the life of your REDMOND Air Fryer Oven.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Cleaning the Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive sponge. Avoid using harsh chemicals or abrasive cleaners.
3. **Cleaning Accessories:** All removable accessories (rotisserie basket, drip tray, racks, chicken fork) are dishwasher safe. Alternatively, wash them by hand with warm, soapy water and a non-abrasive sponge. Rinse and dry thoroughly.
4. **Cleaning the Exterior:** Wipe the exterior with a damp cloth. Do not immerse the main unit in water or any other liquid.

5. **Drip Tray:** Empty and clean the drip tray after each use to prevent grease buildup and smoke.
6. **Storage:** Ensure the appliance is clean and dry before storing. Store it in a cool, dry place.

Troubleshooting

If you encounter issues with your air fryer oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the issue persists, contact customer support.
Food is not cooked evenly.	Overcrowding the basket/racks; incorrect temperature/time; food not rotated.	Do not overcrowd the oven; cook in smaller batches if necessary. Adjust temperature and time according to recipe. For best results, shake or turn food halfway through cooking. Use the rotisserie function for whole items.
White smoke coming from the appliance.	Grease buildup from previous use; fatty foods cooking.	Clean the drip tray and interior thoroughly after each use. For very fatty foods, you may place a small amount of water in the drip tray to reduce smoke.
Appliance emits a burning smell.	Food residue burning; new appliance smell.	Ensure the oven and accessories are clean. If it's the first few uses, a slight smell is normal. If the smell persists or is strong, unplug and contact support.
Rotisserie function not working.	Rotisserie skewer not properly installed; function not activated.	Ensure the rotisserie skewer is correctly inserted into the drive and support slots. Press the rotisserie icon on the control panel to activate.

Specifications

Feature	Detail
Brand	REDMOND
Model Name	AF008
Capacity	14.8 Quarts
Color	Black
Material	Plastic (Exterior), Stainless Steel (Interior elements)
Output Wattage	1700 Watts

Feature	Detail
Voltage	120 Volts
Control Method	Touch (LED Digital Touchscreen)
Max Temperature Setting	400 °F
Air Frying Technology	Rapid Air Circulation
Number of Items	1 (Main Unit)
Accessories Included	Skewer Rotisserie, Roasting Basket, Drip Tray, Fetch Rack, Dehydrating Racks, Chicken Fork



Image: Dimensional drawing of the REDMOND Air Fryer Oven, showing its external and internal measurements.

Warranty and Support

REDMOND products are designed with quality and reliability in mind. For warranty information, please refer to the warranty card included with your purchase or visit the official REDMOND website. If you have any questions, require technical assistance, or need to report an issue, please contact REDMOND customer support.

Customer Support:

- Refer to your product packaging or the official REDMOND website for the most current contact information.
- When contacting support, please have your model number (AF008) and purchase date available.

© 2023 REDMOND. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08GYQ9K41

More documents and user manuals: **https://manuals.plus/**