**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**proscenic S1**

# Proscenic S1 3-in-1 Handheld Vacuum User Manual

## 1. Introduction

Thank you for choosing the Proscenic S1 3-in-1 Handheld Vacuum. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new device. Please read this manual thoroughly before first use and retain it for future reference.

The Proscenic S1 is a lightweight, cordless handheld vacuum designed for versatile cleaning in both home and car environments. It features powerful suction, adjustable modes, and multiple charging options to ensure a convenient cleaning experience.

## 2. Product Overview

Familiarize yourself with the components of your Proscenic S1 handheld vacuum.




Image: The Proscenic S1 handheld vacuum, its charging base, and various cleaning attachments.

### Package Contents:

- Proscenic S1 Handheld Vacuum Unit
- Charging Dock
- Crevice Nozzle
- Brush Nozzle
- Type-C Charging Cable
- HEPA Filter (pre-installed)

## 3. Setup

Before first use, ensure all components are present and the vacuum is fully charged.

1. **Unpack:** Carefully remove all items from the packaging.
2. **Assemble:** Attach the desired nozzle (crevice or brush) to the vacuum's suction port. For storage, place the vacuum and accessories onto the charging dock.
3. **Initial Charge:** Fully charge the vacuum before its first use. Refer to the 'Charging' section for detailed instructions.

## 4. Charging

The Proscenic S1 offers flexible charging options to suit your needs.




Image: The Proscenic S1 vacuum being charged via its dock and directly via a Type-C cable in a car.

### Charging Methods:

- **Charging Dock:** Place the vacuum unit onto the charging dock. Connect the charging dock to a power outlet using the provided adapter. The indicator light on the vacuum will show charging status.
- **Type-C Direct Charging:** For convenience, especially in a car, you can directly connect a Type-C charging

cable to the vacuum's charging port. Ensure the power source meets the vacuum's charging specifications.

A full charge provides up to 30 minutes of low-grade running time, ensuring sufficient power for most cleaning tasks.

## 5. Operation

Operating your Proscenic S1 vacuum is straightforward.




Image: The Proscenic S1 vacuum cleaning coffee grounds, illustrating its two suction power levels: 8KPa and 17KPa.

### Power On/Off and Suction Modes:

1. **Power On:** Press the power button once to turn on the vacuum in the low suction mode (8KPa).
2. **Adjust Suction:** Press the power button a second time to switch to high suction mode (17KPa).
3. **Power Off:** Press the power button a third time to turn off the vacuum.

### Using Attachments:

The vacuum comes with three different brush heads to handle various cleaning scenarios:

- **Crevice Nozzle:** Ideal for reaching tight spaces, corners, and gaps in furniture or car interiors.
- **Brush Nozzle:** Suitable for cleaning delicate surfaces, upholstery, and dislodging stubborn dirt from carpets or vents.




Image: The Proscenic S1 vacuum in use, demonstrating its versatility for cleaning car seats, dashboards, and household surfaces.

## 6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Proscenic S1 vacuum.




Image: Exploded view of the Proscenic S1's washable filter and dustbin, highlighting their cleanability.

## Emptying the Dustbin:

The 120ml large dustbin should be emptied regularly to maintain suction power. To empty:

1. Ensure the vacuum is turned off.
2. Locate the dustbin release button or twist mechanism.
3. Detach the dustbin and empty its contents into a waste bin.
4. Reattach the dustbin securely until it clicks into place.

## Cleaning the HEPA Filter:

The built-in steel filter with H12 high-efficiency HEPA helps filter air and should be cleaned periodically.




Image: A visual representation of the Proscenic S1's filtration process, showing how dust is absorbed and locked by the HEPA filter.

1. After emptying the dustbin, twist or pull to remove the HEPA filter assembly.
2. Tap the filter gently over a waste bin to remove loose dust.
3. If heavily soiled, rinse the filter under running water. Ensure it is completely dry before reinserting it into the vacuum. Do not use a brush or abrasive materials on the filter.
4. Reinsert the dry filter assembly and secure the dustbin.

## 7. Troubleshooting

If you encounter issues with your Proscenic S1 vacuum, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
| --- | --- | --- |

| Problem | Possible Cause | Solution |
|---|---|---|
| Vacuum does not turn on | Battery is depleted | Charge the vacuum fully. |
| Low suction power | Dustbin is full; Filter is clogged; Suction inlet is blocked | Empty the dustbin. Clean the HEPA filter. Check and clear any blockages in the suction inlet or nozzles. |
| Battery not holding charge / Short run time | Filter is severely clogged; Battery degradation | Thoroughly clean the HEPA filter and ensure it is completely dry. If the issue persists after cleaning, contact customer support for battery assessment. |
| Unusual noise during operation | Blockage in the vacuum path; Loose component | Turn off the vacuum and check for any foreign objects in the nozzles, dustbin, or main suction path. Ensure all components are securely attached. |

If the problem persists after attempting these solutions, please contact customer support.

## 8. Specifications

Detailed technical specifications for the Proscenic S1 Handheld Vacuum.

| Feature | Specification |
|---|---|
| Brand | proscenic |
| Model | S1 |
| Item Weight | 635 g (1.39 lbs) |
| Form Factor | Handheld |
| Suction Power | 8KPa (Low), 17KPa (High) |
| Dustbin Capacity | 0.55 Liters (120ml) |
| Filter Type | H12 HEPA Filter, Cartridge |
| Power Source | Battery Powered |
| Voltage | 11.1 Volts (AC) |
| Cordless | Yes |
| Special Features | Portable |
| Included Components | Brush, HEPA Filter |

| Feature | Specification |
| --- | --- |
| First Available Date | 1 September 2020 |

## 9. Warranty and Support

Proscenic is committed to providing high-quality products and customer satisfaction. For warranty information, product support, or any inquiries not covered in this manual, please contact our customer service team.

### Customer Support:

- **Toll-Free Call (North & South America):** +1(833) 313 1310
- **Hours:** Monday - Friday, 9am - 6pm ET
- Please have your product model (S1) and purchase details ready when contacting support.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B08H4YJBS7**

More documents and user manuals: **https://manuals.plus/**