Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ledwood LD-M1011-TWS-BLK

LEDWOOD InEar M1011 Bluetooth Earphones

Model: LD-M1011-TWS-BLK

Introduction

Thank you for choosing the LEDWOOD InEar M1011 Bluetooth Earphones. This manual provides essential information for setting up, operating, and maintaining your new wireless earphones. Please read these instructions carefully before use to ensure optimal performance and longevity of your device. Keep this manual for future reference.

Product Overview

The LEDWOOD InEar M1011 earphones are designed for wireless audio playback and hands-free calling, featuring Bluetooth 5.0 connectivity and intuitive touch controls. The compact charging case ensures your earphones are always ready for use.



Image: LEDWOOD InEar M1011 Bluetooth Earphones and Charging Case. This image displays the black earphones alongside their matching charging case, highlighting the sleek design.

Key Features:

- **Bluetooth 5.0:** For stable and efficient wireless connection.
- **Up to 3 Hours Playtime:** Enjoy your audio for extended periods.
- **1 Hour Charge Time:** Quick charging for minimal downtime.
- **10 Meter Range:** Freedom of movement without losing connection.
- **LED Charge Indicator:** Provides clear status of battery levels.
- **Touch Control:** Manage music and calls with simple taps.
- **Active Noise Suppression:** For an immersive listening experience.
- **Waterproof Design:** Suitable for various activities.

Setup

1. Charging the Earphones and Case

Before first use, fully charge the earphones and the charging case. The charging case contains an internal battery that charges the earphones when they are placed inside.

1. Place the earphones into their respective slots in the charging case.
2. Connect the provided USB cable to the charging port on the case and to a compatible USB power source (e.g., computer, wall adapter).
3. The LED indicator on the charging case will illuminate to show charging status. A full charge typically takes about 1 hour.
4. Once fully charged, disconnect the charging cable.



Image: LEDWOOD InEar M1011 Charging Case. This image shows the black charging case with its LED indicators, which light up during charging.

2. Pairing with a Bluetooth Device

To connect your earphones to your smartphone, tablet, or other Bluetooth-enabled device:

1. Ensure the earphones are charged and placed in the charging case.
2. Open the charging case. The earphones will automatically enter pairing mode, and their LED indicators will flash.
3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. You should see "LEDWOOD M1011" or a similar name appear in the list.
5. Select the earphones to connect. Once paired, the earphone LEDs will stop flashing, and your device will confirm the connection.
6. The earphones will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

Operating Instructions

The LEDWOOD InEar M1011 earphones feature touch controls for easy management of audio playback and calls.



Image: Front view of LEDWOOD InEar M1011 Bluetooth Earphones. This image shows the front of both black earphones, highlighting the speaker grilles and touch control areas.

Touch Controls:

- **Play/Pause:** Single tap on either earphone.
- **Next Track:** Double tap on the right earphone.
- **Previous Track:** Double tap on the left earphone.
- **Answer/End Call:** Single tap on either earphone during an incoming call.
- **Reject Call:** Press and hold either earphone for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earphone (e.g., Siri, Google Assistant).
- **Power On:** Remove from charging case.
- **Power Off:** Place back into charging case or press and hold either earphone for 5 seconds.

Maintenance

Proper care and maintenance will extend the life of your LEDWOOD InEar M1011 earphones.

Cleaning:

- Regularly clean the earphones and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Gently remove any earwax or debris from the ear tips and speaker grilles using a small, soft brush or cotton swab.

Storage:

- When not in use, always store the earphones in their charging case to protect them from dust, dirt, and damage.
- Store the device in a cool, dry place, away from extreme temperatures and direct sunlight.

Troubleshooting

If you encounter issues with your earphones, refer to the following common solutions:

- **Earphones not pairing:**
  - Ensure both earphones are charged.
  - Turn off Bluetooth on your device, then turn it back on.
  - Forget the earphones from your device's Bluetooth list and attempt to pair again.
  - Restart your Bluetooth device.
- **No sound from one earphone:**
  - Ensure both earphones are charged.
  - Place both earphones back into the charging case, close the lid, wait a few seconds, then take them out again.
  - Check your device's audio balance settings.
- **Earphones not charging:**
  - Ensure the charging cable is securely connected to both the case and the power source.
  - Verify the power source is functional.
  - Clean the charging contacts on both the earphones and inside the case with a dry cotton swab.
- **Poor sound quality or intermittent connection:**
  - Ensure you are within the 10-meter Bluetooth range of your device.
  - Avoid obstacles between the earphones and your device.
  - Check for interference from other wireless devices.

Specifications

Feature	Specification
Brand	Ledwood

Model Name	Hubble (LD-M1011-TWS-BLK)
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	10 Meters
Ear Placement	In-Ear
Form Factor	In-Ear
Noise Control	Active Noise Suppression
Headphone Jack (Charging)	USB
Components Included	Cable
Charge Time	1 Hour
Average Battery Life	3 Hours
Control Type	Touch Control
Water Resistance Level	Waterproof
Item Weight	39 Grams
Compatible Devices	Mobile phones, tablets, laptops, game consoles

Safety Information

Please observe the following safety guidelines to prevent damage to your earphones or personal injury:

- Do not expose the earphones or charging case to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble, repair, or modify the earphones or charging case. This will void the warranty and may cause damage.
- Listen at moderate volume levels to prevent hearing damage. Prolonged exposure to loud sounds can cause irreversible hearing loss.
- Keep out of reach of children and pets to prevent accidental ingestion of small parts.
- Dispose of the product responsibly according to local regulations for electronic waste.

Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact your retailer. You may also visit the official Ledwood website for further assistance.

© 2023 Ledwood. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08H5DJ3L4

More documents and user manuals: **https://manuals.plus/**