Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

H.Koenig KM120

H.Koenig KM120 5L Stand Mixer User Manual

1. Introduction

This manual provides essential instructions for the safe and efficient use of your H.Koenig KM120 5L Stand Mixer. Please read all instructions carefully before operating the appliance and retain this manual for future reference.

2. Safety Instructions

To prevent injury or damage, always observe basic safety precautions when using electrical appliances:

- Read all instructions thoroughly before initial use.
- Ensure the power supply voltage matches the rating label on the appliance.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands, hair, clothing, and utensils away from moving parts during operation to prevent injury.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments and accessories recommended or sold by the manufacturer.
- Close supervision is necessary when any appliance is used by or near children.
- Place the appliance on a stable, flat, and dry surface.

3. Product Overview

The H.Koenig KM120 is a versatile stand mixer designed for various kitchen tasks, featuring a powerful 800W motor and a 5-liter stainless steel bowl.

Key Features:

- **Generous 5L Capacity:** The large stainless steel bowl allows for preparing substantial quantities of dough, batters, and other culinary preparations.
- **Precise Control:** Features 8 speed settings, a digital display, and an integrated timer for accurate preparation control.

- **Tilt-Head Design:** Facilitates easy attachment and removal of the bowl and accessories.
- **Complete Accessories:** Includes a whisk, beater, dough hook, and splash guard for versatile use.

Components:

1. Motor Unit with Tilt-Head
2. 5L Stainless Steel Mixing Bowl
3. Whisk Attachment
4. Beater Attachment
5. Dough Hook Attachment
6. Splash Guard
7. Digital Display and Control Dial



The H.Koenig KM120 Stand Mixer with the whisk attachment in place, ready for use.



The stand mixer equipped with the dough hook, suitable for kneading heavy doughs.



The stand mixer featuring the beater attachment, ideal for mixing batters and frostings.



An exploded view of the H.Koenig KM120 Stand Mixer showing all included accessories.



A close-up of the digital display and control dial, showing the timer function.

4. Setup

Follow these steps to set up your stand mixer for first use:

1. **Unpack:** Carefully remove all components from the packaging. Dispose of packaging materials responsibly.
2. **Clean:** Before first use, wash the mixing bowl, whisk, beater, dough hook, and splash guard in warm soapy water. Rinse thoroughly and dry. Wipe the motor unit with a damp cloth.
3. **Position:** Place the motor unit on a clean, dry, and stable surface. Ensure there is enough space around the mixer for operation.
4. **Attach Bowl:** Place the stainless steel mixing bowl onto the base and turn it clockwise until it locks securely into position.
5. **Install Attachment:** Press the tilt-head release button and lift the motor head. Select the desired attachment (whisk, beater, or dough hook) and push it upwards onto the attachment shaft, then turn it counter-clockwise until it locks.
6. **Lower Head:** Gently lower the motor head until it clicks into place. Ensure it is fully locked before operation.
7. **Attach Splash Guard (Optional):** If desired, place the splash guard over the mixing bowl before lowering the head.

5. Operating Instructions

Using your H.Koenig KM120 Stand Mixer is straightforward:

1. **Add Ingredients:** Place your ingredients into the mixing bowl.
2. **Select Attachment:** Ensure the correct attachment is installed for your recipe (whisk for whipping, beater for mixing, dough hook for kneading).
3. **Plug In:** Connect the power cord to a suitable electrical outlet. The digital display will illuminate.
4. **Set Speed:** Turn the control dial to select one of the 8 available speeds. Start with a lower speed and gradually increase as needed to prevent splashing.
5. **Set Timer (Optional):** Use the timer function on the digital display to set a specific mixing duration. The mixer will automatically stop when the timer counts down to zero.
6. **Monitor Mixing:** Observe the mixing process. If necessary, stop the mixer, lift the head, and scrape down the sides of the bowl with a spatula.
7. **Stop Operation:** Turn the control dial to the '0' position to stop the mixer. Unplug the appliance from the power outlet.
8. **Remove Bowl and Attachment:** Press the tilt-head release button, lift the motor head, and remove the attachment by turning it clockwise and pulling it down. Then, unlock and remove the mixing bowl.

Note: For heavy doughs, avoid continuous operation for more than 10 minutes to prevent motor overheating. Allow the mixer to rest for at least 30 minutes between uses for heavy loads.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your mixer:

- **Always Unplug:** Before cleaning, always ensure the mixer is unplugged from the power outlet.
- **Motor Unit:** Wipe the exterior of the motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Mixing Bowl:** The stainless steel mixing bowl is dishwasher-safe. Alternatively, wash it by hand with warm soapy water, rinse, and dry thoroughly.
- **Attachments (Whisk, Beater, Dough Hook):** These accessories are dishwasher-safe. For hand washing, use

warm soapy water, rinse well, and dry immediately to prevent water spots.

- **Splash Guard:** The splash guard can be washed by hand or in the dishwasher.
- **Storage:** Store the mixer and its accessories in a clean, dry place.

7. Troubleshooting

If you encounter issues with your H.Koenig KM120, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not start	Not plugged in; power outage; motor head not locked.	Ensure the mixer is securely plugged in. Check power supply. Make sure the motor head is fully lowered and locked.
Attachments do not reach ingredients at the bottom of the bowl	Small quantity of ingredients; attachment not properly installed.	Increase ingredient quantity if possible. Ensure the attachment is fully pushed onto the shaft and locked.
Mixer stops during operation	Overload protection activated; motor overheating.	Reduce the load (e.g., remove some dough). Turn off the mixer and let it cool down for at least 30 minutes before restarting.
Excessive noise or vibration	Unstable surface; heavy load; attachment not properly installed.	Place the mixer on a stable, flat surface. Reduce the load. Re-install the attachment ensuring it is locked.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

Feature	Specification
Brand	H.Koenig
Model	KM120
Color	Black
Power	800W
Bowl Capacity	5 Liters
Number of Speeds	8
Special Feature	Tilt-head design
Item Weight	8.2 Kilograms
Product Dimensions (D x W x H)	22cm x 39cm x 34cm

Feature	Specification
Controls Type	Digital control panel

9. Warranty and Support

Your H.Koenig KM120 Stand Mixer comes with a **2-year extended warranty**. This warranty covers manufacturing defects and ensures peace of mind for prolonged and reliable use.

For warranty claims, technical assistance, or any questions regarding your product, please refer to the contact information provided with your purchase documentation or visit the official H.Koenig website for support details. An after-sales laboratory is available in Italy to assist with service needs.

© 2024 H.Koenig. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08H5Q3P24

More documents and user manuals: **https://manuals.plus/**