Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bosch BCHF2MX20

BOSCH BCHF2MX20 Cordless Readyy'y 2in1 Vacuum Cleaner Instruction Manual

Model: BCHF2MX20

1. Introduction

Thank you for choosing the BOSCH BCHF2MX20 Cordless Readyy'y 2in1 Vacuum Cleaner. This appliance is designed for efficient cleaning of various surfaces in your home. This manual provides essential information for the safe operation, proper maintenance, and effective troubleshooting of your vacuum cleaner. Please read these instructions carefully before first use and keep them for future reference.

2. Safety Instructions

- Always ensure the vacuum cleaner is switched off before cleaning or performing maintenance.
- Do not use the appliance to vacuum water or other liquids, hot ashes, or sharp objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only the original charger supplied with the appliance.
- Do not operate the vacuum cleaner if it is damaged or malfunctioning. Contact customer service for repairs.
- This appliance is intended for domestic use only.
- Children should be supervised to ensure that they do not play with the appliance.

3. Package Contents

Please check that all items are present and in good condition:

- BOSCH BCHF2MX20 Cordless Readyy'y 2in1 Vacuum Cleaner (main unit)
- Integrated Handheld Vacuum
- Floor Nozzle with Electric Rotary Brush
- Charging Cable/Adapter
- User Manual (this document)

4. Product Overview

The BOSCH BCHF2MX20 is a versatile 2-in-1 vacuum cleaner, functioning as both a stick vacuum for floors and a

detachable handheld unit for smaller tasks. Key components include:

- **Main Unit:** Houses the motor, dust bin, and controls.
- **Handheld Unit:** Detachable for quick clean-ups.
- **Floor Nozzle:** Equipped with an electric rotary brush for effective cleaning on various floor types.
- **Dust Bin:** Collects dirt and debris.
- **Filter System:** Cyclonic technology with a washable filter.





Figure 1: The BOSCH BCHF2MX20 Cordless Readyy'y 2in1 Vacuum Cleaner in its upright stick configuration. This image displays the full unit, highlighting its sleek design and integrated handheld component.

5. Setup and Assembly

Your vacuum cleaner comes partially assembled. Follow these steps to prepare it for use:

1. **Attach the Handle:** Insert the handle into the main body of the vacuum cleaner until it clicks securely into place.
2. **Attach the Floor Nozzle:** Connect the floor nozzle to the bottom of the main unit. Ensure it is firmly attached.
3. **Handheld Unit:** The handheld unit is integrated into the main body. To detach, press the release button and pull the handheld unit upwards. To reattach, slide it back into the main unit until it clicks.





Figure 2: Illustration of the handheld unit being detached from the main stick vacuum body. This demonstrates the 2-in-1 functionality, allowing for versatile cleaning.





Figure 3: An overhead view showing the main stick vacuum body alongside the detached handheld unit. This image provides a clear perspective of the separate components.

6. Charging the Battery

The BOSCH BCHF2MX20 is powered by a Lithium-ion battery. For optimal performance, fully charge the battery before first use.

1. Connect the charging adapter to the charging port on the vacuum cleaner.
2. Plug the adapter into a suitable wall outlet.
3. The charging indicator light will illuminate, indicating that the battery is charging.
4. Once fully charged, the indicator light may change color or turn off (refer to the specific indicator behavior in your product's quick start guide). A full charge provides approximately 44 minutes of autonomy.
5. Disconnect the charger once charging is complete.

7. Operating the Vacuum Cleaner

7.1. Stick Vacuum Mode

1. Ensure the handheld unit is securely attached to the main body.
2. Press the power button to turn on the vacuum cleaner.
3. Select the desired speed setting (the appliance has 2 speeds) using the speed selector switch. Use a lower speed for lighter debris and longer battery life, and a higher speed for stubborn dirt.
4. Guide the vacuum cleaner over the floor surface. The electric rotary brush is effective on hard floors.
5. When finished, press the power button to turn off the appliance.

7.2. Handheld Vacuum Mode

1. Detach the handheld unit from the main stick body by pressing the release button and pulling it out.
2. Press the power button on the handheld unit to turn it on.
3. Use the handheld unit for cleaning furniture, car interiors, stairs, or other hard-to-reach areas.
4. When finished, press the power button to turn off the handheld unit.
5. Reattach the handheld unit to the main body for storage or to use as a stick vacuum.





Figure 4: A hand operating the detached handheld vacuum unit to clean crumbs from a surface. This illustrates the practical application of the handheld mode for targeted cleaning tasks.

8. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

8.1. Emptying the Dust Bin

1. Ensure the vacuum cleaner is switched off.
2. Detach the handheld unit.
3. Locate the dust bin release button and press it to open the bin.
4. Empty the contents of the 400 ml dust bin into a waste receptacle.
5. Close the dust bin securely.

8.2. Cleaning the Filter

The cyclonic filter is washable and should be cleaned regularly to maintain suction power.

1. With the dust bin open, carefully remove the filter assembly.
2. Tap the filter gently to remove loose dust.
3. Rinse the filter under cold running water until the water runs clear. Do not use detergents.
4. Allow the filter to air dry completely for at least 24 hours before reinserting it. Do not use a dryer or direct heat.
5. Reassemble the filter and dust bin, then reattach to the handheld unit.

8.3. Cleaning the Rotary Brush

1. Ensure the vacuum cleaner is switched off and disconnected from the charger.
2. Turn the floor nozzle upside down.
3. Use scissors or a brush to remove any hair, threads, or debris tangled around the rotary brush.
4. Ensure the brush can rotate freely after cleaning.

9. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Battery is discharged.	Charge the battery fully.
Low suction power.	Dust bin is full. Filter is clogged. Obstruction in nozzle or hose.	Empty the dust bin. Clean or wash the filter. Check for and remove any blockages.
Rotary brush not spinning.	Hair or debris tangled in brush.	Clean the rotary brush as described in Section 8.3.
Charging indicator not lighting up.	Charger not properly connected. Power outlet not working.	Ensure charger is securely plugged into both the vacuum and the wall. Test the outlet with another device.

10. Specifications

Brand	Bosch
Model Number	BCHF2MX20
Type	Cordless 2in1 Stick and Handheld Vacuum
Power	120 Watts

Voltage	18 Volts
Battery Type	Lithium-ion
Autonomy	Up to 44 minutes
Number of Speeds	2
Dust Bin Capacity	400 ml
Filter Type	Cyclonic, Washable
Noise Level	79 Decibels
Dimensions (L x W x H)	16.5 x 26.5 x 116 cm
Weight	2.5 Kilograms
Recommended Surface	Hard floor

11. Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Bosch website. If you require technical support, spare parts, or service, please contact Bosch customer service in your region. Keep your proof of purchase for warranty claims.
You can find more information and contact details on the official Bosch website:www.bosch-home.com

© 2023 Bosch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HD1YR3P

More documents and user manuals: **https://manuals.plus/**