Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit NB887UD

NB887UD NB887 Replacement Remote Control User Manual

Your guide to setting up and operating your new replacement remote control.

1. Introduction

This manual provides detailed instructions for the use and maintenance of your new NB887UD NB887 Replacement Remote Control. Designed for seamless compatibility, this remote offers a direct replacement solution for various Magnavox DVD VCR Combo Player models, ensuring immediate functionality without complex setup procedures. Compatible Magnavox DVD VCR Combo Player models include: **ZV427MG9A, RZV427MG9, ZV427MG9, RZV427MG9A, NB820UD, NB820**.

2. Setup

2.1 Battery Installation

The NB887UD remote control requires two (2) AA size alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2.1: Angled view of the NB887UD remote control. The battery compartment is located on the rear side.

2.2 Initial Use

Once batteries are correctly installed, the remote control is ready for immediate use.**No programming or pairing is required.** Simply point the remote control towards your Magnavox DVD VCR Combo Player and begin operating.

3. Operating Instructions

The NB887UD remote control provides full functionality for your compatible Magnavox DVD VCR Combo Player. Below is a guide to the primary buttons and their functions.


STANDBY-ON
SOURCE
OPEN/
CLOSE
.@/:
ABC
DEF
1
2
3
+
TRACKING
GHI
JKL
MNO
4
5
6
−
PQRS
TUV
WXYZ
HDMI
7
8
9
SPACE
CLEAR
AUDIO
0
DISPLAY
TIMER
DISC MENU
TITLE
OK
SETUP
RETURN
VCR
DVD
CM SKIP
RAPID PLAY
SEARCH
REC MODE
D.DUBBING
TIMER SET
REC
NB887

Figure 3.1: Front view of the NB887UD remote control with button layout.

3.1 Button Functions Overview

Button Name	Function
STANDBY-ON	Powers the unit On or Off (Standby mode).
SOURCE	Selects the input source (e.g., TV, DVD, VCR).
OPEN/CLOSE	Opens or closes the DVD disc tray.
0-9 (Number Buttons)	Direct selection of tracks, chapters, or channels.
ABC, DEF, GHI, JKL, MNO, PQRS, TUV, WXYZ	Used for text input or specific functions as indicated by the player.
SPACE	Inserts a space during text input.
CLEAR	Clears current selection or input.
AUDIO	Changes audio tracks or modes.
TITLE	Accesses the DVD title menu.
DISPLAY	Shows on-screen display information.
DISC MENU	Accesses the DVD disc menu.
Navigation (▲, ▼, ◄, ►)	Navigates through menus and options.
OK	Confirms a selection.
SETUP	Accesses the system setup menu.
RETURN	Returns to the previous menu or screen.
VCR	Switches the unit to VCR mode.
DVD	Switches the unit to DVD mode.
Playback Controls (◀◀, ▶, ▶▶, ■, ▮▮, ◀, ▶)	Rewind, Play, Fast Forward, Stop, Pause, Skip Back, Skip Forward.
CM SKIP	Skips forward by a set commercial length.
RAPID PLAY	Initiates rapid playback.
SEARCH	Activates search function.
REC MODE	Selects recording quality mode.
D.DUBBING	Initiates direct dubbing (copying) from DVD to VCR or vice versa.
TIMER SET	Sets recording timers.
REC	Starts recording.

Button Name	Function
TRACKING (+/-)	Adjusts VCR tracking for optimal picture quality.
HDMI	Selects HDMI input (if supported by the player).

4. Maintenance

4.1 Cleaning the Remote Control

To maintain the appearance and functionality of your remote control, wipe it regularly with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or it ceases to function. Always replace both batteries at the same time with new AA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

5. Troubleshooting

Common Issues and Solutions

- **Remote Control Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AA alkaline batteries.
  - Check for any obstructions between the remote control and the Magnavox player's infrared sensor.
  - Ensure you are within the effective operating range and line of sight of the player.
- **Specific Buttons Not Working:**
  - Clean the remote control surface, especially around the non-working buttons, to remove any dirt or debris.
  - Verify that the remote control is in the correct mode (e.g., DVD or VCR mode) for the function you are trying to perform.

6. Specifications

Feature	Detail
Model	NB887UD / NB887
Compatibility	Magnavox DVD VCR Combo Players (ZV427MG9A, RZV427MG9, ZV427MG9, RZV427MG9A, NB820UD, NB820)
Power Source	2 x AA Alkaline Batteries (not included)
Dimensions	8 x 2 x 0.6 inches (approximate)
Item Weight	2.82 ounces (without batteries)
Color	Black
Special Feature	Pre-Programmed (No setup required)

Feature	Detail

7. Warranty and Support

This replacement remote control is designed for reliable performance. While specific warranty details are not provided in this manual, for any questions, concerns, or support needs regarding your NB887UD NB887 Replacement Remote Control, please do not hesitate to contact the manufacturer, ZdalaMit, or your point of purchase.
Your satisfaction is important, and assistance is available for any operational issues or inquiries.

© 2024 ZdalaMit. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HMJH41N

More documents and user manuals: **https://manuals.plus/**