ZdalaMit AKB75595401

ZdalaMit AKB75595401 AKB75515305 Replacement Remote Control User Manual

For LG Soundbar Models: SK5R, SK5Y, SKM5Y, SPK5B-W

1. Overview

This manual provides instructions for the ZdalaMit AKB75595401 AKB75515305 replacement remote control. This remote is designed to function as a direct replacement for the original remote controls of specific LG Soundbar models, ensuring seamless operation without the need for complex programming.

Compatible LG Soundbar Models:

- SK5R
- SK5Y
- SKM5Y
- SPK5B-W



Image 1.1: Front view of the ZdalaMit AKB75595401 AKB75515305 replacement remote control. This image displays the full layout of the remote, including power, volume, mute, playback, and sound mode buttons.

2. Setup

The ZdalaMit AKB75595401 AKB75515305 replacement remote control requires no programming or pairing. Simply install the batteries, and it will be ready for immediate use with your compatible LG Soundbar.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: Batteries are not included with the remote control. Always use new AAA alkaline batteries for optimal performance.

3. Operating Instructions

Once batteries are installed, the remote control is ready to operate your LG Soundbar. Point the remote directly at the soundbar's sensor for best results.



Image 3.1: Detailed view of the remote control buttons. This image highlights the various functions available on the remote for controlling your LG Soundbar.

3.1 Button Functions

Button	Function
Power (Red Circle)	Turns the soundbar On or Off.
VOL + / -	Increases or decreases the main volume level.
Mute (Speaker with X)	Mutes or unmutes the sound.
F (Function)	Cycles through input sources (e.g., Optical, Bluetooth, HDMI).
Previous Track (Double Left Arrow)	Skips to the beginning of the current track or the previous track.
Play/Pause (Vertical Bars & Triangle)	Plays or pauses audio playback.
Next Track (Double Right Arrow)	Skips to the next track.
ASC (Adaptive Sound Control)	Activates or deactivates Adaptive Sound Control mode.
DTS V:X	Activates or deactivates DTS Virtual:X sound mode.
BASS BLAST	Enhances bass output.
REAR + / -	Adjusts the volume level of the rear speakers (if connected).
WOOFER + / -	Adjusts the volume level of the subwoofer.
AUTO POWER ON	Enables or disables the Auto Power On feature.
AUTO POWER OFF	Enables or disables the Auto Power Off feature.

4. Maintenance

4.1 Cleaning the Remote

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.

Dispose of used batteries according to local regulations.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with new 1.5V AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the soundbar's sensor.
  - Make sure you are within the effective range of the soundbar.
- **Specific buttons not working:**
  - Clean the remote control surface and buttons to ensure no debris is interfering with button presses.
  - If only certain buttons are unresponsive, it might indicate a fault with the remote.

If the issue persists after trying these steps, please refer to the Warranty and Support section.

6. Specifications

Feature	Detail
Model Numbers	AKB75595401, AKB75515305
Compatible Soundbar Models	LG SK5R, SK5Y, SKM5Y, SPK5B-W
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	4.5 x 1.5 x 0.5 inches (approximately)
Item Weight	1.5 ounces (approximately)
Color	Black
Special Feature	Ergonomic design

7. Warranty and Support

For any questions, concerns, or support regarding your ZdalaMit replacement remote control, please contact the seller directly through your purchase platform. Please have your order details available when contacting support.

Specific warranty information may vary by retailer and region. Please refer to your purchase documentation for details on applicable warranty coverage.

© 2026 ZdalaMit. All rights reserved.