Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iClever TM231G

iClever Ergonomic Vertical Wireless Mouse (Model TM231G) User Manual

Model: TM231G

1. Introduction

Thank you for choosing the iClever Ergonomic Vertical Wireless Mouse. This manual provides essential information for setting up, operating, and maintaining your mouse to ensure optimal performance and comfort. This mouse is designed to promote a natural 'handshake' wrist and arm position, reducing strain during extended use.

Please read this manual thoroughly before using the product and retain it for future reference.

2. Package Contents

- 1x iClever Wireless Vertical Ergonomic Optical Mouse
- 1x 2.4G USB Receiver
- 1x User Manual
- 1x Charging Cable (not explicitly listed but implied by 'Chargable')

3. Product Overview

Familiarize yourself with the key components of your iClever Ergonomic Vertical Wireless Mouse.



Image: Bottom view of the mouse, highlighting the Power Switch, Charging Port, and Receiver Slot.

1. **Left Click Button**
2. **Right Click Button**
3. **Scroll Wheel**
4. **DPI Adjustment Button**
5. **Forward Button** (Note: May not function on Mac OS)
6. **Backward Button** (Note: May not function on Mac OS)
7. **Charging Port**
8. **Power Switch (ON/OFF)**
9. **USB Receiver Slot**

4. Setup

4.1 Initial Charging

Before first use, it is recommended to fully charge the mouse. Connect the provided charging cable to the Charging

Port on the mouse and a USB power source (e.g., computer USB port, USB wall adapter). The indicator light will show charging status and turn off when fully charged.

4.2 Connecting the Mouse

1. Locate the 2.4G USB receiver. It is stored in the receiver slot on the bottom of the mouse.
2. Remove the USB receiver from its slot.
3. Plug the USB receiver into an available USB-A port on your computer (laptop or desktop).
4. Turn on the mouse by sliding the Power Switch to the 'ON' position, located on the bottom of the mouse.
5. Your computer should automatically detect and install the necessary drivers. The mouse will be ready for use within a few seconds.



Image: The mouse connected wirelessly to a laptop, demonstrating its 33-foot wireless range.

The mouse operates on a 2.4 GHz wireless connection, offering a stable connection with a range of up to 33 feet (10 meters).

5. Operating Instructions

5.1 Ergonomic Design

The iClever Vertical Mouse is designed to promote a natural 'handshake' position for your wrist and arm. This ergonomic design aims to reduce muscle strain and discomfort often associated with traditional mice.



Image: Visual comparison of ergonomic hand position with the iClever Vertical Mouse versus a traditional mouse.

5.2 DPI Adjustment

The mouse features adjustable DPI (Dots Per Inch) settings to control cursor sensitivity and speed. Press the DPI Adjustment Button (usually located near the scroll wheel) to cycle through the available DPI levels: 1000, 1600, and 2400. Choose the setting that best suits your preference and task.

5.3 Forward/Backward Buttons

Utilize the conveniently placed Forward and Backward buttons (typically on the thumb side) for quick navigation in web browsers and file explorers.



Image: Side view of the mouse, indicating the Forward and Backward navigation buttons.

Note: The Forward/Backward buttons may not be fully functional or customizable on Mac OS due to system limitations.

5.4 Whisper Quiet Click

The mouse is designed with silent click technology, reducing operational noise. This feature allows for a quieter working environment, minimizing distractions for yourself and those around you.



Image: Illustration of the mouse's whisper-quiet click feature, emphasizing a silent work environment.

5.5 Compatibility

The iClever Vertical Wireless Mouse is compatible with various operating systems, including Windows 7/8/10/11, macOS, and Chrome OS. It is designed for use with laptops and personal computers.

6. Maintenance

6.1 Cleaning

To clean your mouse, gently wipe its surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. Ensure no liquid enters the mouse's internal components.

6.2 Battery Care

The mouse features a rechargeable battery. To prolong battery life, avoid fully discharging the mouse frequently. Charge the mouse when the low battery indicator appears or when performance degrades. Store the mouse in a cool, dry place when not in use for extended periods.

7. Troubleshooting

- **Mouse not responding:**
  - Ensure the mouse is turned ON using the power switch on the bottom.
  - Check if the USB receiver is securely plugged into a working USB port on your computer.
  - Verify the mouse battery has sufficient charge. Connect it to a power source using the charging cable.
  - Try plugging the USB receiver into a different USB port or a different computer to rule out port issues.
- **Intermittent connection or lag:**
  - Ensure the mouse is within the 33-foot (10-meter) operating range of the USB receiver.
  - Minimize obstacles between the mouse and the receiver.
  - Avoid using the mouse near other strong wireless devices that might cause interference.
- **Cursor movement is too fast or too slow:**
  - Press the DPI Adjustment Button to change the cursor sensitivity (1000/1600/2400 DPI).
  - Adjust mouse pointer speed settings in your computer's operating system (e.g., Windows Control Panel or Mac System Settings).
- **Scroll wheel not working:**
  - Ensure the mouse is properly connected and powered on.
  - Try restarting your computer.
  - Check for any software conflicts or outdated drivers.

8. Specifications



Image: Dimensions of the iClever Ergonomic Vertical Wireless Mouse.

Brand	iClever
Model Number	TM231G
Connectivity Technology	2.4G Wireless USB (USB-A port required)
Movement Detection Technology	Optical
DPI Resolution	1000 / 1600 / 2400 DPI
Number of Buttons	6 (Left, Right, Scroll Wheel, DPI, Forward, Backward)
Hand Orientation	Right
Wireless Range	Up to 33 feet (10 meters)
Power Source	Rechargeable Battery (Corded Electric for charging)
Compatible Operating Systems	Windows 7/8/10/11, macOS, Chrome OS

Item Weight	3.68 ounces

9. Warranty and Support

9.1 Warranty Information

This iClever product comes with a 12-month hassle-free warranty from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

If you encounter any issues or have questions regarding your iClever Ergonomic Vertical Wireless Mouse, please contact iClever customer support. Refer to the contact information provided on the iClever official website or your product packaging for assistance.

For further assistance, you may visit the iClever Store on Amazon.

© 2024 iClever. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HRY3SMD

More documents and user manuals: **https://manuals.plus/**