Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Seiki SC-32HS970N

Seiki 32-inch HD LED TV SC-32HS970N User Manual

Model: SC-32HS970N

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Seiki 32-inch HD LED TV, model SC-32HS970N. Please read this manual thoroughly before using your television to ensure safe and efficient operation. Keep this manual for future reference.

The Seiki SC-32HS970N is a 32-inch 720p LED television designed to enhance your home entertainment experience. It features a built-in ATSC TV tuner, a VGA port for PC connectivity, three HDMI inputs, and one USB input for versatile media playback.

Package Contents

Before proceeding with the setup, ensure all items are present in the package:

- Seiki 32-inch HD LED TV (SC-32HS970N)
- Remote Control
- TV Stand (2 pieces)
- Screws for TV Stand
- Power Cord
- User Manual (this document)

Setup

1. Attaching the TV Stand

Carefully place the TV face down on a soft, clean surface to prevent screen damage. Align each stand piece with the corresponding slots on the bottom of the TV. Secure the stands using the provided screws.



Image: Angled view of the Seiki 32-inch TV, illustrating the attached stand.

2. Connecting Cables

After attaching the stand, place the TV in its desired location. Connect the necessary cables:

- **Power:** Connect the power cord to the TV's power input and then to a wall outlet.
- **Antenna/Cable:** For over-the-air broadcasts or basic cable, connect an antenna or cable TV coaxial cable to the 'ANT/CABLE IN' port.
- **External Devices (HDMI):** Connect devices like Blu-ray players, game consoles, or streaming devices to the HDMI ports. This TV features three HDMI inputs.
- **External Devices (VGA):** For connecting a computer, use the VGA port.
- **USB Devices:** Insert USB drives for media playback into the USB port.





Image: Side view of the television, highlighting the accessible input ports including HDMI, USB, and VGA.



Image: Rear view of the television, displaying the VESA mounting points and additional rear input/output ports.

3. Initial Power-On and Channel Scan

After connecting all cables, plug the TV into a power outlet. Press the power button on the remote control or on the TV. Follow the on-screen instructions for initial setup, which typically includes language selection and an automatic channel scan for antenna/cable connections.

Operating Instructions

1. Remote Control Overview

The remote control allows you to access all functions of your TV. Ensure batteries are correctly inserted.





Image: The Seiki TV remote control, showing buttons for power, input, channel, volume, menu navigation, and media playback.

- **Power ( ):** Turns the TV on or off.
- **Input:** Selects the input source (HDMI 1/2/3, VGA, TV, USB).
- **Volume (+/-):** Adjusts the sound level.
- **Channel (CH +/-):** Changes TV channels.
- **Menu:** Accesses the main menu for settings adjustments.

- **Navigation Buttons (▲▼◄►):** Navigates through menu options.
- **OK:** Confirms selections.
- **Exit:** Exits the current menu or function.
- **Mute:** Mutes or unmutes the sound.

2. Selecting Input Source

Press the 'Input' button on the remote control to cycle through available input sources (TV, HDMI 1, HDMI 2, HDMI 3, VGA, USB). Select the desired source using the navigation buttons and press 'OK'.

3. Adjusting Settings

Press the 'Menu' button to access picture, sound, and other system settings. Use the navigation buttons to highlight an option and 'OK' to select. Adjust values using the left/right navigation buttons.

- **Picture Settings:** Adjust brightness, contrast, color, tint, and sharpness.
- **Sound Settings:** Control bass, treble, balance, and select sound modes.
- **Channel Settings:** Perform channel scans, edit channels, and set parental controls.
- **Time Settings:** Set the current time and sleep timer.

4. USB Media Playback

Insert a USB flash drive into the USB port. Select 'USB' as the input source. The TV's media browser will appear, allowing you to navigate and play compatible photo, music, or video files stored on the USB drive.

Maintenance

1. Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner. Never spray cleaner directly onto the screen.
- **Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Avoid using abrasive cleaners or solvents.

2. General Care

- Unplug the TV from the power outlet before cleaning or when not in use for extended periods.
- Avoid exposing the TV to direct sunlight, extreme temperatures, or high humidity.
- Do not block ventilation openings on the back of the TV.

Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Ensure the power cord is securely plugged into both the TV and a working electrical outlet. Try a different outlet.
No picture, but sound is present	Check the input source. Ensure the external device (e.g., cable box, DVD player) is powered on and connected correctly.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio cables for external devices.

Problem	Possible Solution
Remote control not working	Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Cannot find channels	Ensure the antenna/cable is properly connected. Perform an automatic channel scan from the TV's menu.

Specifications

Detailed technical specifications for the Seiki 32-inch HD LED TV SC-32HS970N:

Feature	Specification
Brand	Seiki
Model	SC-32HS970N
Screen Size	32 Inches (82 cm)
Display Technology	LED
Display Resolution	720p (1280 x 720 pixels)
Tuner Technology	ATSC, NTSC
Hardware Interface	3x HDMI, 1x USB, 1x VGA
Audio Input	HDMI, USB
Special Features	3D Comb Filter, ATSC Tuner, HDMI Input, USB Input, NTSC Converter, Noise Reduction
Mounting Type	Table Stand (VESA 200mm x 200mm compatible)
Compatible Devices	Laptop, Smartphone, Tablet, Game Console
Recommended Uses	Casual viewing
Package Dimensions	78.74 x 49.02 x 11.18 cm
Item Weight	4.9 kg

Warranty and Support

Warranty Information

This Seiki television, model SC-32HS970N, typically comes with a 1-year warranty from the manufacturer. For renewed products, warranty terms may vary. Please refer to your purchase documentation or contact your retailer for specific warranty details and coverage.



Image: The product packaging, indicating a 1-year warranty from Seiki.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Seiki customer support. Refer to the official Seiki website or your product documentation for the most current contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HY4Y1RK

More documents and user manuals: **https://manuals.plus/**