Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UGREEN 80551

UGREEN USB C Laptop Docking Station User Manual

Model: 80551
Brand: UGREEN

1. Introduction

Thank you for choosing the UGREEN USB C Laptop Docking Station. This device combines a versatile laptop stand with a powerful 5-in-1 USB C hub, designed to enhance your productivity and comfort. It provides ergonomic benefits by elevating your laptop and expands connectivity with essential ports for various peripherals.



Image: The UGREEN USB C Laptop Docking Station, showcasing its dual functionality as a laptop stand and integrated hub.

2. Features

- **5-in-1 USB C Hub:** Integrates essential ports for expanded connectivity.
- **4K HDMI Output:** Connect to external displays for high-resolution video output.
- **Dual USB 3.0 Ports:** High-speed data transfer for peripherals like external hard drives, keyboards, and mice.
- **TF/SD Card Reader:** Convenient access for memory cards from cameras or other devices.
- **4-Level Adjustable Angle:** Ergonomic design allows for adjusting the laptop screen height to reduce neck and arm fatigue.
- **Foldable & Portable Design:** Compact and easy to carry, ideal for travel or on-the-go use.
- **Efficient Heat Dissipation:** Open design promotes airflow to prevent laptop overheating.



Image: Detailed view of the 5-in-1 USB C hub, highlighting the Anti-slip Pad, Type C input, two USB 3.0 ports, HDMI port, and TF/SD Card Reader.



4-Level Adjustable Angle

Relieve cervical pressure



Image: A laptop positioned on the stand, illustrating the four adjustable angle levels (15°, 20°, 30°, 33°) designed to relieve cervical pressure.



Image: A laptop connected to a large external monitor, demonstrating the 4K HDMI output capability of the docking station.



Image: A laptop on the stand with green arrows indicating airflow underneath, illustrating the fast heat dissipation feature to prevent overheating.

3. Setup

1. **Unfold the Stand:** Gently pull the two main support arms outwards until the stand locks into an open position.
2. **Adjust the Angle:** Locate the adjustable support bar at the back of the stand. Lift and position it into one of the four available notches to achieve your desired viewing angle.
3. **Place Your Laptop:** Carefully place your laptop onto the anti-slip pads on the stand. Ensure it is stable and centered.
4. **Connect to Laptop:** Connect the integrated USB C cable from the docking station to your laptop's USB C port.
5. **Connect Peripherals:** Plug your HDMI cable, USB devices, and TF/SD cards into the corresponding ports on the side of the docking station.



Image: A visual guide demonstrating the simple three-step process to unfold and set up the UGREEN docking station.

4. Operating Instructions

4.1 Using the Laptop Stand

The stand can be adjusted to 4 different angles (15°, 20°, 30°, 33°) to provide an optimal ergonomic viewing and typing experience. Adjust the angle by lifting the support bar and placing it into the desired groove. This helps in maintaining a healthy posture and reducing strain during long working hours.

4.2 Using the USB C Hub

- **HDMI Port:** Connect an HDMI cable from the docking station to an external monitor or projector. Ensure your laptop's USB C port supports video output (DisplayPort Alternate Mode). The hub supports up to 4K resolution.
- **USB 3.0 Ports:** Plug in USB devices such as flash drives, external hard drives, keyboards, mice, or printers. These ports offer data transfer speeds of up to 5Gbps.
- **TF/SD Card Reader:** Insert your TF (MicroSD) or SD card into the respective slot. The card reader supports data transfer speeds up to 104MB/s.



Image: A close-up view of the docking station's ports, indicating the data transfer speeds for SD/TF cards (104MB/s) and USB 3.0 (5Gbps).

5. Maintenance

- Keep the device clean by wiping it with a soft, dry cloth.

- Avoid exposing the device to extreme temperatures, humidity, or direct sunlight.
- Do not use abrasive cleaners or solvents.
- Store the device in a cool, dry place when not in use, preferably in its original packaging or a protective pouch.

6. Troubleshooting

6.1 No Display Output via HDMI

- Ensure your laptop's USB C port supports video output (DisplayPort Alternate Mode). Not all USB C ports have this capability.
- Check the HDMI cable connection at both ends (docking station and monitor).
- Try a different HDMI cable or monitor to rule out faulty equipment.
- Update your laptop's graphics drivers.
- Restart your laptop.

6.2 USB Devices Not Recognized

- Ensure the docking station is securely connected to your laptop.
- Try connecting the USB device to a different USB port on the docking station.
- Test the USB device by connecting it directly to your laptop to confirm it is functional.
- For high-power consumption devices, ensure your laptop provides sufficient power through the USB C port.

6.3 SD/TF Card Not Detected

- Ensure the card is fully inserted into the correct slot.
- Check if the card is damaged or corrupted by testing it on another device.
- Ensure your operating system has the necessary drivers for card readers (usually built-in).

7. Specifications

Attribute	Value
Product Dimensions	19.69 x 19.69 x 11.02 inches
Item Weight	8.8 ounces
Model Number	80551
Brand	UGREEN
Color	Black

Attribute	Value
Hardware Interface	USB
Special Feature	Foldable
Compatible Devices	MacBook Pro, iPad Pro, HP, Dell, Acer, Asus, Lenovo (USB C enabled)

8. Warranty and Support

8.1 Warranty Information

UGREEN products typically come with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official UGREEN website. Extended protection plans may also be available for purchase, offering additional coverage for 3 or 4 years.

8.2 Customer Support

For technical assistance, product inquiries, or warranty claims, please contact UGREEN customer support through their official website or the retailer where you purchased the product. You can also visit the UGREEN Store on Amazon for more information and product resources.

© 2025 UGREEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08HYZKD9P

More documents and user manuals: **https://manuals.plus/**