Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit RTS7015B

ZdalaMit RTS7015B Replacement Remote Control User Manual

For RCA Soundbar Models: RTS7015B, RTS7116S, RTS7010BR6, RTS7010BGE6

1. Introduction

This manual provides essential instructions for the proper use and maintenance of your ZdalaMit RTS7015B replacement remote control. Please read this manual thoroughly before operating the device to ensure optimal performance and compatibility with your RCA soundbar.

2. Product Overview

The ZdalaMit RTS7015B is an infrared replacement remote control designed to operate specific RCA soundbar models. It features dedicated buttons for power, volume, input selection, and audio adjustments.



Image 1: ZdalaMit RTS7015B Replacement Remote Control. This image displays the front face of the remote control, showing all its buttons and their labels, including power, volume, input, and audio adjustment controls.

3. Compatibility

This remote control is specifically designed for the following RCA Soundbar models:

- RTS7015B
- RTS7116S
- RTS7010BR6
- RTS7010BGE6

Important: This is not a universal remote control. It will not function with other soundbar models or televisions. Please verify your soundbar model before use.

4. Setup

4.1 Battery Installation

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries (not included), ensuring correct polarity (+ and -).
3. Close the battery compartment cover securely.

4.2 Initial Use

This remote control is pre-programmed and requires no additional setup or pairing. Once batteries are installed, it is ready for use with compatible RCA soundbar models.

5. Operating Instructions

Familiarize yourself with the functions of each button on your remote control:

Button	Function
Power ( )	Turns the soundbar on or off.
Mute ( )	Mutes or unmutes the soundbar audio.
VOL + / **-**	Adjusts the master volume level.
Bluetooth	Selects the Bluetooth input source.
DIGITAL	Selects the Digital (Optical/Coaxial) input source.
Previous Track ( )	Skips to the previous track (in Bluetooth mode).
Play/Pause ( )	Plays or pauses audio playback (in Bluetooth mode).
Next Track ( )	Skips to the next track (in Bluetooth mode).
AUX	Selects the Auxiliary input source.
LINE IN	Selects the Line In input source.
BASS ⌃ / ⌄	Adjusts the bass level up or down.
TREBLE ⌃ / ⌄	Adjusts the treble level up or down.
SOURCE ⌃ / ⌄	Cycles through available input sources.

6. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly inserted and not depleted. Replace if necessary.
  - Point the remote directly at the soundbar's infrared receiver.

- Unplug the soundbar's power supply for a few minutes, then plug it back in to reset the device.

- **Remote does not control my soundbar:**
  - Verify that your soundbar model is listed in the "Compatibility" section (Section 3) of this manual. This remote is not universal.

7. Specifications

- **Model:** RTS7015B (Replacement)
- **Dimensions:** 3 x 2 x 0.5 inches
- **Item Weight:** 0.705 ounces
- **Color:** Black
- **Special Feature:** Pre-Programmed
- **Max Number of Supported Devices:** 1
- **Compatible Devices:** RCA Home Theater Soundbars (specific models listed in Section 3)

8. Maintenance

- Clean the remote control with a soft, dry cloth. Do not use liquid cleaners.
- Avoid exposing the remote to extreme temperatures, humidity, or direct sunlight.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.

9. Support

For any questions or concerns regarding your ZdalaMit RTS7015B replacement remote control, please contact the seller or manufacturer directly. Provide your product model number and a detailed description of the issue for efficient assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08J7NGNDF

More documents and user manuals: **https://manuals.plus/**