MEBERRY M8

MEBERRY M8 10-inch Android 10.0 Tablet User Manual

Model: M8 | Brand: MEBERRY

1. Introduction and Overview

Thank you for choosing the MEBERRY M8 Tablet. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. The MEBERRY M8 is a versatile 10.1-inch tablet running on Android 10.0, designed for a smooth and efficient user experience.

Key features include an Octa-Core processor, 4GB RAM, 64GB internal storage (expandable up to 128GB via TF card), a 1920x1200 Full HD IPS display, and an 8000mAh battery for extended use. It supports dual-band Wi-Fi (2.4GHz and 5GHz) and Bluetooth 5.0 for seamless connectivity. The tablet also comes with a Bluetooth keyboard and wireless mouse for enhanced productivity.



Image 1.1: MEBERRY M8 Tablet with included accessories (keyboard, mouse, and stylus).

2. What's in the Box

Please check the contents of your package. If any items are missing or damaged, contact customer support immediately.

- MEBERRY M8 Tablet
- EU Charger
- Bluetooth Keyboard
- Wireless Mouse
- Charging Cable (USB Type-C)
- Protective Case
- Capacitive Stylus Pen
- Warranty Card
- Cleaning Cloth
- Screen Protector (pre-applied or included)

- User Manual (this document)



Image 2.1: All components included in the MEBERRY M8 Tablet package.

3. Product Features and Components

Familiarize yourself with the physical features and components of your MEBERRY M8 Tablet.

3.1. Tablet Layout



Image 3.1: MEBERRY M8 Tablet physical layout with labeled components.

1. **3.5mm Earphone Jack:** For connecting headphones or external speakers.
2. **Power On/Off Button:** Press and hold to power on/off, short press to sleep/wake.
3. **Volume + Button:** Increases audio volume.
4. **Volume - Button:** Decreases audio volume.
5. **Reset Pinhole:** Use a thin pin to reset the device if it becomes unresponsive.
6. **Type-C Interface:** For charging and data transfer.
7. **Microphone:** For audio input during calls or recordings.
8. **Triple Camera:** Rear camera module.

9. **Lights Flash:** LED flash for the rear camera.
10. **5.0MP Camera:** Front-facing camera.
11. **Double Speaker:** Stereo speakers for audio output.
12. **TF Card Slot:** For inserting a microSD card to expand storage.

3.2. Display

The tablet features a 10.1-inch IPS FHD display with a resolution of 1920 x 1200 pixels, providing clear and vibrant visuals. It is a capacitive touch screen for responsive interaction.



Image 3.2: The tablet's sharp and bright 10.1-inch IPS FHD display.

4. Setup

4.1. Initial Charging

Before first use, fully charge the tablet. Connect the provided USB Type-C cable to the tablet's Type-C port (6) and the other end to the EU charger. Plug the charger into a power outlet. The charging indicator will show the charging status.

4.2. Powering On/Off

- **To Power On:** Press and hold the Power On/Off button (2) for a few seconds until the MEBERRY logo appears.
- **To Power Off:** Press and hold the Power On/Off button (2) until the power options menu appears. Select "Power off" and confirm.
- **Sleep/Wake:** Short press the Power On/Off button (2) to put the tablet to sleep or wake it up.

4.3. Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup wizard. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Set up your Google account (optional, but recommended for app downloads).
- Set date and time.

4.4. Connecting Accessories

4.4.1. Bluetooth Keyboard and Mouse

1. Ensure the keyboard and mouse are charged or have fresh batteries.
2. Turn on the keyboard and mouse.
3. On the tablet, go to **Settings > Connected devices > Bluetooth**.
4. Turn on Bluetooth and scan for devices.
5. Select the keyboard and mouse from the list to pair them. Follow any on-screen prompts for pairing codes.

4.4.2. TF Card Installation

To expand storage, insert a microSD (TF) card into the TF Card Slot (labeled TF on the diagram). Gently push the card until it clicks into place. Ensure the card is inserted in the correct orientation.

5. Operating Instructions

5.1. Basic Navigation

The MEBERRY M8 Tablet uses standard Android touch gestures:

- **Tap:** To select an item or open an app.
- **Tap and Hold:** To access contextual menus or move icons.
- **Swipe:** To scroll through pages or lists.
- **Pinch-to-Zoom:** To zoom in or out on images or web pages.

5.2. Wi-Fi Connection

To connect to a Wi-Fi network:

1. Go to **Settings > Network & internet > Wi-Fi**
2. Turn on Wi-Fi.
3. Select your desired network from the list.
4. Enter the password if prompted and tap "Connect".

The tablet supports both 2.4GHz and 5GHz Wi-Fi bands.

5.3. Using the Cameras

The tablet has a 5.0MP front camera and an 8.0MP rear camera. Open the "Camera" app to take photos or record videos. You can switch between front and rear cameras within the app.

5.4. App Management

- **Installing Apps:** Open the "Google Play Store" app, search for your desired app, and tap "Install".
- **Uninstalling Apps:** Tap and hold the app icon on the home screen or app drawer, then drag it to "Uninstall" or select "App info" and then "Uninstall". Alternatively, go to **Settings > Apps & notifications > See all apps**, select the app, and tap "Uninstall".

5.5. Productivity with Keyboard and Mouse

Once connected, the Bluetooth keyboard and mouse function like a traditional computer setup, allowing for more efficient typing, navigation, and interaction with applications, transforming your tablet into a portable workstation.



Image 5.1: The MEBERRY M8 Tablet can be used as a tablet or a laptop with accessories.



Image 5.2: Enhanced productivity with the included Bluetooth keyboard.

6. Maintenance

6.1. Cleaning

- **Screen:** Use the provided cleaning cloth or a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals.
- **Body:** Wipe the tablet's body with a soft, dry cloth.

6.2. Screen Protector

The product screen comes with a protective film to reduce damage during transport. If you notice scratches on this film, it is recommended to carefully remove it. The actual screen underneath should be pristine.

6.3. Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Do not let the battery completely drain frequently.
- Use the original charger and cable for optimal charging.

6.4. Software Updates

Periodically check for system updates to ensure your tablet has the latest features and security patches. Go to **Settings > System > System update**.

7. Troubleshooting

If you encounter issues with your MEBERRY M8 Tablet, refer to the following common solutions:

7.1. Tablet Not Powering On

- Ensure the tablet is sufficiently charged. Connect it to the charger for at least 30 minutes.
- Press and hold the Power On/Off button (2) for 10-15 seconds to force a restart.

7.2. Unresponsive Screen/System Freeze

- Press and hold the Power On/Off button (2) for 10-15 seconds to force a restart.
- If the tablet remains unresponsive, locate the Reset pinhole (5) and gently insert a thin pin (like a paperclip) to press the reset button. This will force a restart without data loss.

7.3. Wi-Fi Connection Issues

- Ensure Wi-Fi is enabled on the tablet.
- Restart your Wi-Fi router.
- Forget the network (**Settings > Network & internet > Wi-Fi**, tap network, then "Forget") and reconnect.
- Ensure you are within range of the Wi-Fi signal.

7.4. Slow Performance

- Close unnecessary background applications.
- Clear cache for frequently used apps (**Settings > Apps & notifications > See all apps**, select app, then **Storage & cache > Clear cache**).
- Ensure sufficient free storage space.
- Restart the tablet periodically.

8. Specifications

Feature	Specification
Brand	MEBERRY
Model Number	M8
Operating System	Android 10.0
Processor	UNISOC SC9863A Octa-Core, 1.6 GHz
RAM	4 GB
Internal Storage	64 GB
Expandable Storage	Up to 128 GB (via TF/microSD card)

Display Size	10.1 inches
Display Resolution	1920 x 1200 pixels (FHD IPS)
Front Camera	5.0 MP
Rear Camera	8.0 MP
Battery Capacity	8000 mAh
Wi-Fi	802.11a/b/g/n (Dual-band 2.4G & 5G)
Bluetooth	Bluetooth 5.0
Ports	USB Type-C, 3.5mm Audio Jack, TF Card Slot
Dimensions (L x W x H)	24 x 16 x 0.7 cm (approx. 9.45 x 6.3 x 0.28 inches)
Weight	489 grams (approx. 1.08 lbs)

9. Warranty and Support

MEBERRY is committed to providing high-quality products and excellent customer service. Your MEBERRY M8 Tablet comes with a warranty, details of which can be found on the included Warranty Card.
If you have any questions, concerns, or require technical assistance, please do not hesitate to contact our professional customer service team. We aim to respond to all inquiries within 24 hours.
For support, please refer to the contact information provided on your warranty card or the official MEBERRY website.

© 2024 MEBERRY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question