TELESIN Waterproof Case Set

TELESIN Waterproof Case Set for GoPro Hero 9/10/11/12/13 Black - Instruction Manual

Model: Waterproof Case Set | Brand: TELESIN

Introduction

This instruction manual provides essential information for the proper setup, operation, and maintenance of your TELESIN Waterproof Case Set for GoPro Hero 9, 10, 11, 12, and 13 Black cameras. This case is designed to protect your camera during extreme outdoor activities and underwater adventures, supporting depths up to 60 meters (196 feet). The set also includes a 3-pack of dive filters for enhanced underwater color correction.

Figure 1: TELESIN Waterproof Case Set, including the clear housing, three dive filters (red, light red, magenta), and anti-fog inserts.

Setup

1. Opening the Waterproof Case

1. Locate the latch mechanism on the top of the waterproof case.
2. Push the small button on the latch down to release the locking mechanism.
3. Lift the latch upwards to open the back door of the case.

2. Inserting the GoPro Camera

1. Ensure your GoPro Hero 9/10/11/12/13 Black camera's side and bottom flaps are securely closed.
2. Carefully slide your GoPro camera into the open waterproof case. Ensure it sits snugly and correctly within the internal padding.

3. Closing and Securing the Case

1. Close the back door of the waterproof case.
2. Push the top latch down until it clicks securely into place. Verify that the case is fully sealed and airtight.

4. Attaching Dive Filters

1. Select the appropriate dive filter (Red, Light Red, or Magenta) based on your diving conditions (refer to the Operating

section for guidance).

2. Align the chosen filter with the lens port of the waterproof case.
3. Gently push the filter onto the lens port until it snaps securely into place. The filters are designed for easy attachment and removal.
4. Each filter includes a tether string. For added security, loop the tether string through the designated attachment point on the waterproof case to prevent accidental loss underwater.

5. Using Anti-Fog Inserts

1. For environments with significant temperature differences, place the provided anti-fog inserts inside the waterproof case before closing it. Position them along the sides or bottom, ensuring they do not obstruct the camera lens or buttons.

Video 1: Demonstrates the installation of the GoPro Hero 9 Black into the TELESIN Waterproof Housing and the attachment of filters. This video also shows how to access the camera's buttons while inside the case.

Operating the Waterproof Case and Filters

1. Camera Control

The waterproof case features external buttons that align with your GoPro's controls, allowing you to power on/off, change modes, and start/stop recording without opening the case.

2. Dive Filter Usage

Dive filters are crucial for correcting color loss underwater, which occurs because water absorbs different wavelengths of light at varying depths. Using the correct filter will restore natural colors to your footage.

- **Red Filter:** Ideal for blue or tropical waters at depths of 5-25 meters (16-82 feet). This filter helps restore red tones lost at these depths, preventing a greenish or bluish cast.

Figure 2: Comparison of underwater footage before and after applying a red dive filter, showing improved color balance.

- **Light Red/Orange Filter:** Suitable for shallower blue or tropical waters, or for green waters at moderate depths. This filter provides a lighter correction than the standard red filter.

Figure 3: Comparison of underwater footage before and after applying a light red dive filter, demonstrating color enhancement.

- **Magenta Filter:** Best for green waters (freshwater or green ocean water) at depths of 5-25 meters (16-82 feet). This filter counteracts the green tint, bringing out more natural colors.

Figure 4: Comparison of underwater footage before and after applying a magenta dive filter, showing improved color accuracy in green water.

Video 2: Illustrates the effect of SOONSUN color filters on underwater footage, showing the difference between using a filter and no filter for vibrant colors.

Video 3: A short preview demonstrating the waterproof capabilities and ease of use of the protective case for GoPro Hero 9/10/11/12/13 Black cameras.

Maintenance

1. Cleaning

- After each use, especially in saltwater, rinse the waterproof case and filters thoroughly with fresh water.
- Use a soft, lint-free cloth to gently wipe the case and filters dry. Avoid abrasive materials that could scratch the surfaces.
- Ensure no salt residue remains on the O-ring seal of the case, as this can compromise its waterproof integrity.

2. Inspection and Storage

- Regularly inspect the O-ring seal for any signs of damage, cracks, or debris. Replace if necessary.
- Store the waterproof case and filters in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep filters in their protective pouches when not in use to prevent scratches.

Troubleshooting

1. Water Leakage

- **Cause:** Improperly closed latch, damaged O-ring, or debris on the O-ring.
- **Solution:** Ensure the latch is fully engaged. Inspect the O-ring for any damage or foreign particles and clean or replace if needed. Always perform a dry test before submerging with the camera.

2. Fogging Inside the Case

- **Cause:** High humidity or temperature difference between the inside and outside of the case.
- **Solution:** Use the provided anti-fog inserts. Ensure the camera and case are dry before sealing.

3. Filters Not Staying On

- **Cause:** Incorrect alignment or worn attachment points.
- **Solution:** Realign the filter carefully and apply firm, even pressure until it clicks. If the issue persists, inspect the filter's attachment clips for damage.

Specifications

- **Brand:** TELESIN
- **Model:** Waterproof Case Set
- **Compatibility:** GoPro Hero 9 Black, Hero 10 Black, Hero 11 Black, Hero 12 Black, Hero 13 Black
- **Waterproof Depth:** Up to 60 meters (196 feet)
- **Case Material:** High-quality PMMA plastic
- **Lens Cover Material:** Ultra-thick tempered glass with high light transmittance
- **Included Filters:** Red, Light Red/Orange, Magenta (3-pack)
- **Additional Accessories:** Quick release buckle mount, long screw, anti-fog inserts

Figure 5: Detailed product specifications and included components of the TELESIN Waterproof Case Set.

Warranty and Support

This TELESIN product is covered by the manufacturer's warranty. For specific warranty details, claims, or technical

support, please refer to the documentation included with your product or visit the official TELESIN website. You may also contact the seller directly for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question