Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Contixo R3

Contixo R3 Robot Dog: Remote Control Interactive Toy User Manual

Model: R3

Introduction

Welcome to the Contixo R3 Robot Dog user manual. This guide provides comprehensive instructions for setting up, operating, and maintaining your interactive robot dog. The Contixo R3 is designed to provide engaging play with various movements, sounds, and programmable actions.



Image: The Contixo R3 Robot Dog, showcasing its interactive features and design.

What's Included

Please check the package contents to ensure all items are present:

- Contixo R3 Robot Dog
- Remote Control
- USB Charging Cable
- User Manual (this document)
- 2 AA Batteries (for remote control)



Image: Contixo R3 Robot Dog and its remote control.

Safety Information

- Not suitable for children under 3 years due to small parts.
- Adult supervision is recommended during play.
- Do not operate the robot near water or in wet conditions.

- Ensure the robot is turned off when not in use or during charging.
- Do not attempt to disassemble or modify the robot or remote control.
- Dispose of batteries responsibly.

Setup

1. Remote Control Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Open the battery cover using a small screwdriver (not included).
3. Insert 2 AA batteries, ensuring correct polarity (+/-).
4. Close the battery cover and secure it with the screw.

2. Charging the Robot Dog

The Contixo R3 Robot Dog has a built-in rechargeable battery.

1. Locate the charging port on the robot dog (typically on the underside or rear).
2. Connect the USB charging cable to the robot's charging port.
3. Connect the other end of the USB cable to a standard USB power adapter (e.g., phone charger, computer USB port).
4. The indicator light will show charging status (e.g., red for charging, off when fully charged).
5. A full charge typically takes approximately 60-90 minutes.



Image: Contixo R3 Robot Dog features, including the charging port.

3. Powering On/Off

- To turn on the robot dog, locate the On/Off switch (usually on the underside) and slide it to the "ON" position.
- To turn off the robot dog, slide the switch to the "OFF" position.

Your browser does not support the video tag.

Video: Unboxing and initial setup of the Contixo R3 Smart Robot Toy.

Operating Instructions

Remote Control Functions

The remote control allows you to direct the robot dog's movements and actions. Refer to the remote control diagram for specific button layouts.

- **Forward/Backward:** Moves the robot dog in the specified direction.
- **Left/Right:** Turns the robot dog.
- **Sit Down:** Commands the robot to sit.
- **Push-Up:** Initiates a push-up action.
- **Dance:** Activates a dance routine.
- **Sing:** Plays a song.
- **Bark:** Makes barking sounds.



Image: Children operating the Contixo R3 Robot Dog with the remote control.

Gesture Sensing

The Contixo R3 Robot Dog can respond to hand gestures. Wave your hand in front of its head to trigger various reactions, such as walking forward or making sounds.



Image: Robot dog responding to gesture sensing.

Voice Commands

The robot dog features 7 built-in voice commands. Speak clearly to the robot to activate specific actions. Examples include:

- "Hello"
- "Follow me"

- "Dance"
- "Sing"
- "Sit"
- "Stand"
- "Bark"



Image: Robot dog responding to music and voice commands.

Your browser does not support the video tag.

Video: Demonstrating various movements and interactions of the Contixo R3 Blue Robot Toy.

Programming

The Contixo R3 Robot Dog can be programmed to perform a series of up to 30 commands. This feature allows for customized play sequences.

1. Press the "Program" button on the remote control to enter programming mode.
2. Input your desired sequence of commands using the remote control buttons (e.g., Forward, Sit Down, Push-Up).
3. Press the "Program" button again to save the sequence and exit programming mode.
4. Press the "Play" button to execute the programmed sequence.



Image: Steps for programming the robot dog.

Your browser does not support the video tag.

Video: Demonstrating the programming capabilities of the Contixo R3 Blue Smart Robot.

Maintenance

- **Cleaning:** Wipe the robot dog with a soft, dry cloth. Do not use harsh chemicals or immerse in water.
- **Storage:** Store the robot dog and remote control in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** If the robot will not be used for an extended period, ensure it is fully charged before storage. Remove AA batteries from the remote control if storing for long periods to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Robot does not turn on.	Low battery; Power switch off.	Charge the robot dog; Ensure power switch is ON.
Remote control not working.	Remote batteries low or incorrectly installed.	Replace AA batteries in remote; Check polarity.
Robot not responding to commands.	Out of range; Interference; Robot not paired.	Move closer to the robot; Ensure no obstructions; Power cycle both robot and remote.
Short battery life.	Frequent use of high-power functions; Old battery.	Ensure full charge before use; Reduce continuous high-power actions.

Specifications

- **Model Number:** R3
- **Brand:** Contixo
- **Material:** Plastic
- **Color:** Blue (also available in Pink)
- **Item Dimensions:** 9.65 x 9.65 x 10.04 inches
- **Item Weight:** 1.8 pounds
- **Robot Battery:** Built-in Rechargeable (400 mAh)
- **Remote Control Batteries:** 2 AA batteries (included)
- **Recommended Age:** 4 - 12 years
- **Educational Objective:** Develop and improve motor skills, focus, and problem-solving abilities
- **Indoor/Outdoor Usage:** Indoor

Warranty & Support

Contixo is committed to providing quality products. If you encounter any issues with your Contixo R3 Robot Dog, please do not hesitate to contact our service team for assistance. We are dedicated to ensuring your satisfaction.
For support, please visit the official Contixo website or refer to the contact information provided on the product packaging.

© 2023 Contixo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JJG7NH8

More documents and user manuals: **https://manuals.plus/**