Midea MAD40F8APK

Midea Air Fryer 4L User Manual

Model: MAD40F8APK

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating the appliance.

- Do not immerse the cord, plug, or the appliance in water or other liquid.
- Always ensure the appliance is unplugged from the outlet before cleaning, assembling, or disassembling parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.
- Always place the appliance on a stable, heat-resistant surface.
- Do not use the appliance for anything other than its intended use.
- Exercise extreme caution when removing the basket or disposing of hot grease.

2. Product Overview

The Midea 4L Air Fryer utilizes X-Express Technology for 3D heating, providing a healthier cooking method with up to 90% less oil compared to traditional frying. It features an intuitive LED touch screen and 8 pre-programmed cooking modes for ease of use.



Figure 2.1: Front view of the Midea 4L Air Fryer, showcasing its sleek design and digital display.

2.1 Components



Figure 2.2: Diagram illustrating key components including the control panel, wire winding handle, non-slip rubber feet, and removable baking tray.

- **Control Panel:** Digital LED touch screen for setting temperature, time, and selecting cooking modes.
- **Air Inlet:** Located at the top of the unit for air circulation.
- **Air Outlet:** Located at the rear of the unit for hot air exhaust.
- **Basket/Baking Tray:** Removable, non-stick coated basket for holding food during cooking. Dishwasher safe for easy cleaning.
- **Handle:** Ergonomically designed for safe removal of the basket.
- **Non-slip Rubber Feet:** Ensures stability on various surfaces.
- **Wire Winding Handle:** For convenient cord storage.

3. Setup and First Use

3.1 Unpacking

1. Remove all packaging materials from the appliance.
2. Check that all components are present and undamaged.

3.2 Initial Cleaning

1. Wipe the exterior of the air fryer with a damp cloth.
2. Wash the basket and baking tray thoroughly with hot water, dish soap, and a non-abrasive sponge. These parts are dishwasher safe.
3. Dry all parts completely before use.

3.3 Placement

- Place the air fryer on a stable, level, and heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of free space on the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.
- Do not place the appliance against a wall or other appliances.

4. Operating Instructions

4.1 Powering On and Off

- Plug the power cord into a grounded wall outlet. The display will illuminate briefly.
- To turn off, press and hold the power button on the control panel.

4.2 Using the Control Panel



Figure 4.1: The LED touch screen control panel displaying 8 one-touch cooking functions.

The Midea Air Fryer features an intuitive LED touch screen for easy operation. You can manually set temperature and time or use the pre-programmed functions.

- **Temperature Control:** Use the '+' and '-' buttons to adjust the temperature from 35°C to 200°C.
- **Time Control:** Use the '+' and '-' buttons to set the cooking time from 0 to 60 minutes.
- **Pre-programmed Modes:** Select from 8 one-touch functions for common dishes like Defrost, French Fries, Chicken Wing, Meat, Shrimp, Fish, Cake, and Reheat. Selecting a preset will automatically set the optimal temperature and time.
- **Shake Alarm:** For certain recipes, the air fryer will emit an audible alert to remind you to shake or flip the food halfway through cooking, ensuring even results.

4.3 Cooking Process

1. Place the food into the air fryer basket. Do not overfill the basket to allow for proper air circulation.
2. Slide the basket back into the air fryer until it clicks into place.

3. Select a pre-programmed mode or manually set the desired temperature and time.
4. Press the start button to begin cooking.
5. If prompted by the shake alarm, carefully remove the basket, shake or flip the food, and reinsert the basket to resume cooking.
6. Once cooking is complete, the timer will sound, and the appliance will automatically shut off.
7. Carefully remove the basket and transfer the cooked food to a serving dish.



Figure 4.2: Illustration of the Dual-Cyclone Rapid Air Technology, providing 360° air flow heating for crispy exteriors and juicy interiors without preheating.



Figure 4.3: Examples of food quantities suitable for the 4L capacity, including 450g French fries, 1.5kg grilled chicken, 10 chicken wingettes, and a 6-inch pizza.

5. Maintenance and Cleaning

Regular cleaning of your Midea Air Fryer will ensure optimal performance and extend its lifespan.

5.1 Cleaning the Basket and Tray



Figure 5.1: The non-stick basket and tray are easy to clean by hand or in a dishwasher.

- Always unplug the air fryer and allow it to cool completely before cleaning.
- Remove the basket and baking tray. These parts are dishwasher safe.
- For hand washing, use hot water, dish soap, and a non-abrasive sponge. Do not use metal scouring pads or abrasive cleaning materials, as they can damage the non-stick coating.
- For stubborn food residue, soak the basket and tray in warm, soapy water for about 10 minutes before cleaning.
- Ensure all parts are thoroughly dry before reassembling or storing.

5.2 Cleaning the Exterior and Interior

- Wipe the exterior of the air fryer with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Clean the interior of the appliance with a damp cloth and mild detergent if necessary.
- Ensure no water enters the main unit.

6. Troubleshooting

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in.	Ensure the power cord is securely plugged into a grounded outlet.
Food is not cooked evenly.	Basket is overfilled; food not shaken.	Do not overfill the basket. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty food.	Clean the basket and tray thoroughly after each use. For fatty foods, consider using parchment paper.
Shake alarm not sounding.	Not all presets include a shake reminder.	The shake reminder is specific to certain pre-programmed modes. For manual cooking, remember to shake food manually.

7. Specifications

Feature	Detail
Brand	Midea
Model Number	MAD40F8APK
Colour	matt Black
Product Dimensions	27.5 x 38 x 31.6 cm
Capacity	4 litres
Power / Wattage	1500 watts
Voltage	220 Volts
Material	Metal
Item Weight	4.76 kg
Special Features	Temperature Control, Timer, Stain Resistant, Automatic Shut-Off, Programmable

8. Warranty and Support

Midea offers comprehensive customer support for your air fryer.

- **Warranty:** This product comes with a 2-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims.
- **Customer Service:** For any inquiries, technical assistance, or warranty claims, please contact Midea customer service. 24/7 customer service is available.
- **Online Resources:** Visit the official Midea store on Amazon for additional product information and support:Midea Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question