Arno OF5328B2

Arno 6-in-1 AirFry 40L Electric Oven User Manual

Model: OF5328B2

1. Introduction

Thank you for choosing the Arno 6-in-1 AirFry 40L Electric Oven. This versatile appliance combines six cooking functions: AirFry, bake, grill, heat, roast, and toast, providing a wide range of culinary possibilities. With its 40-liter capacity, 240-minute timer with automatic shut-off, and adjustable temperature up to 240°C, it is designed for efficient and convenient cooking. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. These include:

- Read all instructions before operating the oven.
- Do not touch hot surfaces. Always use oven mitts or gloves when handling hot materials.
- To protect against electric shock, do not immerse the cord, plug, or any part of the oven in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use attachments not recommended by the appliance manufacturer, as they may cause hazards.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended household use.

- Ensure adequate ventilation around the oven during operation.

3. Product Overview and Components

The Arno 6-in-1 AirFry Electric Oven is designed for ease of use and versatility. Familiarize yourself with its main components:

- **Oven Cavity (40L Capacity):** Spacious interior for various dishes.
- **Control Panel:** Features knobs for temperature, cooking function, and timer.
- **Temperature Control Knob:** Adjusts temperature up to 240°C.
- **Function Selector Knob:** Choose from AirFry, Bake, Grill, Heat, Roast, or Toast.
- **Timer Knob:** Sets cooking time up to 240 minutes with automatic shut-off.
- **Power Indicator Light:** Illuminates when the oven is operating.
- **Glass Door:** Allows monitoring of cooking progress.
- **Cool-Touch Handle:** For safe opening and closing of the oven door.
- **Removable Grill Rack:** For grilling and supporting cookware.
- **Removable Baking Tray:** For baking, roasting, and collecting drips.



Image 3.1: The Arno 6-in-1 AirFry 40L Electric Oven shown with various dishes prepared using its functions.



Image 3.2: Interior view highlighting the heating elements and air circulation for the AirFry function.

4. Setup

Follow these steps to set up your Arno Electric Oven for the first time:

1. **Unpack:** Carefully remove the oven and all accessories from the packaging. Retain packaging for future transport or storage.

2. **Placement:** Place the oven on a stable, level, and heat-resistant surface. Ensure there is at least 10-15 cm (4-6 inches) of clearance on all sides and above the oven for proper ventilation. Do not place it directly against a wall or under cabinets.
3. **Power Connection:** Ensure your electrical outlet matches the oven's voltage requirements (220V for this model). Plug the power cord into a grounded electrical outlet.
4. **Initial Cleaning:** Wash the removable grill rack and baking tray with warm, soapy water. Rinse thoroughly and dry completely. Wipe the interior and exterior of the oven with a damp cloth.
5. **First Use Burn-in:** Before cooking food, operate the oven empty for approximately 15 minutes at the maximum temperature (240°C) using the 'Bake' function. This helps to burn off any manufacturing oils and odors. Some smoke and odor are normal during this process; ensure the area is well-ventilated.



Image 4.1: The oven's 40L capacity allows for cooking multiple items or larger meals.

5. Operating Instructions

Your Arno Electric Oven offers multiple cooking functions for diverse culinary needs.

5.1 General Operation

1. **Prepare Food:** Place your food on the grill rack or baking tray.
2. **Insert Food:** Carefully slide the rack or tray into the desired position within the oven cavity.
3. **Select Function:** Turn the Function Selector Knob to choose your desired cooking mode (AirFry, Bake, Grill, Heat, Roast, Toast).
4. **Set Temperature:** Turn the Temperature Control Knob to the desired temperature (up to 240°C).
5. **Set Timer:** Turn the Timer Knob to the desired cooking time (up to 240 minutes). The power indicator light will illuminate, signaling that the oven has started heating.
6. **Monitor Cooking:** Observe food through the glass door. The oven will automatically shut off when the timer reaches zero, and a bell will sound.
7. **Remove Food:** Using oven mitts, carefully remove the cooked food from the oven.

5.2 Cooking Functions

- **AirFry:** Utilizes uniform hot air circulation to achieve crispy results with little to no oil. Ideal for fries, chicken wings, and other fried foods.
- **Bake:** For traditional baking of cakes, cookies, bread, and casseroles.
- **Grill:** Perfect for browning the top of dishes, grilling meats, or making toast.
- **Heat:** For warming up pre-cooked meals or keeping food warm.
- **Roast:** Suitable for roasting meats, poultry, and vegetables.

- **Toast:** For toasting bread, bagels, and similar items.



Image 5.1: Visual representation of the six cooking functions available.

6. Cleaning and Maintenance

Regular cleaning and maintenance will prolong the life of your oven and ensure optimal performance.

1. **Always Unplug:** Before cleaning, always unplug the oven from the electrical outlet and allow it to cool completely.
2. **Clean Accessories:** The removable grill rack and baking tray can be washed in warm, soapy water. For stubborn food residue, soak them before cleaning. Rinse and dry thoroughly.
3. **Clean Interior:** Wipe the interior walls of the oven with a damp cloth and a mild, non-abrasive detergent. Do not use harsh chemicals or abrasive sponges, as they can damage the non-stick coating (if applicable) or surfaces.
4. **Clean Exterior:** Wipe the exterior surface with a damp cloth. Dry thoroughly. Do not immerse the oven in water or spray water directly onto it.
5. **Door Cleaning:** Clean the glass door with a glass cleaner or a damp cloth.
6. **Storage:** When not in use, store the oven in a clean, dry place.

7. Troubleshooting

If you encounter any issues with your Arno Electric Oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Oven does not turn on.	Not plugged in; power outage; faulty outlet; timer not set.	Ensure the oven is securely plugged into a working outlet. Check your home's circuit breaker. Ensure the timer knob is turned past the 'OFF' position.
Food not cooking evenly.	Oven not preheated; incorrect rack position; overcrowding.	Allow the oven to preheat fully before inserting food. Adjust rack position for optimal heat distribution. Avoid overcrowding the oven; cook in batches if necessary.
Excessive smoke during cooking.	Food residue or grease buildup; fatty foods.	Clean the oven interior thoroughly. Use the baking tray to catch drips from fatty foods. Ensure proper ventilation.
AirFry function not making food crispy.	Overcrowding; insufficient cooking time/temperature; too much oil.	Do not overcrowd the basket/tray. Ensure food is in a single layer. Increase cooking time or temperature slightly. Use minimal oil or none at all for best AirFry results.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Detailed technical specifications for the Arno 6-in-1 AirFry 40L Electric Oven:

- **Brand:** Arno
- **Model Name:** Arno Airfry 6 em 1
- **Model Number:** OF5328B2
- **Color:** Black
- **Dimensions (D x W x H):** 41.5 cm x 56.4 cm x 36.3 cm
- **Capacity:** 40 Liters
- **Power:** 1600 KW
- **Control Type:** Knobs
- **Power Source:** Electric
- **Voltage:** 220 Volts (for this specific variant)
- **Temperature Range:** Up to 240°C
- **Timer:** Up to 240 minutes with automatic shut-off
- **Item Weight:** 8000 Grams (8 kg)
- **Material:** Metal
- **Included Components:** Airfry Oven, grill rack, baking tray, user manual



Image 8.1: Product dimensions for placement reference.

9. Warranty and Support

Your Arno 6-in-1 AirFry 40L Electric Oven comes with a manufacturer's warranty and dedicated support.

9.1 Warranty Information

This product is covered by a **1-year warranty** from the manufacturer. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.

9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Arno customer support. You can find contact information on the official Arno website or through your retailer. When contacting support, please have your product model number (OF5328B2) and proof of purchase readily available.

© 2023 Arno. All rights reserved.