Chefhandy 7200

Chefhandy Baby Wipe Warmer & Wet Wipes Dispenser (Model 7200) Instruction Manual

Your guide to safe and effective use of your Chefhandy wipe warmer.

1. Introduction

Thank you for choosing the Chefhandy Baby Wipe Warmer & Wet Wipes Dispenser. This device is designed to provide warm, moist wipes for enhanced comfort during diaper changes or for general use. Please read this manual thoroughly before operation to ensure proper use and maintenance.

2. Important Safety Instructions

- Read all instructions before use.
- Do not immerse the unit in water or other liquids.
- Unplug the unit when not in use or before cleaning.
- Keep out of reach of children.
- Use only with the provided power adapter.
- Do not operate if the cord or plug is damaged.
- Ensure the lid is firmly closed after each use to maintain moisture and heat.
- If wipes are heated for more than a week, it is recommended to replace the old pack with a new one to ensure hygiene.

3. Package Contents

- Chefhandy Baby Wipe Warmer (Model 7200)
- Power Adapter (supports 120V voltage)
- User Manual



Figure 1: Included items in the package: the Chefhandy wipe warmer, its power cable, and the instruction manual.

4. Product Features

- **Large Capacity:** Accommodates up to 150 wipes, functioning as both a warmer and dispenser.
- **Advanced Surround Heating:** Heats wipes evenly from around the inner box, preventing local overheating and maintaining moisture.
- **Multi-Heating Modes:** Three adjustable temperature settings:
  - Low: 86 to 95 degrees Fahrenheit (30-35°C)
  - Medium: 104 to 113 degrees Fahrenheit (40-45°C)
  - High: 122 to 131 degrees Fahrenheit (50-55°C)

  Once the set temperature is reached, the warmer maintains a constant temperature.
- **Super Silent Operation:** Designed to operate quietly, avoiding disturbance.
- **Leak-Proof Design:** Features a fully sealing lid to prevent leaks and keep wipes moist.
- **Convenient Operation:** Includes a subtle night light for visibility and an easy on/off switch.



Figure 2: The temperature control panel and the sealing gasket of the lid, which helps retain heat and moisture.

5. Setup

1. **Unpack:** Carefully remove the wipe warmer and all accessories from the packaging.
2. **Placement:** Place the unit on a flat, stable surface away from water sources.
3. **Power Connection:** Connect the power adapter to the unit and then plug it into a standard 120V electrical outlet.
4. **Load Wipes:** Open the lid by pressing the "Press" button to open it. Place a pack of wet wipes (up to 150 count) into the warmer. For best results, keep the wipes in their original packaging.
5. **Secure Lid:** Close the lid firmly, ensuring the sealing gasket creates a tight seal.



Figure 3: The wipe warmer with a pack of wipes inserted, ready for use.

6. Operating Instructions

1. **Power On:** Press the power button (marked with a circle and vertical line) to turn on the unit. The indicator light will illuminate.
2. **Select Temperature:** Press the heat setting button (marked with three wavy lines) to cycle through the three temperature modes: Low (one wavy line illuminated), Medium (two wavy lines illuminated), and High (three wavy lines illuminated). Select your desired temperature.
3. **Heating Process:** The unit will begin heating the wipes. It may take some time for the wipes to reach the selected temperature, especially for a new pack.
4. **Dispensing Wipes:** To retrieve a warm wipe, press the "Press" button on the lid to open it. Pull out a wipe from the top of the pack. Ensure the lid is closed firmly after each use to maintain optimal temperature and moisture.
5. **Night Light:** The subtle indicator lights provide visibility in low-light conditions without causing disturbance.
6. **Power Off:** Press the power button again to turn off the unit.

Your browser does not support the video tag.

Video 1: Demonstration of loading wipes and selecting temperature settings on the Chefhandy wipe warmer.

Your browser does not support the video tag.

Video 2: A user demonstrating the ease of use and universal fit for various wipe brands within the Chefhandy warmer.

7. Maintenance

- **Cleaning:** Unplug the unit before cleaning. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Moisture Check:** Periodically check the inside of the lid for condensation. If excessive, wipe it dry.
- **Wipe Replacement:** For optimal hygiene and performance, replace the pack of wipes if they have been heated for more than one week.

8. Troubleshooting

Problem	Possible Cause	Solution
Wipes are not warm.	Unit not plugged in or turned on; incorrect heat setting; insufficient heating time.	Ensure unit is plugged in and powered on. Select a higher heat setting. Allow 1-2 hours for wipes to fully warm up.
Wipes are drying out.	Lid not properly sealed; wipes heated for too long.	Ensure the lid is firmly closed after each use. Replace wipes if heated for over a week. Consider adding a small amount of water to the bottom of the unit if using loose wipes.
Unit makes noise.	Normal operation sounds (clicking when changing settings).	This is generally normal. The unit is designed for silent operation during heating, but button presses may produce a sound.

9. Specifications

- **Brand:** Chefhandy
- **Model:** 7200
- **Product Dimensions:** 10.2 x 6.3 x 4.3 inches
- **Item Weight:** 1.83 pounds
- **Material Composition:** ABS
- **Power Input:** 120V
- **Temperature Modes:** Low (86-95°F), Medium (104-113°F), High (122-131°F)
- **Additional Features:** 3 Temperature Adjustable, Even Heating, Night Light

10. Warranty & Support

The Chefhandy Baby Wipe Warmer (Model 7200) comes with a **2-year warranty**. For any product inquiries, technical support, or warranty claims, please contact Chefhandy customer service through the retailer's platform or visit the official Chefhandy store online.
Online Store: Chefhandy Store

© 2025 Chefhandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question