Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi SR-06

De'Longhi SR-06 Fryer Switch Instruction Manual

Detailed guide for installation, operation, and maintenance of your De'Longhi SR-06 Fryer Switch.

1. Introduction

This instruction manual provides essential information for the safe and correct installation, operation, and maintenance of the De'Longhi SR-06 fryer switch. This component is an original replacement part designed for specific De'Longhi fryer models. Please read this manual thoroughly before attempting any installation or repair.

2. Safety Information

- **Disconnect Power:** Always ensure the fryer is completely disconnected from the main power supply before attempting any installation, maintenance, or repair. Failure to do so can result in electric shock or serious injury.
- **Professional Installation Recommended:** If you are not experienced with electrical repairs, it is highly recommended to seek assistance from a qualified technician.
- **Use Original Parts:** Only use genuine De'Longhi replacement parts to ensure compatibility and safety.
- **Inspect for Damage:** Before installation, visually inspect the new switch for any signs of damage. Do not install a damaged component.
- **Proper Tools:** Use appropriate insulated tools for electrical work.

3. Product Overview

The De'Longhi SR-06 is a genuine replacement rocker switch designed for various De'Longhi fryer models. It features two contacts and is rated for specific electrical loads to ensure safe and reliable operation within compatible appliances.



Image 1: The De'Longhi SR-06 fryer switch. This image displays the compact black rocker switch with its two electrical terminals visible on the side, indicating its design for integration into appliance control panels.

4. Installation Instructions

Follow these steps carefully to replace the SR-06 fryer switch:

1. **Prepare the Fryer:** Ensure the fryer is unplugged from the wall outlet. Allow it to cool completely if it has been in use.
2. **Access the Switch:** Depending on your specific fryer model, you may need to remove screws or panels to access the existing switch. Refer to your fryer's original service manual if available.
3. **Identify Wiring:** Carefully note or photograph the wiring connections to the old switch. There are typically two wires connected to the switch terminals.
4. **Remove Old Switch:** Disconnect the wires from the old switch. The switch may be held in place by clips or a friction fit. Gently pry it out if necessary.
5. **Install New Switch:** Insert the new De'Longhi SR-06 switch into the opening. Ensure it clicks securely into place.
6. **Connect Wiring:** Reconnect the wires to the new switch terminals exactly as they were connected to the old switch. Ensure connections are firm and secure.
7. **Reassemble Fryer:** Replace any panels or screws that were removed.
8. **Test Functionality:** Plug the fryer back into the power outlet and test the switch functionality. Ensure the fryer powers on and off correctly.

5. Operation

The SR-06 switch functions as a simple ON/OFF control for your De'Longhi fryer. Press one side of the rocker to turn the appliance ON, and the other side to turn it OFF. The switch typically has markings (e.g., 'I' for ON, 'O' for OFF) to indicate its state.

6. Maintenance

The De'Longhi SR-06 switch requires minimal maintenance. Keep the exterior of the switch clean and free from grease or food debris. Use a soft, damp cloth for cleaning. Do not use abrasive cleaners or immerse the switch in water. Regular inspection for loose connections or physical damage is recommended.

7. Troubleshooting

- **Switch Not Responding:** Ensure the fryer is properly plugged in and receiving power. Check for loose wiring

connections to the switch. If the switch still does not respond, it may be faulty and require replacement.

- **Intermittent Power:** This could indicate a loose connection or a failing switch. Recheck wiring or consider replacing the switch.
- **Visible Damage:** If the switch shows signs of burning, melting, or physical damage, it must be replaced immediately.

If troubleshooting steps do not resolve the issue, consult a qualified appliance repair technician.

8. Specifications

Feature	Specification
Model	SR-06
Contacts	2
Voltage/Current Ratings	8A 250VAC, 16A 125VAC, 13A 250VAC, 6(6)A 250VAC, 10(3)A 250VAC, 16A GP 125VAC
Temperature Rating	T85µ, T100
Dimensions (Approx.)	1.5 x 2 x 2 cm
Weight (Approx.)	40 g

9. Compatible De'Longhi Fryer Models

The SR-06 switch is compatible with a wide range of De'Longhi fryer models. To verify compatibility, locate the identification plate on your appliance, usually found on the underside. Cross-reference your model number with the list below. This list is not exhaustive, but includes many common compatible models:

330715, 330715T, 330920, 331020T, 331220, BQ100, CP20, CP20B, CS230TP, CS230TP EX:1, D14D, D15D, D16D, D20D, D28533.UX, D41, D44, D45, D881C, D882-UX, D895C, D895U, D895UX, D895-UX, D895-UX.BK, D986U, D996C, D999U, EVT5000, F026, F026SG, F026Y, F027, F076, F076 GG, F076SG, F076Y, F077, F077AG, F077SG, F077Y, F1000, F1000.W, F1000EC, F126, F16231, F16233, F17221, F17221 EX:A, F17223, F1723 EX:A, F17231, F17233, F17233 EX:A, F17300, F17300 EX:A, F17301, F17301 EX:A, F17303, F17303 EX:A, F17311, F17311 EX:A, F17331, F17431, F17431 EX:A, F17433, F17433 EX:A, F176, F18231, F18233, F18304, F18311, F18316, F18433, F18436, F220, F260, F260.115V, F260 EX:V, F260-E9, F260Y, F261, F270, F270 EX:V, F270E9, F27201 EX:1, F28211 EX:1, F28211.W1 EX:1, F28233, F28311 EX:1, F28311.W1 EX:1, F28313.BK, F28313.W1, F28533, F28533.BK, F28533.W1, F330, F336, F350, F350.WA, F356, F3823, F38436, F760, F760 E9, F760 EX:V, F760Y, F761, F770, F770 AG, F770 EX:V, F770Y, F818, F870, F871V, F874, F880, F880.WO, F883, F884, F885, F885.SO, F885V, F885V R.47647, F885V R.47648, F885V R.47649, F885V Y R.47649, F885V.AG R.47648, F885VB, F885Y, F887, F890, F890.WA, F890AG R.4133101, F890SG, F891, F894, F895, F895.SP, F895.WP, F895SG, F912, F956V, F9800, F980B, F981, F986, F988, F988.Y, F989, F989.WA, F995, F996, F996.WA, F997, F999, F999.Y, FAR, FBR, FBS, FCR, FEC, FECW, FP EX:B, FP.T., FP.T EX:B, FP100, FP100A, FP103A, FP103A.Y, FPA EX:B, FPA EX:BV, FPA-E9 EX:0, FPAEC E9, FPAY, FP-E9, FPEC, FPECEX:BV, FPECY, FPX, FPXEC, FQC, FQE, FQS, FQT, FRM MW, FRP, FRPS, FRX, FST, FSX, FTO, FTOW, FTS, G128TP, GN130TP, GN130TP EX:1, HPT02, HPV2, HPVT, IC4000, IC4000SK, IC5000, IC6000, IC6000S, KF1.

10. Support and Warranty

For technical support or inquiries regarding your De'Longhi SR-06 fryer switch, please contact De'Longhi customer service or an authorized service center. Information regarding warranty coverage for replacement parts can typically be found on the original product packaging or by contacting the seller. Always retain your proof of purchase for warranty claims.

© 2023 De'Longhi. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JW6ZXP5

More documents and user manuals: **https://manuals.plus/**