Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hitachi R-W660PS7 GGR

Hitachi Refrigerator User Manual

Model: R-W660PS7 GGR

1. Introduction

Thank you for choosing the Hitachi R-W660PS7 GGR Refrigerator. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before using the refrigerator and keep it for future reference.



Figure 1.1: Front view of the Hitachi R-W660PS7 GGR 4-door side-by-side refrigerator in black finish.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the refrigerator is properly grounded.
- Do not damage the refrigerant circuit.
- Keep ventilation openings clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

- Unplug the appliance before cleaning or performing any maintenance.

3. Setup and Installation

Proper installation is crucial for the performance and longevity of your refrigerator.

3.1 Unpacking

Carefully remove all packaging materials. Inspect the refrigerator for any shipping damage. Report any damage to your retailer immediately.

3.2 Placement

Place the refrigerator on a firm, level floor. Ensure adequate clearance around the unit for proper ventilation. Avoid direct sunlight or heat sources.



Figure 3.1: Side view of the refrigerator, illustrating the depth and need for proper clearance.

3.3 Electrical Connection

Connect the refrigerator to a dedicated, grounded electrical outlet. Do not use extension cords or adapter plugs.

3.4 Professional Installation

For installations in Riyadh, Jeddah, and Dammam, please contact the Al Yasa customer service center at8001240020 for professional assistance.

4. Operating Instructions

Familiarize yourself with the controls and features of your Hitachi refrigerator.

4.1 Initial Startup

After plugging in, allow the refrigerator to run for several hours (at least 4-6 hours) before loading it with food. This allows the internal temperature to stabilize.

4.2 Temperature Control

The refrigerator features intuitive temperature controls. Refer to the control panel for specific settings. Recommended temperatures are typically 3-5°C (37-41°F) for the refrigerator compartment and -18°C (0°F) for the freezer compartment.



Figure 4.1: Interior view showing the spacious compartments, shelves, and drawers for fresh food and freezer storage.

4.3 Water Dispenser

The refrigerator is equipped with a water dispenser. Ensure the water tank is filled for operation. For first-time use, dispense a few liters of water to flush the system.



Figure 4.2: Close-up of the internal water dispenser reservoir, indicating the fill level.

4.4 Automatic Defrost

This model features an automatic defrost system, eliminating the need for manual defrosting of the freezer compartment.

5. Maintenance and Cleaning

Regular cleaning and maintenance will help keep your refrigerator operating efficiently.

5.1 Interior Cleaning

Clean the interior regularly with a mild detergent and warm water. Wipe dry with a soft cloth. Remove shelves and drawers for thorough cleaning as needed.

5.2 Exterior Cleaning

Wipe the exterior surfaces with a soft, damp cloth. For stainless steel surfaces, use a specialized stainless steel cleaner. Avoid abrasive cleaners.

5.3 Door Gaskets

Clean door gaskets regularly to ensure a tight seal. A loose seal can lead to increased energy consumption and frost buildup.

6. Troubleshooting

Before contacting service, refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Refrigerator not cooling	Power outage; thermostat set too high; door not closed properly; excessive food load.	Check power supply; adjust thermostat; ensure door is sealed; reduce food load.
Unusual noises	Refrigerator not level; items vibrating inside; normal operating sounds (e.g., refrigerant flow).	Level the refrigerator; rearrange items; these sounds are normal.
Water dispenser not working	Water tank empty; water line kinked or blocked.	Refill water tank; check water line for obstructions.

7. Specifications

Detailed specifications for the Hitachi R-W660PS7 GGR Refrigerator.

Feature	Value
Brand Name	Hitachi
Model Information	R-W660PS7 GGR
Product Dimensions (LxWxH)	73 x 85 x 184 cm
Item Weight	95 Kilograms
Capacity	550 Liters
Annual Energy Consumption	370.8 kWh per year
Fresh Food Capacity (Refrigerator)	396 Liters
Freezer Capacity	144 Liters
Installation Type	Freestanding
Form Factor	Side-by-Side
Color	Black
Number of Vegetable Drawers/Drawers	4
Defrost Type	Automatic
Door Hinges	Left
Door Material Type	Stainless Steel
Number of Shelves	4
Certification	CE

Feature	Value
Included Components	No
Batteries Required?	No
First Available Date	September 24, 2020

8. Warranty and Support

Your Hitachi refrigerator comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions.

8.1 Extended Protection Plans

Extended protection plans are available for purchase to provide additional coverage beyond the standard manufacturer's warranty. These plans may cover accidental damage and extended service periods.

- **1-Year Extended Warranty:** Provides an additional year of coverage.
- **1-Year Accidental Damage Protection Plan:** Covers accidental damage for one year for major appliances (SAR 4000 to SAR 4499.99).
- **2-Year Accidental Damage Protection Plan:** Covers accidental damage for two years for major appliances (SAR 4000 to SAR 4499.99).

For details on purchasing these plans, please check the product page or contact your retailer.

8.2 Customer Service

For any inquiries, technical support, or service requests, please contact Hitachi customer service or the authorized service center in your region. For installations in Riyadh, Jeddah, and Dammam, contact Al Yasa customer service center at 8001240020.

© 2023 Hitachi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JZBXC4W

More documents and user manuals: **https://manuals.plus/**