Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nokia E3500

Nokia E3500 True Wireless Earbuds User Manual

Model: E3500 (8P00000115)

1. Product Overview

The Nokia E3500 True Wireless Earbuds are designed to provide a superior audio experience with clear sound and reliable connectivity. Featuring Bluetooth 5.0, Clear Voice Capture (CVC) technology, and a dynamic driver, these earbuds are suitable for both music listening and calls.

The earbuds are lightweight and designed for comfort, offering up to 7 hours of non-stop playtime, extended to 25 hours with the included charging case. They also feature an ambient mode for situational awareness and are water-resistant for everyday use.

2. Package Contents

Please ensure all items are present in the package:

- Nokia E3500 True Wireless Earbuds (Left and Right)
- Nokia E3500 Charging Case
- USB Charging Cable
- Multiple sizes of ear tips for optimal fit



Image: Nokia E3500 True Wireless Earbuds in their charging case.

3. Setup and First Use

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB cable to the charging port on the case and to a power source. The indicator lights on the case will show the charging status. A full charge provides up to 7 hours of playtime for the earbuds, with the case offering approximately three additional charges for a total of up to 25 hours.



Image: Top view of the Nokia E3500 charging case, showing the USB charging port.

3.2 Pairing with a Device

1. Ensure the earbuds are charged and placed in the charging case.
2. Open the charging case lid. The earbuds will automatically enter pairing mode, indicated by a flashing light on the earbuds.
3. On your device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Select "Nokia E3500" from the list of available devices.
5. Once connected, the indicator light on the earbuds will stop flashing.

The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.



Image: Side view of the Nokia E3500 earbuds, showing their design and fit.

4. Operating the Earbuds

4.1 Touch Controls

The Nokia E3500 earbuds feature intuitive touch controls on each earbud for managing playback, calls, and activating voice assistants. Specific gestures (e.g., single tap, double tap, long press) correspond to different functions. Refer to the quick start guide included in your package for a detailed list of touch commands.

4.2 Audio Features

- **Clear Voice Capture (CVC) Technology:** Utilizes four microphones to reduce background noise during calls, ensuring clear communication.
- **Dynamic 10mm Driver:** Amplifies low frequencies and produces a soft mid-high range for a rich sound experience.

- **Qualcomm aptX Technology:** Provides consistent, high-quality audio with low latency, ideal for music and video playback.
- **Ambient Mode:** Allows you to hear your surroundings clearly without removing the earbuds, useful for conversations or being aware of your environment.



Image: Top view of the Nokia E3500 earbuds placed in their charging case.

5. Maintenance and Care

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Ear Tips:** Remove and clean the ear tips periodically. Ensure they are completely dry before reattaching them to the earbuds.
- **Water Resistance:** The Nokia E3500 earbuds are water-resistant (IPX5 rated). This means they can withstand splashes of water and light rain, but they are not designed for submersion in water. Avoid exposing them to excessive moisture or liquids.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.



Image: Nokia E3500 earbuds and charging case, illustrating their lightweight design (5g per earbud, 32g for case).

6. Troubleshooting

If you encounter issues with your Nokia E3500 earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Place them in the case, close the lid, then open it again to re-enter pairing mode. Check your device's Bluetooth settings and try forgetting/re-pairing the device.
No sound or low volume	Check the volume level on both your device and the earbuds. Ensure earbuds are properly seated in your ears. Clean any debris from the earbud grilles.
Charging issues	Verify the USB cable and power source are working. Ensure the charging contacts on the earbuds and inside the case are clean and free of obstruction.
Intermittent connection	Move closer to your paired device. Avoid environments with strong Wi-Fi or other wireless interference. Try resetting the earbuds (refer to manufacturer's website for specific reset instructions).

If the problem persists, please refer to the support section for further assistance.

7. Specifications

Feature	Detail
Model Name	Nokia E3500
Item Model Number	8P00000115
Connectivity Technology	Wireless (Bluetooth 5.0)
Headphones Jack	USB (for charging case)
Item Weight	44 Grams (total package)
Earbud Weight	Approx. 5 Grams per earbud
Water Resistance Level	Water Resistant (IPX5)
Battery Type	Lithium Polymer (included)
Playtime (Earbuds)	Up to 7 hours
Total Playtime (with Case)	Up to 25 hours
Impedance	16 Ohm

Feature	Detail
Noise Control	Sound Isolation
Material Type	Faux Leather

8. Warranty and Support

For detailed warranty information and terms of service, please refer to the documentation provided with your purchase or visit the official Nokia audio product support website. This manual provides general operational guidelines.

If you require technical support, have questions about product functionality, or need to report an issue, please contact Nokia customer service through their official channels. Contact information can typically be found on the product packaging or the official Nokia support website.

© 2024 Nokia. All rights reserved. Nokia and the Nokia logo are trademarks of Nokia Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08JZC2KTP

More documents and user manuals: **https://manuals.plus/**