VINABTY Jadoo 5 5S

VINABTY Replacement Remote Control User Manual

Compatible with Jadoo 5 and Jadoo 5S

1. INTRODUCTION

This manual provides detailed instructions for the VINABTY replacement remote control, designed for seamless compatibility with Jadoo 5 and Jadoo 5S devices. Please read this manual carefully before using the remote control to ensure proper operation and to maximize your viewing experience.

2. PRODUCT OVERVIEW

Figure 1: VINABTY Replacement Remote Control. This image displays the full layout of the black remote control, featuring various buttons for power, volume, navigation, playback, and numeric input.

The VINABTY replacement remote control is an infrared (IR) remote designed to replicate the functionality of the original remote for Jadoo 5 and Jadoo 5S set-top boxes. It features a standard button layout for easy navigation and control of your device.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.

3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

4. OPERATING INSTRUCTIONS

This remote control operates via infrared (IR) technology. Ensure there is a clear line of sight between the remote and your Jadoo 5 or Jadoo 5S device for optimal performance.

4.1 Button Functions

- **Power ( ):** Turns the Jadoo device on or off.
- **Mute ( ):** Mutes or unmutes the audio.
- **Volume Up/Down (/):** Adjusts the audio volume.
- **Channel Up/Down (▲ / ▼):** Navigates through channels or menu items.
- **Navigation Pad (Up, Down, Left, Right arrows):** Moves the cursor or selection within menus.
- **OK:** Confirms a selection or enters a menu item.
- **Home ( ):** Returns to the main home screen.
- **Back/Return (↶):** Goes back to the previous screen or menu.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop):** Controls media playback.
- **Numeric Keypad (0-9):** Directly enters channel numbers or other numerical inputs.
- **Colored Buttons (Red, Green, Yellow, Blue):** These buttons typically correspond to specific functions displayed on-screen within applications or menus.
- **Menu (≣):** Opens the main menu or context-sensitive options.
- **Mouse/Cursor ( ):** Activates or deactivates an on-screen cursor for navigation.
- **Star ( ):** Often used for favorites or custom functions.
- **Refresh/Loop (↻):** May refresh content or loop playback.
- **Info (i):** Displays information about the current program or selected item.
- **Search:** Opens a search interface.
- **Guide:** Accesses the electronic program guide (EPG).
- **Time Seek:** Used for navigating within a timeline or seeking specific times in media.

5. MAINTENANCE

5.1 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these may damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Follow the battery installation steps in Section 3.1. Dispose of used batteries responsibly according to local regulations.

6. TROUBLESHOOTING

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with fresh AAA batteries.
  - Ensure there are no obstructions between the remote control and the Jadoo device's IR receiver.
  - Make sure you are within the effective range of the remote control (typically up to 20 feet).

- **Buttons are sticky or unresponsive:**
  - Clean the remote control as described in Section 5.1.

7. SPECIFICATIONS

- **Brand:** VINABTY
- **Model Compatibility:** Jadoo 5, Jadoo 5S
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 2 x AAA batteries (required)
- **Product Dimensions:** 6.9 x 2 x 0.7 inches (approximately)
- **Item Weight:** 2.1 ounces (approximately, without batteries)
- **Max Number of Supported Devices:** 1
- **Compatible Devices:** Set Top Box

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the VINABTY customer service directly. Keep your purchase receipt as proof of purchase.