Hitachi ALR0564

Astemo ALR0564 Voltage Regulator Instruction Manual

Model: ALR0564

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your Astemo ALR0564 Voltage Regulator. Please read this manual thoroughly before installation and retain it for future reference. The Astemo ALR0564 Voltage Regulator is designed to control the voltage output from your vehicle's alternator, ensuring a stable electrical supply and protecting sensitive electronic components.

2. Safety Information

WARNING: Improper installation or handling of electrical components can result in serious injury or damage to the vehicle. Always disconnect the vehicle's battery before performing any electrical work.

- Always wear appropriate personal protective equipment (PPE), such as safety glasses and gloves.
- Ensure the vehicle's ignition is off and the battery is disconnected before beginning installation.
- Consult a qualified automotive technician if you are unsure about any installation steps.
- Do not attempt to modify the voltage regulator.
- Keep away from open flames and sources of extreme heat.

3. Product Overview

The Astemo ALR0564 is a high-quality voltage regulator designed for automotive alternators. It ensures that the alternator produces a consistent and safe voltage level for the vehicle's electrical system and battery charging.




Figure 1: Astemo ALR0564 Voltage Regulator. This image shows the compact design of the voltage regulator, highlighting its electrical terminals and mounting points. The main body is metallic with a black plastic cover on top, and white plastic components for the terminals.

Key Features:

- Precise voltage control for optimal battery charging.
- Protects vehicle electronics from voltage fluctuations.
- Constructed with high-quality materials for durability.
- Meets OE performance standards.

4. Installation Instructions

The Astemo ALR0564 Voltage Regulator is an internal component of the alternator. Installation typically involves disassembling the alternator. Due to the complexity and specific vehicle requirements, professional installation is highly recommended.

4.1. Tools and Materials Required

- Socket set and wrenches
- Screwdrivers (Phillips and flathead)

- Multimeter (for testing)
- Battery terminal wrench
- Personal Protective Equipment (PPE)

4.2. General Installation Steps (Consult Vehicle Service Manual for Specifics)

1. **Disconnect Battery:** Locate the vehicle's battery and disconnect the negative (-) terminal first, followed by the positive (+) terminal.
2. **Access Alternator:** Depending on the vehicle, this may involve removing other components to gain access to the alternator.
3. **Remove Alternator:** Disconnect all wiring from the alternator and remove any mounting bolts. Carefully remove the alternator from the vehicle.
4. **Disassemble Alternator:** Follow the vehicle-specific service manual to safely disassemble the alternator housing to access the internal voltage regulator.
5. **Remove Old Regulator:** Carefully disconnect and remove the old voltage regulator. Note its orientation and connections.
6. **Install New Regulator:** Install the Astemo ALR0564 Voltage Regulator in the same orientation as the old one, ensuring all connections are secure.
7. **Reassemble Alternator:** Reassemble the alternator housing, ensuring all components are correctly seated and fasteners are tightened to specifications.
8. **Reinstall Alternator:** Mount the alternator back into the vehicle, reconnect all wiring, and tighten mounting bolts.
9. **Reconnect Battery:** Reconnect the positive (+) battery terminal first, then the negative (-) terminal.
10. **Test System:** Start the vehicle and check the charging system voltage with a multimeter to ensure proper operation (typically 13.5V - 14.8V).

5. Operation

Once correctly installed, the Astemo ALR0564 Voltage Regulator operates automatically as part of the vehicle's charging system. It continuously monitors the electrical system voltage and adjusts the alternator's output to maintain a stable voltage, typically between 13.5 and 14.8 volts, depending on the vehicle and operating conditions. This ensures the battery is properly charged and all electrical components receive the correct voltage.

6. Maintenance

The Astemo ALR0564 Voltage Regulator is a sealed unit and requires no routine maintenance. However, regular inspection of the vehicle's entire charging system is recommended to ensure optimal performance and longevity of all components, including the voltage regulator.

- Periodically check battery terminals for corrosion and ensure they are clean and tight.
- Inspect alternator drive belt for proper tension and wear.
- Monitor the vehicle's dashboard warning lights for any indications of charging system issues.
- If charging system issues arise, have the system diagnosed by a qualified technician.

7. Troubleshooting

If you experience issues with your vehicle's charging system after installing the Astemo ALR0564 Voltage Regulator, consider the following common problems and solutions:

- **Problem: Battery not charging or low voltage.**

- **Possible Cause:** Loose or corroded battery terminals.
- **Solution:** Clean and tighten battery terminals.
- **Possible Cause:** Faulty alternator drive belt.
- **Solution:** Inspect and replace the belt if worn or loose.
- **Possible Cause:** Incorrect wiring connections to the alternator/regulator.
- **Solution:** Double-check all electrical connections according to the vehicle's service manual.
- **Possible Cause:** Faulty alternator (beyond the regulator).
- **Solution:** Test the alternator's output.

- **Problem: Overcharging (high voltage).**
  - **Possible Cause:** Faulty voltage regulator.
  - **Solution:** If all other components are confirmed good, the regulator may need replacement.

- **Problem: Dashboard battery light illuminated.**
  - **Possible Cause:** General charging system fault.
  - **Solution:** Have the charging system diagnosed by a professional using diagnostic tools.

If troubleshooting steps do not resolve the issue, it is recommended to seek assistance from a certified automotive technician.

8. Specifications

Feature	Specification
Brand	Hitachi (Astemo)
Model Number	ALR0564
Item Weight	5.6 ounces
Product Dimensions	4.5 x 3.5 x 3.25 inches
Manufacturer Part Number	ALR0564
OEM Part Number	9168496

9. Warranty and Support

For specific warranty information regarding your Astemo ALR0564 Voltage Regulator, please refer to the documentation provided at the time of purchase or contact your retailer. Astemo products are manufactured to high standards, and support is typically available through authorized distributors and service centers.
For technical assistance or further inquiries, please visit the official Hitachi Astemo website or contact their customer support.

© 2023 Hitachi Astemo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question