Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vieta Pro VM-BS46LB

Vieta Pro Goody 2 Bluetooth Speaker User Manual

Model: VM-BS46LB

1. Introduction

Thank you for choosing the Vieta Pro Goody 2 Bluetooth Speaker. This manual provides detailed instructions for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

Key Features:

- Bluetooth 5.0 for stable wireless connectivity.
- True Wireless function to connect two Goody 2 speakers for enhanced stereo sound.
- IPX7 water resistance, making it suitable for various environments.
- Integrated FM Radio for independent music listening.
- Built-in microphone for hands-free calling.
- Dedicated button for direct access to your virtual assistant.
- Up to 12 hours of battery life.
- Auxiliary input and USB port for versatile audio playback and power bank functionality.
- Dynamic lighting system with three different themes.
- 25W powerful audio output.

2. Package Contents

Please check the package for the following items:

- Vieta Pro Goody 2 Bluetooth Speaker
- 1 x Charging Cable (Type-C)
- User Manual (this document)



Image: The retail packaging for the Vieta Pro Goody 2 speaker, showing the product and its key features listed on the box.

3. Product Overview

Familiarize yourself with the speaker's components and controls.

3.1 Top Panel



Image: A close-up top view of the Vieta Pro Goody 2 speaker, highlighting the central button with the "VIETA PRO" logo.

- **VIETA PRO Button:** Short press to cycle through lighting themes. Long press to activate Voice Assistant.
- **LED Light Ring:** Indicates power status, charging, and active lighting themes.

3.2 Side Panel Controls and Ports



Image: Side view of the Vieta Pro Goody 2 speaker, displaying the control panel with buttons for power, volume, mode, and track control, along with LED indicators and a charging port.

- **Power Button:** Press and hold to power on/off.
- **Volume Up (+):** Increase volume.
- **Mode (M):** Switch between Bluetooth, FM Radio, and Aux-in modes.
- **Volume Down (-):** Decrease volume.
- **Play/Pause/Call Button:** Play/pause music, answer/end calls.
- **USB Port:** For USB drive playback or charging external devices (power bank function).
- **AUX-in Port:** For connecting external audio devices via a 3.5mm audio cable.
- **Type-C Charging Port:** For charging the speaker.

- **LED Indicators:** Show battery level and charging status.

4. Setup

4.1 Charging the Speaker

1. Connect the provided Type-C charging cable to the speaker's Type-C charging port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicators will show the charging status. A full charge typically takes approximately 3-4 hours.
4. Once fully charged, disconnect the charging cable.

Note: For optimal battery life, fully charge the speaker before first use.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button on the side panel for 2-3 seconds. You will hear an audible prompt, and the LED light ring will illuminate.
- **To Power Off:** Press and hold the Power button for 2-3 seconds. You will hear an audible prompt, and the LED light ring will turn off.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode. If not, press the **M** button to switch to Bluetooth mode. The LED light ring will flash, indicating it's ready for pairing.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select **"Vieta Pro Goody 2"** from the list.
4. Once connected, you will hear a confirmation sound, and the LED light ring will stop flashing and remain solid.

Note: The speaker will automatically attempt to reconnect to the last paired device when powered on.

4.4 True Wireless Stereo (TWS) Pairing

The TWS function allows you to connect two Vieta Pro Goody 2 speakers for a stereo sound experience.

1. Ensure both Goody 2 speakers are powered on and not connected to any Bluetooth device.
2. On one of the speakers (this will be the primary speaker), press and hold the **Play**/**Pause**/**Call** button for 3-5 seconds until you hear a pairing tone.
3. The two speakers will automatically search and pair with each other. Once connected, you will hear a confirmation sound.
4. Now, connect your Bluetooth device to the primary speaker as described in section 4.3. The audio will play in stereo through both speakers.

Note: TWS pairing only works with two identical Vieta Pro Goody 2 speakers.

4.5 Auxiliary Input (AUX-in)

1. Connect one end of a 3.5mm audio cable (not included) to the AUX-in port on the speaker.
2. Connect the other end to the audio output jack of your external device (e.g., MP3 player, computer).
3. Press the **M** button on the speaker to switch to AUX-in mode.
4. Control playback and volume from your external device.

4.6 USB Playback and Power Bank Function

1. **USB Playback:** Insert a USB flash drive containing audio files into the USB port. The speaker will automatically

switch to USB mode and begin playing.

2. **Power Bank:** Connect your smartphone or other USB-powered device to the speaker's USB port using a compatible charging cable. The speaker's battery will provide power to charge your device.

5. Operating Instructions

5.1 Music Playback (Bluetooth/USB/AUX-in)

- **Play/Pause:** Short press the **Play/Pause/Call** button.
- **Volume Up:** Short press the **+** button.
- **Volume Down:** Short press the **-** button.
- **Next Track:** Long press the **+** button.
- **Previous Track:** Long press the **-** button.

5.2 FM Radio

1. Press the **M** button to switch to FM Radio mode.
2. Long press the **Play/Pause/Call** button to automatically scan and save available FM stations.
3. Short press the **+** or **-** buttons to switch between saved stations.

Tip: For better FM reception, ensure the speaker is in an open area.

5.3 Hands-Free Calling

When connected via Bluetooth to your smartphone:

- **Answer Call:** Short press the **Play/Pause/Call** button.
- **End Call:** Short press the **Play/Pause/Call** button during a call.
- **Reject Call:** Long press the **Play/Pause/Call** button when an incoming call rings.

5.4 Voice Assistant

To activate your smartphone's voice assistant (e.g., Siri, Google Assistant):

- Ensure the speaker is connected to your smartphone via Bluetooth.
- **Long press** the **VIETA PRO** button on the top panel. Your device's voice assistant will activate, and you can speak your commands through the speaker's microphone.

5.5 Lighting System

The speaker features a dynamic LED light ring with three different themes.

- To cycle through the lighting themes, **short press** the **VIETA PRO** button on the top panel.
- To turn off the lighting, continue short pressing the button until the lights are off.

6. Maintenance

6.1 Water Resistance (IPX7)

The Vieta Pro Goody 2 speaker is rated IPX7, meaning it can be immersed in water up to 1 meter (3 feet) for up to 30 minutes. This makes it suitable for use by the pool, at the beach, or in the shower.

- Ensure all port covers are securely closed before exposing the speaker to water.

- Do not expose the speaker to saltwater or other chemicals, as this may damage the seals.
- After exposure to water, wipe the speaker dry with a soft cloth before charging or opening any port covers.
- Do not intentionally submerge the speaker for extended periods or beyond the specified depth.



Image: The Vieta Pro Goody 2 speaker partially submerged in water, demonstrating its IPX7 water resistance.

6.2 Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

6.3 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50% every few months to maintain battery health.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the provided Type-C cable.
Cannot connect via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in Bluetooth pairing mode (flashing LED). Turn on Bluetooth on your device. Move device closer to speaker (within 10 meters).
No sound.	Volume too low; incorrect mode selected; device not playing.	Increase speaker and device volume. Press **M** button to select correct mode (Bluetooth, AUX, USB). Ensure audio is playing on your source device.
FM Radio reception is poor.	Weak signal; interference.	Move the speaker to an open area, away from potential interference sources.
True Wireless (TWS) pairing fails.	Speakers already connected to another device; not in TWS pairing mode.	Ensure both speakers are disconnected from other devices. Follow TWS pairing instructions carefully (Section 4.4).

8. Specifications

Feature	Detail
Model Number	VM-BS46LB
Bluetooth Version	5.0
Output Power	25 Watts
Battery Life	Up to 12 hours
Water Resistance	IPX7
Connectivity	Bluetooth, AUX-in, USB
Special Features	True Wireless Stereo (TWS), FM Radio, Microphone, Voice Assistant, Lighting System, Power Bank Function
Dimensions (L x W x H)	19.1 x 7.4 x 7.4 cm
Weight	860 grams
Compatible Devices	Smartphones, Tablets, Computers

9. Warranty and Support

Vieta Pro products are designed and manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included with your product or visit the official Vieta Pro website. If you encounter any issues or require technical assistance, please contact Vieta Pro customer support through their official channels.
Please retain your proof of purchase for warranty claims.

© 2023 Vieta Pro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KGSKND7

More documents and user manuals: **https://manuals.plus/**