ONN 100009768

ONN 11" HD Display Portable Blu-Ray/DVD/CD Media Player User Manual

Model: 100009768

Introduction

This manual provides comprehensive instructions for the operation and maintenance of your ONN 11" HD Display Portable Blu-Ray/DVD/CD Media Player (Model 100009768). Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your viewing and listening experience. This portable player allows you to enjoy your favorite content from Blu-Ray discs, DVDs, CDs, and USB devices, offering versatile entertainment on the go.

Package Contents

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

- ONN 11" HD Display Portable Blu-Ray/DVD/CD Media Player
- Remote Control (requires 2 AAA batteries, included)
- AC Power Adapter
- Car Power Adapter (DC 12V)
- Earphones



Image: The ONN portable Blu-Ray player displayed with its full set of accessories, including the remote control, AC power adapter, car power adapter, and earphones.

Product Features

- **11" High Resolution HD Display:** Provides clear and vibrant visuals for an immersive viewing experience.
- **Swivel Screen:** The display swivels 90 degrees to the right and 180 degrees to the left, allowing for flexible viewing angles.
- **Multi-Format Compatibility:** Supports BD, BD-R, BD-RE, DVD-R/RW, DVD+R/RW, DVD-VIDEO, VCD, CD, and CD-R/RW disc formats.
- **Advanced Audio Decoders:** Equipped with Dolby Digital, Dolby Digital Plus, and Dolby TrueHD decoders for high-quality audio output.

- **Multiple Connectivity Options:** Features 1 HDMI output port, 1 USB port, 1 Ethernet (LAN) port, and a 3.5mm earphone jack.
- **SD/MMC Card Reader:** Allows playback of media files directly from SD or MMC memory cards.

Controls and Connections

Familiarize yourself with the various controls and connection ports on your portable media player.



Image: The ONN portable Blu-Ray player with its screen open, showcasing the main control panel, disc tray, and integrated speakers.



Image: A detailed view of the right side of the player, highlighting the HDMI OUT, USB, LAN, DC IN 12V, AV IN, and SD/MMC card reader ports, along with the power switch and volume controls.

Front/Top Panel Controls:

- **Disc Tray:** For inserting Blu-Ray, DVD, or CD discs.
- **Control Pad:** Directional buttons (Up, Down, Left, Right) and Enter button for menu navigation.
- **Play/Pause Button:** Starts or pauses playback.
- **Stop Button:** Stops playback.
- **Skip Buttons:** Skips to the next or previous track/chapter.
- **SETUP Button:** Accesses the system settings menu.
- **VOL- / VOL+ Buttons:** Adjusts the volume level.
- **Speakers:** Integrated stereo speakers for audio output.

Side Panel Connections:

- **ON/OFF Switch:** Powers the device on or off.
- **AV IN Port:** For connecting external audio/video sources.
- **SD/MMC Card Reader:** Slot for inserting SD or MMC memory cards.

- **HDMI OUT Port:** Connects the player to an external display (e.g., TV, monitor) for high-definition video and audio output.
- **USB Port:** Connects USB storage devices for media playback.
- **LAN (Ethernet) Port:** For network connectivity (if supported by specific Blu-Ray features).
- **DC IN 12V Port:** Connects the AC power adapter or car power adapter.
- **3.5mm Earphone Jack:** For connecting headphones or external speakers.

Setup

1. Powering the Player

- **Using the AC Power Adapter:** Connect the AC power adapter to the DC IN 12V port on the player and plug the other end into a standard wall outlet.
- **Using the Car Power Adapter:** Connect the car power adapter to the DC IN 12V port on the player and plug the other end into your vehicle's 12V accessory socket.
- **Internal Battery:** The player has a built-in rechargeable battery. Ensure it is charged before portable use. The battery charges automatically when connected to either power adapter.

2. Remote Control Setup

Insert the two included AAA batteries into the remote control, observing the correct polarity (+/-) as indicated inside the battery compartment.

3. Connecting to an External Display (Optional)

To view content on a larger screen, connect an HDMI cable (not included) from the HDMI OUT port on the player to an HDMI input port on your television or monitor. Select the corresponding HDMI input on your external display.

Operating Instructions

1. Powering On/Off

Slide the ON/OFF switch on the side of the player to the "ON" position to power on. Slide it to "OFF" to power off.

2. Disc Playback

1. Gently open the disc tray cover.
2. Place a Blu-Ray, DVD, or CD disc onto the spindle with the label side facing up. Ensure the disc is seated correctly.
3. Close the disc tray cover firmly until it clicks.
4. The player will automatically detect the disc and begin playback or display the disc menu.
5. Use the control pad or remote control to navigate menus and control playback (Play, Pause, Stop, Skip).

3. USB/SD Card Playback

1. Insert a USB flash drive into the USB port or an SD/MMC card into the card reader slot.
2. The player should automatically detect the media and prompt you to select the content type (e.g., Video, Music, Photo).
3. Navigate through your files using the control pad or remote and press Enter to select and play.

4. Adjusting Volume and Screen

- Use the VOL- and VOL+ buttons on the player or remote control to adjust the audio volume.
- The screen can be swiveled to your desired viewing angle. Gently rotate the display up to 90 degrees right and 180

degrees left.

5. System Settings (SETUP Menu)

Press the SETUP button on the player or remote control to access the system settings. Here you can configure various options such as display settings, audio settings, language preferences, and parental controls. Use the navigation buttons to select options and the Enter button to confirm.

Maintenance

- **Cleaning the Player:** Use a soft, dry cloth to wipe the exterior of the player. For the screen, use a soft, lint-free cloth specifically designed for electronics displays. Do not use liquid cleaners or abrasive materials.
- **Disc Care:** Handle discs by their edges. Keep discs clean and free of scratches. Store discs in their cases when not in use.
- **Battery Care:** If the player will not be used for an extended period, it is recommended to fully charge the internal battery before storage. For the remote control, remove the AAA batteries if not used for a long time to prevent leakage.
- **Storage:** Store the player in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter issues with your player, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Player does not power on.	Ensure the power adapter is securely connected to the player and the power outlet. Check if the ON/OFF switch is in the "ON" position. The internal battery may be depleted. Connect the player to power and allow it to charge.
Disc does not play / "Lid Open" error.	Ensure the disc tray cover is fully closed and latched. Check if the disc is inserted correctly with the label side facing up. The disc may be dirty or scratched. Clean the disc with a soft, lint-free cloth. Ensure the disc format is compatible with the player (Blu-Ray, DVD, CD).
No sound.	Increase the volume using the VOL+ button. Check if the player is muted. If using earphones, ensure they are fully plugged into the 3.5mm jack. If connected to an external display, check the volume settings on the display.
No picture on external display.	Ensure the HDMI cable is securely connected to both the player and the external display. Verify that the correct HDMI input is selected on your external display. Try a different HDMI cable.
Remote control not working.	Ensure the batteries are inserted correctly with the correct polarity. Replace the batteries if they are old or depleted. Ensure there are no obstructions between the remote and the player's IR sensor.

Specifications

Feature	Detail
Brand	ONN
Model Number	100009768
Screen Size	11 Inches (28 cm visible diagonal)
Display Type	LCD
Compatible Media Types	Blu-Ray, DVD, CD, VCD
Connectivity	HDMI Out, USB, Ethernet (LAN), 3.5mm Earphone, AV In, SD/MMC Card Reader, DC In 12V
Audio Decoders	Dolby Digital, Dolby Digital Plus, Dolby TrueHD
Color	Black
Item Weight	3.87 pounds
Package Dimensions	13.15 x 9.53 x 4.57 inches
Batteries (Remote)	2 AAA batteries (included)

Warranty and Support

For detailed warranty information and customer support, please refer to the warranty card included with your product packaging or visit the official ONN website. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance or technical support, please contact ONN customer service through the contact information provided on their official website.

© 2025 ONN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question