ONN 100008691

User Manual: ONN 10" Portable DVD and Media Player

Model: 100008691

Brand: ONN

Introduction

Thank you for choosing the ONN 10-inch Portable DVD and Media Player. This device is designed to provide versatile entertainment on the go, featuring a vibrant 10-inch screen with 180-degree swivel functionality, a long-lasting battery, and multiple media playback options. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and enjoyment of your player.

Package Contents

Please verify that all items listed below are included in your package:

- ONN 10-inch Portable DVD Player
- Remote Control
- AC Power Adapter
- Car Charger
- Headphones
- AV Cable

Product Overview

Front View



Figure 1: The ONN 10-inch Portable DVD Player in its open position, displaying the screen, disc compartment, and main control buttons.

Swivel Screen Functionality



Figure 2: The player's screen can swivel 180 degrees and fold flat against the base, allowing for a compact, tablet-like viewing experience.

Control Panel



Figure 3: A detailed view of the control panel, featuring buttons for power, playback (play/pause, stop, fast forward/rewind), navigation, and volume adjustment.

Ports and Connections



Figure 4: The side of the player, highlighting the USB port, SD card slot, 3.5mm auxiliary jack, AV-out, AV-in, and DC-in power input.

Included Accessories



Figure 5: The portable DVD player shown with all standard accessories, including the remote control, power adapters, headphones, and AV cable.

Setup

Charging the Battery

Before first use, fully charge the player's internal battery. Connect the AC power adapter to the DC-in port on the player and plug it into a standard wall outlet. The charging indicator light will illuminate. A full charge provides up to 5 hours of playback time. You can also use the included car charger for charging in a vehicle.

Inserting a DVD/CD

1. Gently open the disc compartment cover.
2. Place the DVD or CD onto the spindle with the label side facing up. Ensure the disc is securely seated.
3. Close the disc compartment cover firmly until it clicks into place.

Connecting External Devices

- **USB Drive:** Insert a USB flash drive into the USB port to play compatible media files (JPEG, MP3).
- **SD Card:** Insert an SD card into the SD card slot to play compatible media files (JPEG, MP3).
- **Headphones:** Plug the included headphones or any standard 3.5mm headphones into the headphone jack for private listening.
- **External Display (AV-OUT):** Use the AV cable to connect the player's AV-out port to a TV or monitor for larger screen viewing.
- **External Source (AV-IN):** Use the AV cable to connect an external video source (e.g., game console) to the player's AV-in port to use the player's screen as a display.

Operating Instructions

Basic Playback

1. Press the **POWER** button to turn on the player.
2. Insert a DVD/CD or connect a USB drive/SD card. The player will typically begin playback automatically.
3. Use the **PLAY/PAUSE** button to pause or resume playback.
4. Use the **STOP** button to stop playback.
5. Use the **SKIP** buttons (*Previous/Next*) to navigate between tracks or chapters.
6. Use the **VOLUME +/-** buttons to adjust the sound level.

Using USB/SD Card

After inserting a USB drive or SD card, the player's menu will allow you to select the media source. Navigate through your files using the directional buttons and press **OK** to select and play content. Supported formats include JPEG for images and MP3 for audio.

Adjusting Settings

Press the **MENU** button to access the player's settings. Use the directional buttons to navigate through options such as display settings, audio settings, and general preferences. Press **OK** to confirm selections and **MENU** again to exit.

Swivel Screen Functionality

The 10-inch LCD screen can swivel up to 180 degrees horizontally and fold flat against the base, allowing for multiple viewing angles and compact storage. Gently rotate the screen to your desired position. Ensure not to force the screen beyond its intended range of motion.

Maintenance

Proper care and maintenance will extend the life of your portable DVD player.

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics. Avoid harsh chemicals.
- **Cleaning the Disc Compartment:** Periodically inspect the disc compartment for dust or debris. Use a soft brush or compressed air to clean. Do not touch the laser lens.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. If storing the player for an extended period, charge it to about 50% and recharge every few months.
- **Storage:** Store the player in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.

Troubleshooting

If you encounter issues with your player, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Player does not turn on	Low battery or no power connection	Connect the AC adapter and ensure it's plugged into a working outlet. Allow the battery to charge.
Disc does not play	Disc inserted incorrectly, dirty/scratched disc, unsupported disc format	Ensure the disc is inserted correctly (label side up). Clean the disc with a soft cloth. Verify the disc format is supported (DVD+R, RW, CD-R, RW).
No sound	Volume too low, headphones not fully plugged in, audio settings	Increase the volume. Ensure headphones are fully inserted. Check audio settings in the player's menu.
Poor picture quality	Dirty screen, dirty/damaged disc	Clean the screen. Clean or try a different disc.
USB/SD card not recognized	Improperly inserted, unsupported file format, corrupted media	Ensure the USB drive/SD card is fully inserted. Verify files are in supported formats (JPEG, MP3). Try a different USB drive/SD card.

Specifications

Feature	Detail
Brand	ONN
Model Number	100008691
Screen Size	10 Inches (26 cm diagonal)
Display Type	LCD
Color	Black
Compatible Media Types	DVD+R, RW, CD-R, RW, JPEG, MP3
Connectivity	USB port, SD card reader, 3.5mm Aux jack, AV-out, AV-in, DC-in
Battery Life	Up to 5 hours
Item Weight	3.58 pounds
Package Dimensions	12.4 x 12.32 x 3.86 inches

Warranty and Support

For specific warranty information and support, please refer to the documentation provided at the time of purchase or contact the retailer/manufacturer directly. As a renewed product, it may be subject to specific return policies, such as the 90-day return policy offered by Amazon Renewed. Please retain your proof of purchase for any warranty claims or support inquiries.

© 2025 ONN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question