Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

S-link 33198

S-link IP-217W 10000mAh Wireless Power Bank User Manual

Model: IP-217W (33198)

1. Introduction

Thank you for choosing the S-link IP-217W 10000mAh Wireless Power Bank. This portable battery charger is designed to provide convenient power for your mobile devices, featuring both wired (dual USB ports) and wireless charging capabilities, along with a digital display for battery status.
Please read this manual carefully before using the product to ensure safe and optimal performance. Keep this manual for future reference.

2. Product Overview

The S-link IP-217W power bank is equipped with a 10000mAh Lithium-Polymer battery, offering reliable power on the go. It features two USB output ports, a wireless charging pad, and a digital display to show the remaining battery percentage.



Figure 1: S-link IP-217W Power Bank in use, demonstrating wireless charging with a smartphone. The power bank features a sleek black design with visible USB ports on the side.

Key Components:

- **Wireless Charging Pad:** Located on the top surface for compatible devices.
- **USB Output Ports (x2):** For wired charging of devices.
- **Digital Display:** Shows battery percentage and charging status.
- **Power Button:** Activates the display and initiates wireless charging.
- **Input Port (Micro USB/Type-C):** For recharging the power bank.



Figure 2: The S-link IP-217W Power Bank shown in its retail packaging, highlighting its 10000mAh capacity, wireless charging feature, and dual USB/Type-C/Micro USB connectivity.

3. Setup

Before first use, it is recommended to fully charge your S-link IP-217W Power Bank.

1. Connect the power bank to a USB wall adapter (not included) using a compatible Micro USB or USB-C cable.
2. The digital display will show the charging progress, indicating the battery percentage increasing.
3. Once the display shows "100%", the power bank is fully charged and ready for use. Disconnect it from the

power source.

4. Operating Instructions

4.1 Charging Devices via USB Cable

1. Connect one end of your device's USB charging cable to one of the power bank's USB output ports.
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The digital display will illuminate to show the remaining battery percentage.
4. To stop charging, simply disconnect your device.

4.2 Charging Devices Wirelessly

Ensure your device supports Qi wireless charging.

1. Press the power button on the power bank to activate the wireless charging function. The digital display will light up.
2. Place your Qi-compatible device directly onto the wireless charging pad on the top surface of the power bank.
3. Ensure the device is centered on the charging pad for optimal contact. The power bank's display may indicate wireless charging activity, and your device should show that it is charging.
4. If charging does not start, adjust the position of your device on the pad. Some phone cases may interfere with wireless charging; try removing the case if you encounter issues.
5. To stop charging, simply remove your device from the charging pad.

4.3 Recharging the Power Bank

When the digital display shows a low battery percentage, it's time to recharge the power bank.

1. Connect a Micro USB or USB-C cable to the corresponding input port on the power bank.
2. Connect the other end of the cable to a USB wall adapter (5V/2A recommended) or a computer's USB port.
3. The digital display will show the battery percentage increasing as it charges.
4. Once the display shows "100%", the power bank is fully charged. Disconnect the cable.

5. Maintenance

- Keep the power bank dry. Do not expose it to moisture or liquids.
- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the power bank to strong impacts.
- If the power bank will not be used for an extended period, charge it to approximately 50-70% every three months to maintain battery health.

6. Troubleshooting

Problem	Possible Cause / Solution

Problem	Possible Cause / Solution
Power bank not charging device.	Ensure the power bank has sufficient charge. Check if the charging cable is securely connected to both the power bank and the device. Try a different USB cable or a different USB port on the power bank. Ensure your device is compatible with the power bank's output.
Wireless charging not working.	Ensure your device supports Qi wireless charging. Press the power button on the power bank to activate wireless charging. Make sure your device is centered correctly on the wireless charging pad. Remove any thick or metallic phone cases that might interfere with wireless charging.
Power bank not recharging.	Check if the input cable is securely connected to the power bank and the power source. Try a different charging cable or a different wall adapter. Ensure the wall adapter provides sufficient power (e.g., 5V/2A).
Digital display not working.	Press the power button to activate the display. If the power bank is completely depleted, the display may not light up until it receives some charge.

7. Specifications

Model Number:	IP-217W (33198)
Brand:	S-link
Battery Capacity:	10000 mAh
Battery Cell Composition:	Lithium-Polymer
Connector Type:	USB (Output), Micro USB / USB-C (Input)
Number of Output Ports:	2 (USB)
Output Current:	5 Ampere (Total)
Special Features:	Digital Display, Wireless Charging
Color:	Black
Power Source:	Battery Operated
Compatible Phone Models:	All (Universal USB, Qi-compatible for wireless)
Manufacturer:	S-link
Package Dimensions:	19.1 x 9.3 x 3.2 cm

Item Weight:	260 g

8. Safety Information

WARNING: Failure to follow these safety instructions could result in fire, electric shock, injury, or damage to the power bank or other property.

- Do not disassemble, open, crush, bend, deform, puncture, or shred the power bank.
- Do not modify or remanufacture the power bank, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids.
- Do not expose the power bank to fire, explosion, or other hazards.
- Avoid dropping the power bank. If dropped, especially on a hard surface, and you suspect damage, do not use it.
- Keep the power bank away from children.
- Use only chargers and cables recommended by the manufacturer.
- Do not use the power bank in environments with extreme temperatures (below 0°C / 32°F or above 45°C / 113°F).
- Dispose of the power bank according to local regulations. Do not dispose of it with household waste.

9. Warranty and Support

S-link products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official S-link website. Please retain your proof of purchase for any warranty claims.
For further assistance, you may contact S-link customer service through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KHNXTP5

More documents and user manuals: **https://manuals.plus/**