Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EUROSTAR IR222W

EUROSTAR IR222W User Manual

1200W Spray, Steam and Dry Compact Iron with Non-Stick Soleplate

Important Safety Instructions

When using your iron, basic safety precautions should always be followed, including the following:

- Read all instructions before using the iron.
- Use the iron only for its intended use.
- To avoid the risk of electric shock, do not immerse the iron in water or other liquids.
- Always turn the iron to OFF before plugging or unplugging from the electrical outlet. Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
- Do not allow cord to touch hot surfaces. Let iron cool completely before putting away. Loop cord loosely around iron when storing.
- Always disconnect iron from electrical outlet when filling with water or emptying, and when not in use.
- Do not operate iron with a damaged cord or if the iron has been dropped or damaged. To avoid the risk of electric shock, do not disassemble the iron; take it to a qualified serviceman for examination and repair. Incorrect reassembly can cause a risk of electric shock when the iron is used.
- Close supervision is necessary for any appliance being used by or near children. Do not leave iron unattended while connected or on an ironing board.
- Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a steam iron upside down – there may be hot water in the reservoir.
- This appliance is for household use only.

Product Overview



Image of the EUROSTAR IR222W 1200W Spray, Steam and Dry Compact Iron, showing its white body, blue translucent water tank, and black non-stick soleplate.

Parts Identification

- **Spray Nozzle:** For misting fabrics.
- **Water Filling Inlet:** Where water is added to the tank.
- **Spray Button:** Activates the spray mist.
- **Steam Button:** Activates the steam burst.
- **Steam Control Lever:** Adjusts steam output (Dry, Min, Max).
- **Handle:** Ergonomic grip for comfortable use.
- **Pilot Light:** Indicates when the iron is heating.
- **Temperature Control Dial:** Selects fabric type and temperature.
- **Power Cord:** Connects to electrical outlet.
- **Heel Rest:** Stable base for resting the iron.
- **Translucent Water Tank:** Allows visibility of water level.
- **Non-Stick Soleplate:** Smooth surface for gliding over fabrics.

Before First Use

- Remove any labels, protective film, or stickers from the soleplate.
- It is normal for a small amount of smoke or odor to be produced during the first use as manufacturing oils burn off. This will disappear after a short time.
- For the first use, iron an old piece of fabric (e.g., an old towel) to ensure any residue from the manufacturing process is removed from the soleplate.

Setup

Filling the Water Tank

1. Ensure the iron is unplugged from the electrical outlet.
2. Set the Steam Control Lever to the 'Dry' position.
3. Hold the iron in a vertical position.
4. Open the water filling inlet cover.
5. Carefully pour clean tap water into the water tank up to the 'MAX' fill line. Do not overfill.
6. Close the water filling inlet cover securely.

Note: For areas with hard water, it is recommended to use distilled or demineralized water to prevent mineral buildup.

Operating Instructions

Temperature Control

The temperature control dial allows you to select the appropriate heat setting for different fabric types. Always check the garment's care label before ironing.

- **Low Temperature:** Synthetics, Silk
- **Medium Temperature:** Wool
- **High Temperature:** Cotton, Linen

Dry Ironing

1. Ensure the water tank is empty or the Steam Control Lever is set to 'Dry'.
2. Plug the iron into a 120V AC electrical outlet.
3. Set the Temperature Control Dial to the desired fabric setting. The pilot light will illuminate.
4. Wait for the pilot light to turn off, indicating the iron has reached the selected temperature.
5. Begin ironing your garments.

Steam Ironing

1. Fill the water tank as described in the 'Setup' section.
2. Plug the iron into a 120V AC electrical outlet.
3. Set the Temperature Control Dial to the 'Steam' range (usually between Wool and Linen settings). The pilot light will illuminate.
4. Wait for the pilot light to turn off, indicating the iron has reached the steam temperature.
5. Adjust the Steam Control Lever to the desired steam output (Min or Max).
6. Begin ironing. For an extra burst of steam, press the Steam Button.

Spray Mist Function

The spray mist function can be used with both dry and steam ironing to dampen stubborn wrinkles.

1. Ensure the water tank is filled.
2. Point the spray nozzle towards the fabric.
3. Press the Spray Button to release a fine mist onto the garment.

Maintenance and Cleaning

Emptying the Water Tank

1. Unplug the iron from the electrical outlet and allow it to cool completely.
2. Open the water filling inlet cover.
3. Invert the iron over a sink and allow all remaining water to drain out.
4. Close the water filling inlet cover.

Cleaning the Soleplate

- Ensure the iron is unplugged and completely cool.
- Wipe the soleplate with a damp cloth and a non-abrasive (liquid) cleaner.
- Do not use abrasive scouring pads or metal cleaners as these will scratch the non-stick surface.

Storage

- Ensure the iron is unplugged and completely cool.
- Empty any remaining water from the tank.
- Store the iron upright on its heel rest to prevent damage to the soleplate.
- Store in a dry, safe place, out of reach of children.

Troubleshooting

Problem	Possible Cause	Solution
Iron not heating.	Not plugged in; power outlet issue; temperature dial set to OFF.	Ensure iron is securely plugged in; check power outlet; turn temperature dial to a fabric setting.
No steam.	Water tank empty; temperature too low; steam control set to Dry.	Fill water tank; set temperature to steam range (Wool/Cotton/Linen); move steam control to Min/Max.
Water leaking from soleplate.	Temperature too low for steam; overfilled water tank; iron left horizontal when hot.	Increase temperature to steam range; do not overfill water tank; always rest iron on its heel.
Soleplate sticking or dirty.	Residue buildup from starch or fabric.	Clean soleplate as per 'Maintenance' section. Avoid ironing over zippers or metal objects.

Specifications

Feature	Detail
Model Number	IR222W

Feature	Detail
Power	1200 Watts
Voltage	120 Volts
Soleplate Type	Non-Stick
Functions	Spray, Steam, Dry
Dimensions (approx.)	9.49 x 4.49 x 5 inches
Weight (approx.)	1.7 pounds

Warranty and Support

For warranty information or product support, please refer to the documentation included with your purchase or contact EUROSTAR customer service directly. Contact details can typically be found on the product packaging or the official EUROSTAR website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KJNPW5H

More documents and user manuals: **https://manuals.plus/**