Braun MQ7025X

Braun MultiQuick MQ7025X Hand Blender Instruction Manual

Model: MQ7025X

Brand: Braun

1. Introduction

This manual provides essential information for the safe and efficient operation of your Braun MultiQuick MQ7025X Hand Blender. Please read these instructions thoroughly before first use and retain them for future reference.
The Braun MultiQuick MQ7025X is a versatile kitchen appliance designed for blending, chopping, and whisking various ingredients. Its innovative features aim to simplify food preparation and deliver consistent results.

2. Important Safety Information

- Always unplug the appliance before cleaning or when not in use.
- Do not immerse the motor unit in water or other liquids.
- Blades are sharp. Handle with care, especially when assembling, disassembling, or cleaning.
- Keep hands and utensils out of the container while blending to prevent injury.
- This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.

3. What's Included

Your Braun MultiQuick MQ7025X Hand Blender package includes the following components:

- Motor Unit (Hand Blender Handle)
- ACTIVEBlade Blending Wand (Stainless Steel)
- 1.5-Cup Chopper Attachment
- Whisk Attachment
- 20 oz Plastic Beaker
- Instruction Manual



Figure 1: The Braun MultiQuick MQ7025X Hand Blender with its primary attachments: the motor unit, blending wand, whisk, chopper, and beaker.

4. Setup and Assembly

Before initial use, clean all parts that will come into contact with food. Refer to the 'Maintenance and Cleaning' section for detailed instructions.

4.1 Attaching the Blending Wand

1. Align the blending wand with the motor unit.
2. Push the blending wand onto the motor unit until it clicks into place.
3. To detach, press the release buttons on the sides of the motor unit and pull the blending wand off.



Figure 2: The motor unit of the hand blender, showing the ergonomic grip and control buttons.

4.2 Attaching the Whisk

1. Insert the whisk into the whisk gear box.
2. Align the whisk gear box with the motor unit.
3. Push the gear box onto the motor unit until it clicks into place.

4.3 Attaching the Chopper

1. Place the chopper blade onto the center pin of the chopper bowl.
2. Add ingredients to the chopper bowl.
3. Place the chopper lid onto the bowl, ensuring it is securely seated.
4. Align the motor unit with the chopper lid and push down until it clicks into place.



Figure 3: The chopper attachment, ideal for processing smaller quantities of ingredients.

5. Operating Instructions

5.1 Easy SmartSpeed Technology

The MultiQuick MQ7025X features Easy SmartSpeed technology, allowing intuitive speed control. The more you squeeze the button, the more power you get. This enables single-hand operation and precise control over blending results.



Figure 4: The hand blender in use, highlighting the Easy SmartSpeed control and ACTIVEBlade technology for efficient blending.

5.2 Using the Blending Wand

1. Attach the blending wand to the motor unit.
2. Immerse the blending wand into the ingredients. Ensure the ingredients are within the splash guard.
3. Press and hold the SmartSpeed button to start blending. Adjust speed by varying pressure.
4. Move the blender up and down to ensure all ingredients are processed evenly.
5. Release the button to stop.

The **ACTIVEBlade technology** allows the blending shaft to move up and down, providing a larger active cutting surface for finer blending results, even with hard ingredients. The **PowerBell Plus system** includes an extra milling blade for

faster processing of whole foods.



Figure 5: Demonstrating the hand blender's use in a beaker for smooth purees or sauces.



Figure 6: The hand blender can be used directly in pots for soups and other hot liquids.

5.3 Using the Chopper Attachment

1. Assemble the chopper as described in Section 4.3.
2. Place the chopper on a stable, flat surface.
3. Press and hold the SmartSpeed button to chop. Use short pulses for coarse chopping or longer presses for finer results.
4. Do not overfill the chopper bowl.

5.4 Using the Whisk Attachment

1. Attach the whisk as described in Section 4.2.
2. Use the whisk for whipping cream, beating egg whites, or mixing light batters.
3. Insert the whisk into the ingredients.
4. Press and hold the SmartSpeed button. Start with lower speeds and gradually increase as needed.

5.5 SplashControl Technology

The unique bell shape of the blending wand, combined with the blade position, is designed to reduce suction and prevent splashing, keeping your kitchen clean during use.



Figure 7: Key design elements of the Braun MultiQuick MQ7025X, including intuitive speed control and splash-free blending.

5.6 Product Video Demonstration

Your browser does not support the video tag.

Video 1: Official demonstration of the Braun MQ7025X MultiQuick 7 Immersion Blender, showcasing its features and versatility in various kitchen tasks.

6. Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your appliance.

6.1 Cleaning the Motor Unit

- Wipe the motor unit with a damp cloth. Do not immerse it in water.

6.2 Cleaning Attachments

- The blending wand, whisk, chopper bowl, and beaker are dishwasher safe.
- For manual cleaning, wash parts in warm, soapy water, then rinse thoroughly.
- Exercise caution when handling the chopper blade and blending wand blades due to their sharpness.
- Ensure all parts are completely dry before storing.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; attachment not correctly assembled.	Ensure the appliance is securely plugged into a working outlet. Check that attachments are clicked into place.
Motor stops during operation.	Overheating due to prolonged use or processing too hard ingredients.	Unplug the appliance and let it cool down for at least 30 minutes. Reduce the load or process ingredients in smaller batches.
Ingredients are not blending evenly.	Insufficient liquid; ingredients too large; not moving the blender.	Add more liquid if necessary. Cut ingredients into smaller pieces. Move the blending wand up and down and in circles.
Excessive splashing.	Not fully immersing the blending wand; container too full.	Ensure the blending wand's bell is fully immersed. Do not fill the container above the maximum fill line.

8. Specifications

- **Model:** MQ7025X
- **Power:** 500 Watts
- **Voltage:** 120 Volts
- **Color:** Black
- **Product Dimensions:** 2.68"D x 7.84"W x 9.76"H
- **Item Weight:** 3.74 pounds
- **Special Features:** Easy SmartSpeed Technology, ACTIVEBlade Technology, PowerBell Plus, SplashControl Technology

- **Included Components:** 1.5 Cups Chopper attachment, 20 oz Plastic Beaker, Braun MQ7025X Hand Blender with Metal Detachable ActiveBlade Blending Wand, Whisk Attachment

9. Warranty and Support

Your Braun MultiQuick MQ7025X Hand Blender comes with a**3-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal household use.
For warranty claims, technical support, or to purchase replacement parts, please contact Braun customer service. Refer to the product packaging or the official Braun website for the most current contact information.
Please retain your proof of purchase for warranty validation.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question