Tyche ttyy-097

TYCHE CHIC FRIZZ HDCH01 Hair Dryer User Manual

Model: ttyy-097

Introduction

Thank you for choosing the TYCHE CHIC FRIZZ HDCH01 High-Performance Ceramic Hair Dryer. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new hair dryer. Please read these instructions carefully before use and retain them for future reference.

Important Safety Information

WARNING: To reduce the risk of electric shock, burns, fire, or injury to persons:

- Do not use this appliance near water, such as in bathtubs, washbasins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Keep away from children.
- Do not over-heat the appliance.
- Always turn off and unplug the appliance after use.

Product Overview

The TYCHE CHIC FRIZZ HDCH01 hair dryer features advanced ceramic and tourmaline technology for efficient and frizz-free drying. It includes multiple settings and attachments for versatile styling.



Figure 1: TYCHE CHIC FRIZZ HDCH01 Hair Dryer with included concentrator nozzle and styling comb.

Key Features:

- **Tourmaline Technology:** Helps to reduce frizz and enhance shine.
- **Ceramic Grill:** Provides even heat distribution for consistent drying.
- **High Performance DC Motor:** Delivers powerful airflow for fast drying.
- **Cold Shot Button:** Locks in styles with a burst of cool air.
- **Multiple Heat/Speed Settings:** Two heat settings and two speed settings for customized drying.

- **Styling Attachments:** Includes a concentrator nozzle and a styling comb for various hair types and styles.





Figure 2: Detailed view of the control panel, showing the cold shot button, speed, and heat settings.

Setup

1. **Unpack:** Carefully remove the hair dryer and all accessories from the packaging.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Connect Power:** Ensure the power switch is in the 'OFF' (0) position. Plug the power cord into a suitable electrical outlet (120V AC, 60Hz).
4. **Attach Accessories:** To attach the concentrator nozzle or styling comb, align the attachment with the front barrel of the hair dryer and push it firmly into place until it clicks. To remove, pull gently.

Operating Instructions

Before styling, ensure your hair is towel-dried to remove excess water.

1. **Power On:** Slide the ON/OFF switch to your desired speed setting. The hair dryer has two speed settings: 'I' (low) and 'II' (high).
2. **Select Heat:** Use the heat setting switch to choose your preferred temperature. The hair dryer offers two heat settings: '*' (cool) and '**' (warm).
3. **Drying:** Direct the airflow towards your hair, moving the dryer continuously to prevent concentrating heat in one area.
4. **Using Attachments:**
    - **Concentrator Nozzle:** Use for precise styling and smoothing sections of hair.
    - **Styling Comb:** Ideal for detangling and styling curly or textured hair while drying.
5. **Cold Shot Function:** Press and hold the cold shot button (snowflake icon) to deliver a burst of cool air. This helps to set your style and add shine. Release the button to return to the selected heat setting.
6. **Power Off:** After use, slide the ON/OFF switch to the '0' position and unplug the appliance from the power outlet.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your hair dryer.

Cleaning the Air Filter:

1. Ensure the hair dryer is switched off and unplugged from the power outlet.
2. Locate the rear air filter cover. Gently twist or pull to remove it (refer to Figure 3 for typical location).
3. Use a soft brush or cloth to remove any dust, lint, or hair accumulated on the filter screen.

4. Replace the air filter cover by aligning it and twisting or pushing it back into place until secure.



Figure 3: Side view of the hair dryer, indicating the general area of the rear air filter for cleaning.

Storage:

- Allow the appliance to cool completely before storing.
- Do not wrap the power cord around the appliance, as this can cause premature wear and breakage of the cord.
- Store the hair dryer in a cool, dry place, out of reach of children.

Troubleshooting

If you encounter any issues with your hair dryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hair dryer does not turn on.	No power supply. Power switch is off.	Check if the plug is securely inserted into the outlet. Ensure the power switch is set to 'I' or 'II'.
Low airflow or overheating.	Air filter is blocked. Overheating protection activated.	Clean the air filter as described in the Maintenance section. Unplug the dryer, allow it to cool for 10-15 minutes, then restart.
Hair dryer stops working during use.	Overheating protection activated.	Unplug the dryer, allow it to cool for 10-15 minutes, then restart. Clean the air filter if necessary.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail

Feature	Detail
Brand	Tyche
Model Number	ttyy-097
Material	Ceramic
Power Source	Electric Corded
Special Feature	Tourmaline Technology
Number of Speeds	2
Number of Heat Settings	2
Hair Type Recommendation	Frizzy
Recommended Uses	Drying, Smoothing
Included Components	Concentrator Nozzle
UPC	607203035534
ASIN	B08KL4JJ47

Warranty and Support

This TYCHE CHIC FRIZZ HDCH01 Hair Dryer comes with a**1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.
For technical support, warranty claims, or further assistance, please contact your retailer or the manufacturer's customer service. Contact information can typically be found on the product packaging or the brand's official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question