PARKSIDE PWS 20

PARKSIDE PWS 20 Injector/Extractor Wet and Dry Vacuum Cleaner User Manual

Model: PWS 20 | Brand: PARKSIDE

1. Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your PARKSIDE PWS 20 Injector/Extractor Wet and Dry Vacuum Cleaner. Please read these instructions carefully before first use and keep them for future reference.

The PARKSIDE PWS 20 is a versatile 2-in-1 cleaning system designed for deep cleaning of textile surfaces such as carpets, upholstery, and car seats, as well as for general wet and dry vacuuming of hard floors. Its powerful 1600 W motor ensures optimal cleaning results.

2. Safety Information

Always observe the following safety precautions to prevent injury or damage to the appliance:

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not use the appliance near flammable liquids or gases.
- Never immerse the motor unit in water or other liquids.
- Keep hands, feet, loose clothing, and hair away from openings and moving parts.
- Unplug the appliance from the power outlet before cleaning, maintenance, or when not in use.
- Do not vacuum hot ashes, sharp objects, or large debris that could damage the hose or motor.
- Use only recommended accessories and spare parts.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

3. Package Contents

Verify that all items are present and undamaged upon unpacking:

- PARKSIDE PWS 20 Injector/Extractor Vacuum Cleaner unit
- 1 x Suction hose (2 meters)

- 2 x Suction tube pieces
- 1 x Textile cleaning nozzle
- 1 x Nozzle with hard surface attachment
- 1 x Floor nozzle
- 1 x Special upholstery nozzle
- 1 x Crevice tool
- 1 x Foam filter (for wet vacuuming)
- 1 x Paper filter (for dry vacuuming)
- 1 x 100 ml Carpet and upholstery cleaner



Image Description: A collection of all included accessories for the PARKSIDE PWS 20 vacuum cleaner, laid out on a white background. This includes the main suction hose, two extension tubes, various nozzles (textile, hard surface, floor, upholstery, crevice), a foam filter, a paper filter, and a small bottle of cleaning solution.

4. Setup and Assembly

Follow these steps to assemble your vacuum cleaner:

1. **Attach the Castors:** Insert the four castors into the designated slots on the base of the vacuum cleaner unit until they click into place.
2. **Connect the Suction Hose:** Securely attach the main suction hose to the suction inlet on the vacuum cleaner unit.
3. **Assemble the Suction Tube (for floor cleaning):** Connect the two suction tube pieces together, then attach them to the end of the suction hose. Finally, attach the desired floor nozzle (e.g., floor nozzle or hard surface nozzle) to the end of the suction tube.
4. **Prepare for Wet or Dry Use:**
    - **For Dry Vacuuming:** Ensure the paper filter is correctly installed inside the tank.
    - **For Wet Vacuuming/Injection-Extraction:** Remove the paper filter and install the foam filter.
5. **Fill the Detergent Tank (for injection-extraction):** Open the removable water/detergent reservoir and fill it with water and the recommended amount of carpet/upholstery cleaner. Close the reservoir securely.



Image Description: The PARKSIDE PWS 20 vacuum cleaner shown from an angle, highlighting its compact design with the main unit, stainless steel tank, and the integrated spray and suction hose connected. The yellow and black motor head is visible on top of the silver tank, which is mounted on four small wheels.



Image Description: The PARKSIDE PWS 20 vacuum cleaner with the two-piece suction tube assembled and attached, along with a wide floor nozzle. This configuration is suitable for general floor cleaning.

5. Operating Instructions

5.1. Dry Vacuuming

For dry vacuuming, ensure the paper filter is installed. Attach the desired nozzle (e.g., floor nozzle for hard floors, crevice tool for tight spaces) to the suction hose or extension tubes.

1. Plug the power cord into a suitable electrical outlet.

2. Turn on the vacuum cleaner using the power switch.
3. Move the nozzle over the surface to be cleaned, collecting dust and debris.
4. After use, turn off the appliance and unplug it.



Image Description: The PARKSIDE PWS 20 vacuum cleaner in action, demonstrating dry vacuuming on a light wooden floor. The wide floor nozzle is attached to the extended suction tube, collecting debris.

5.2. Wet Vacuuming

For wet vacuuming, ensure the foam filter is installed and the paper filter is removed. This mode is suitable for picking up spilled liquids.

1. Plug the power cord into a suitable electrical outlet.
2. Turn on the vacuum cleaner.
3. Use the appropriate nozzle (e.g., hard surface nozzle) to vacuum liquids.
4. Monitor the dirty water tank and empty it before it reaches maximum capacity.
5. After use, turn off the appliance and unplug it.



Image Description: The PARKSIDE PWS 20 vacuum cleaner is shown cleaning a wet spill on a wooden floor. The wide floor nozzle is attached, and the machine is actively suctioning liquid, demonstrating its wet vacuuming capability.

5.3. Injection/Extraction Cleaning (Deep Cleaning)

This mode is for deep cleaning textile surfaces. Ensure the foam filter is installed and the detergent tank is filled.

1. Attach the textile cleaning nozzle or special upholstery nozzle directly to the suction hose.
2. Plug the power cord into a suitable electrical outlet.
3. Turn on both the vacuum function and the spray function (usually separate switches).
4. Hold the nozzle close to the surface. Press the spray trigger to apply cleaning solution while simultaneously moving the nozzle to vacuum the sprayed solution and dirt.
5. Work in overlapping strokes to ensure thorough cleaning. For heavily soiled areas, you may spray the solution and let it sit for a few minutes before vacuuming.
6. Continue until the extracted water appears clean.
7. After use, turn off both functions and unplug the appliance. Empty and rinse the dirty water tank and the detergent reservoir.



Image Description: A close-up view of the transparent textile cleaning nozzle of the PARKSIDE PWS 20 vacuum cleaner being used on a light grey carpet. The nozzle is designed to spray cleaning solution and immediately suction it back, demonstrating the injection/extraction process.



Image Description: A hand holding the transparent upholstery cleaning nozzle of the PARKSIDE PWS 20 vacuum cleaner against a dark fabric car seat. This image illustrates the use of the specialized nozzle for cleaning vehicle interiors or furniture.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

6.1. Cleaning the Tanks

- **Dirty Water Tank:** After each wet or injection-extraction use, empty the dirty water tank. Rinse it thoroughly with clean water to prevent odor and residue buildup.
- **Detergent Reservoir:** After each injection-extraction use, empty any remaining cleaning solution and rinse the reservoir with clean water.

6.2. Filter Maintenance

- **Foam Filter (Wet Use):** After wet vacuuming, remove the foam filter, rinse it under running water, and allow it to air dry completely before reinstalling or storing.
- **Paper Filter (Dry Use):** For dry vacuuming, regularly check the paper filter for dust accumulation. Replace it when it becomes heavily soiled or suction power decreases.

6.3. Cleaning Accessories

Rinse all nozzles and hoses with clean water after use, especially after injection-extraction cleaning, to prevent blockages and maintain spray effectiveness.

7. Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	No power supply; Power switch off.	Check power cord connection and wall outlet; Ensure power switch is in the "ON" position.
Low suction power.	Clogged hose/nozzle; Full dirty water tank; Clogged filter.	Check and clear any blockages; Empty dirty water tank; Clean or replace filter.
No spray from nozzle.	Empty detergent reservoir; Clogged spray nozzle; Spray pump not activated.	Refill detergent reservoir; Clean spray nozzle; Ensure spray function is switched on.
Water leaking from tank.	Tank not properly sealed; Tank damaged.	Ensure tank lid is securely fastened; Inspect tank for cracks or damage. Contact customer support if damaged.

8. Technical Specifications

- **Model:** PWS 20
- **Power:** 1600 W
- **Max. Suction Power:** 250 airwatts
- **Water/Detergent Tank Capacity:** 4 Liters
- **Dirty Water Tank Capacity (Gross):** 20 Liters
- **Power Cord Length:** 7.5 meters
- **Hose Length:** 2 meters
- **Dimensions (L x W x H):** Approximately 60 x 40 x 40 cm
- **Weight:** Approximately 10 kg
- **Filter Type:** Foam (wet), Paper (dry)

9. Warranty and Support

For warranty information, technical support, or to order spare parts, please refer to the documentation provided with your purchase or visit the official PARKSIDE website. Keep your proof of purchase for warranty claims.

© 2024 PARKSIDE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question