Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NKF AA59-00786A

User Manual for NKF AA59-00786A Remote Control

Replacement Remote Control for Samsung TV Models

1. Introduction

This user manual provides essential information for the operation and maintenance of your new NKF AA59-00786A Remote Control. This remote is designed as a direct replacement for various Samsung TV models, offering full functionality without the need for programming or pairing. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your remote control.



Figure 1: Front and back view of the NKF AA59-00786A remote control. The remote is black with clearly labeled buttons on the front and a smooth, ergonomic design on the back.

2. Package Contents

Upon opening the package, please verify that all items are present and in good condition:

- 1 x NKF AA59-00786A Replacement Samsung TV Remote Control

Note: Batteries and a separate user manual are not included in the package.

3. Key Features

- **Direct Replacement:** Perfectly replaces your damaged or old Samsung TV remote control.
- **Full Functionality:** Covers all functions of the original remote control.
- **Easy to Use:** No programming or pairing required. Simply install batteries and begin use.
- **Durable Construction:** Made from high-quality ABS material for longevity.

4. Compatibility

The NKF AA59-00786A remote control is compatible with a wide range of Samsung TV models, including but not limited to:

- F6800, F6700
- UE40F6800, UE40F6700
- UN55F6800, UN46F6800, UN50F6800, UN40F6800
- TM1240
- PS51F5500AW, PS51F8590SL
- UA40F6400AM, UA55F6400AM
- UE32F6330AK, UE32F6400AK, UE32F6400AW, UE32F6470SS



Figure 2: The NKF AA59-00786A remote control displayed alongside a list of compatible Samsung TV models, emphasizing its broad compatibility.

5. Setup

Setting up your new remote control is a simple process that primarily involves installing the batteries.

5.1 Battery Installation

1. Locate the battery compartment on the back of the remote control. This is typically a sliding cover.
2. Gently slide the battery cover downwards and away from the remote to open it.
3. Insert two (2) new 1.5V AAA alkaline batteries into the compartment. Ensure that the positive (+) and negative (-) ends of the batteries align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Your remote control is now ready for use. No programming or pairing is required.



Figure 3: A visual guide demonstrating the correct orientation for inserting two AAA batteries into the remote control's battery compartment.

Your browser does not support the video tag.

Video 1: This video demonstrates the physical handling of the remote control, including how to open the battery compartment and insert batteries. It also shows the remote from various angles.

6. Operating Instructions

The NKF AA59-00786A remote control functions identically to your original Samsung TV remote. Point the remote directly at your television and press the desired buttons.

6.1 Button Functions Overview



Figure 4: A detailed diagram illustrating the layout and primary functions of each button on the NKF AA59-00786A remote control.

- **Power Button (●):** Turns the TV on or off.
- **Number Keys (0-9):** Directly input channel numbers.
- **Volume Keys (+/-):** Adjust the volume level.
- **Mute Button:** Mutes or unmutes the TV audio.
- **Channel Keys (CH Up/Down):** Change TV channels.
- **Navigation Pad (Up/Down/Left/Right/Enter):** Navigate through menus and select options.
- **Menu Button:** Access the TV's main menu.
- **Smart Hub Button:** Opens the Smart Hub for apps and streaming services.
- **Guide Button:** Displays the electronic program guide.
- **Info Button:** Shows information about the current program or input.
- **Tools Button:** Access quick settings or contextual options.
- **Return Button:** Goes back to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.

- **Colored Buttons (A, B, C, D):** Functionality varies depending on the TV model or application.
- **Playback Controls (Rewind, Play/Pause, Fast Forward):** Control media playback.



Figure 5: A hand holding the remote control, demonstrating its intuitive use to quickly access favorite live TV and frequently used applications from the main menu of a Samsung Smart TV.

7. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA alkaline).
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage, which can damage the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact. Dropping the remote can damage internal components or break the

casing.

8. Troubleshooting

If you encounter issues with your remote control, please refer to the following troubleshooting steps before seeking further assistance:

Problem	Possible Cause	Solution
Remote is not responding.	Dead or incorrectly installed batteries.	Replace batteries with new 1.5V AAA alkaline batteries, ensuring correct polarity (+/-).
Remote only works sometimes.	Weak batteries or obstruction between remote and TV.	Replace batteries. Ensure a clear line of sight between the remote's IR emitter and the TV's IR receiver. Remove any obstacles.
Specific buttons are not working.	Dirt or debris under the button, or internal damage.	Clean the remote surface. If the issue persists, the remote may be damaged and require replacement.
Remote does not control the TV.	Incompatibility or TV's IR receiver issue.	Verify your TV model is listed in the compatibility section. Test with another remote if possible to check the TV's IR receiver.

9. Specifications

Attribute	Detail
Model Number	AA59-00786A
Brand	NKF
Product Dimensions	6.89 x 1.78 x 0.97 inches
Item Weight	2.24 ounces
Batteries Required	2 x AAA batteries (not included)
Material	ABS
Special Feature	No Programming Required
Compatible Devices	Television (Samsung models as listed in Compatibility section)



Figure 6: A visual representation of the remote control's dimensions, indicating its length, width, and thickness in inches.

© 2025 NKF. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08KXYDBFW

More documents and user manuals: **https://manuals.plus/**