Garberiel X11A-ST2

Garberiel LED Flashlight User Manual

Model: X11A-ST2

1. Introduction

Thank you for choosing the Garberiel LED Flashlight. This manual provides detailed instructions for the proper use, setup, and maintenance of your new flashlight. Designed for durability and high performance, this tactical flashlight is ideal for outdoor hunting, fishing, and general illumination. Please read this manual thoroughly before operation to ensure optimal performance and safety.

2. Safety Information

- Do not look directly into the LED light when it is on. The high intensity light can cause temporary vision impairment or permanent eye damage.
- Keep the flashlight out of reach of children.
- Do not disassemble the flashlight. This may void the warranty and could lead to damage or injury.
- Use only the specified battery type and charging method. Improper charging can lead to battery damage, overheating, or fire.
- Avoid exposing the flashlight to extreme temperatures or direct sunlight for prolonged periods.
- Ensure the charging port cover is securely closed when not charging to maintain waterproof integrity.

3. Package Contents

Verify that all items are present in your package:

- Garberiel LED Flashlight (x2)

- Picatinny Rail Mount (x2)
- Tactile Pressure Switch (x2)
- USB Charging Cable (x2)
- Hex Wrench (for rail mount installation) (x1)
- Lanyard (x2)



Image: Contents of the Garberiel LED Flashlight package.

4. Product Overview

The Garberiel LED Flashlight features a durable aluminum body, a high-lumen LED bulb, and multiple operating modes. It is designed for easy attachment to standard Picatinny/Weaver rails and includes a versatile pressure switch for tactical

applications.



Image: Detailed dimensions of the flashlight and its accessories.



Image: Flashlight components including the main body, pressure switch, and standard tail cap.

5. Setup

5.1 Charging the Flashlight

Before first use, fully charge the flashlight. The flashlight features a built-in USB charging port.

1. Locate the USB charging port on the flashlight body.
2. Connect the provided USB charging cable to the flashlight and to a standard USB power source (e.g., wall adapter, power bank, computer USB port).
3. The indicator light on the flashlight will show red when charging and turn green when fully charged.
4. Once charging is complete, disconnect the cable and ensure the charging port cover is securely closed to maintain

waterproof integrity.



Image: Flashlight connected for USB charging, illustrating charging status indicators.

5.2 Rail Mount Installation

The included mount is compatible with all 20mm standard Picatinny/Weaver rails.

1. Loosen the screw on the Picatinny rail mount using the provided hex wrench.
2. Position the mount onto your desired Picatinny/Weaver rail section.
3. Place the flashlight into the mount ring.
4. Tighten the screws on the mount to secure both the mount to the rail and the flashlight within the mount. Ensure it is firm but do not overtighten.



Image: Flashlight mounted on a rail, demonstrating compatibility with 20mm standard Picatinny/Weaver rails.

5.3 Pressure Switch Connection

The tactile pressure switch provides convenient remote operation.

1. Unscrew the original tail cap from the flashlight.
2. Screw the pressure switch tail cap onto the flashlight body until it is secure.
3. Position the pressure pad in a convenient location for operation.



Image: Flashlight with pressure switch connected, illustrating the two modes of activation.

6. Operating Instructions

6.1 Power On/Off (Standard Tail Cap)

If using the standard tail cap:

- Press the button on the tail cap fully to turn the flashlight ON.
- Press the button fully again to turn the flashlight OFF.

6.2 Mode Selection (Standard Tail Cap)

The flashlight features 5 lighting modes: High, Medium, Low, Strobe, and SOS.

- With the flashlight ON, lightly press the tail cap button (without clicking) to cycle through the modes: High → Medium → Low → Strobe → SOS.
- Fully press the button to select and lock the current mode.

6.3 Using the Pressure Switch

When the pressure switch tail cap is installed:

- **Button Switch:** Press the small button on the pressure switch to turn the light ON. Press again to turn it OFF. This button also cycles through modes with a light press when the light is on.
- **Pressure Pad:** Press and hold the pressure pad to momentarily turn the light ON. Release the pressure pad to turn the light OFF. This is ideal for quick, temporary illumination.



Image: Flashlight in use, highlighting its high lumen output and long beam distance.

7. Maintenance

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Lubrication:** Periodically apply a thin layer of silicone grease to the O-rings and screw threads to maintain

waterproof integrity and smooth operation.

- **Battery Care:** Recharge the flashlight regularly, even if not in frequent use, to prolong battery life. Avoid fully depleting the battery before recharging.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, ensure the battery is partially charged (around 50%) and recharge every 3-6 months.



Image: Flashlight demonstrating its waterproof capabilities (IPX65).

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Flashlight does not turn on.	Low battery; Loose tail cap; Damaged switch.	Charge the battery; Tighten the tail cap; Contact customer support if switch is damaged.
Light is dim or flickers.	Low battery; Loose connections; Dirty contacts.	Recharge the battery; Ensure tail cap is tight; Clean battery contacts with a clean cloth.
Cannot change modes.	Switch not fully pressed or released; Malfunction.	Ensure proper light presses; If issue persists, contact customer support.
Charging indicator not working.	Cable issue; Port issue; Already fully charged.	Try a different USB cable/power source; Check if flashlight is already charged.

9. Specifications

Feature	Detail
Model Number	X11A-ST2
Light Source Type	LED
Brightness	3000 Lumens
Beam Distance	Up to 1800 feet
Power Source	Battery Powered (USB Rechargeable)
Battery Type	Lithium (Included)
Runtime	Up to 24 hours (depending on mode)
Material	Aluminum
Color	Black
Water Resistance Level	IPX65 (Waterproof)
Product Dimensions	5.78"D x 1.37"W x 1.37"H (14.7cm x 3.5cm x 3.5cm)
Item Weight	5.17 Ounces (approx. 146g)
Mounting Type	Picatinny Rail Mount (20mm standard)
Special Features	USB Rechargeable, 5 Lighting Modes, Tactile Pressure Switch

10. Warranty and Support

Garberiel products come with a full warranty. For warranty claims, technical support, or any questions regarding your Garberiel LED Flashlight, please contact our customer service team. Please have your model number (X11A-ST2) and purchase information ready when contacting support.
For more information, visit the official Garberiel Store:Garberiel Store on Amazon

© 2023 Garberiel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question