Frigidaire FLCG7522AW

Frigidaire FLCG7522AW 27" Gas Laundry Center User Manual

Model: FLCG7522AW

1. Introduction

This manual provides essential information for the safe and efficient operation of your Frigidaire FLCG7522AW 27" Gas Laundry Center. This unit combines a 3.9 cu. ft. washer and a 5.6 cu. ft. gas dryer, designed for residential use. Please read all instructions carefully before using the appliance.



Figure 1: Front view of the Frigidaire FLCG7522AW Gas Laundry Center.

2. Important Safety Information

Your safety and the safety of others are very important. This manual contains important safety messages. Always read and obey all safety messages.

General Safety Precautions:

- Read all instructions before using the appliance.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Before the appliance is removed from service or discarded, remove the door to the washing or drying compartment.
- Do not reach into the appliance if the tub or drum is moving.
- Do not install or store this appliance where it will be exposed to the weather.

- Do not tamper with controls.
- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in this manual or in published user-repair instructions that you understand and have the skills to carry out.
- Always disconnect the appliance from the power supply before attempting any service.
- For gas appliances, ensure proper ventilation and gas line connections are checked by a qualified technician.
- This appliance is UL Listed and CSA Listed.

3. Setup and Installation

Proper installation is crucial for the performance and safety of your laundry center. Refer to the detailed installation guide provided with your unit for specific instructions. Below are general guidelines and key specifications.

Dimensions and Placement:

- **Width:** 27 inches
- **Height:** 76 inches
- **Depth:** 31.5 inches
- **Depth with Door Open Maximum:** 31.5 inches
- **Weight:** 260 lbs
- Ensure adequate clearance for ventilation and servicing.
- The unit is designed for residential use and can be installed in a closet or dedicated laundry area.



Figure 2: Example installation of the laundry center in a closet space.

Electrical and Gas Requirements:

- **Voltage:** 190-260 Volts

- **Fuel Type:** Gas
- Installation must comply with local codes and ordinances.
- A qualified installer must perform the gas connection.

4. Operating Instructions

This section guides you through the daily operation of your Frigidaire FLCG7522AW Laundry Center.

4.1 Washer Operation



Figure 3: Washer control panel with cycle selector, wash temperature, and water level buttons.

1. **Load the Washer:** Open the washer lid. Place items loosely in the wash basket. Do not overload.
2. **Add Detergent:** Use the single-compartment dispenser for bleach only. Add detergent directly to the wash basket before loading clothes.
3. **Select Wash Cycle:** Turn the **Cycles** knob to choose from 10 available wash cycles, including:
    - Heavy Soil
    - Bulky
    - Normal
    - Activewear
    - Delicates
    - Quick Wash
    - Colors
    - Light Soil
    - Soak

- Rinse & Spin

4. **Select Wash Temperature:** Press the **Wash Temp** button to choose Hot, Warm, or Cold.
5. **Select Water Level:** Press the **Water Level** button to select Max Fill, Med, or Low.
6. **Start Cycle:** Close the washer lid. Press the **Start/Pause** button to begin the wash cycle.
7. **Cancel Cycle:** Press the **Cancel** button to stop the cycle at any time.



Figure 4: Interior view of the washer drum with agitator.

4.2 Dryer Operation



Figure 5: Dryer control panel with cycle selector and dry temperature buttons.

1. **Load the Dryer:** Open the dryer door. Place washed items into the dryer drum. Do not overload.
2. **Select Dry Cycle:** Turn the **Cycles** knob to choose from 10 available dry cycles, including:
    - Normal
    - Bulky
    - Air Fluff
    - Time Dry (15', 30', 60', 90')
    - Quick Dry
    - Delicates
    - Activewear
3. **Select Dry Temperature:** Press the **Dry Temp** button to choose High, Normal, or Low.
4. **Start Cycle:** Close the dryer door. Press the**Start**/**Pause** button to begin the dry cycle.
5. **Cancel Cycle:** Press the **Cancel** button to stop the cycle at any time.



Figure 6: Interior view of the dryer drum.

5. Maintenance

Regular maintenance helps ensure optimal performance and longevity of your appliance.

Cleaning the Lint Filter:

- Clean the lint filter before every load to prevent fire hazards and ensure efficient drying.
- Pull the lint filter straight up and out of its housing.
- Roll the lint off the screen with your fingers. Do not rinse or wash the filter.

- Push the lint filter firmly back into place.

General Cleaning:

- Wipe exterior surfaces with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Clean the washer tub periodically to prevent odor buildup.

6. Troubleshooting

If your laundry center is not operating correctly, consult this section before calling for service.

Problem	Possible Cause	Solution
Appliance does not start	Power cord unplugged; circuit breaker tripped; door not closed properly.	Check power connection; reset breaker; ensure washer lid/dryer door is securely closed.
Washer does not fill or fills slowly	Water supply turned off; inlet hoses kinked; water pressure too low.	Check water supply valves; straighten hoses; ensure adequate water pressure.
Dryer does not heat	Gas supply turned off; lint filter clogged; incorrect cycle/temperature selected.	Check gas supply valve; clean lint filter; select appropriate dry cycle and temperature.
Excessive noise or vibration	Appliance not level; shipping bolts not removed; unbalanced load.	Level the appliance; ensure all shipping bolts are removed; redistribute laundry load.

7. Specifications

Feature	Detail
Brand	Frigidaire
Model Number	FLCG7522AW
Washer Capacity	3.9 cu. ft.
Dryer Capacity	5.6 cu. ft.
Dimensions (D x W x H)	31.5"D x 27"W x 76"H
Item Weight	260 Pounds
Color	White
Fuel Type	Gas
Voltage	190-260 Volts
Controls Type	Push Button
Access Location	Top Load (Washer), Front Load (Dryer)
Washer Cycles	10 (Heavy Soil, Bulky, Normal, Activewear, Delicates, Quick Wash, Colors, Light Soil, Soak, Rinse & Spin)

Feature	Detail
Dryer Cycles	10 (Normal, Bulky, Air Fluff, Time Dry (15', 30', 60', 90'), Quick Dry, Delicates, Activewear)
Drum Material	Stainless Steel
Special Feature	Child Lock
Certifications	UL Listed, CSA Listed

8. Warranty and Support

Warranty Information:

This Frigidaire FLCG7522AW Laundry Center comes with a**1 Year Limited Manufacturer Warranty**. Please refer to the warranty card included with your purchase for full terms and conditions.

Customer Support:

For technical assistance, service scheduling, or to order replacement parts, please contact Frigidaire Customer Support. Contact information can typically be found on the Frigidaire official website or in your product registration materials.

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question