Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

IJOY Banger

iJoy Banger LED Color Changing Bluetooth Party Speaker User Manual

Model: Banger

1. Introduction

Thank you for purchasing the iJoy Banger LED Color Changing Bluetooth Party Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

2. What's in the Box

Upon unpacking, please ensure all items listed below are present and in good condition:

- Speaker
- Charging cable
- Auxiliary cable
- User manual



Front view of the iJoy Banger LED Color Changing Bluetooth Party Speaker, showcasing its dual speakers with illuminated red and orange LEDs and the central control panel.

3. Product Features

The iJoy Banger LED Color Changing Bluetooth Party Speaker is equipped with several key features designed for an enhanced user experience:

- Built-In radio to cover anything you could possibly want out of a speaker
- Lightweight design convenient to take along with you for where ever you go

- Mic Input to turn the party up to the next level
- Color changing LED to light the mood up
- Bluetooth compatible

4. Setup Guide

Follow these steps to set up your iJoy Banger LED Color Changing Bluetooth Party Speaker for first use:

1. **Charging:** Before first use, fully charge the speaker using the provided charging cable. Connect the small end of the cable to the speaker's charging port and the USB end to a compatible USB power adapter (not included). The charging indicator light will typically turn off or change color when fully charged.
2. **Power On:** Locate the power button, usually on the control panel, and press and hold it for a few seconds until you hear an audible prompt or see an indicator light illuminate.
3. **Bluetooth Pairing:**
    - Ensure Bluetooth is enabled on your smartphone or tablet.
    - On your device, search for available Bluetooth devices. The speaker should appear as "Banger" or similar.
    - Select the speaker from the list to pair. A confirmation tone or voice prompt will indicate successful pairing.
4. **Auxiliary Connection (Optional):** If using the auxiliary cable, connect one end to the speaker's AUX input and the other end to the audio output of your external device.
5. **Microphone Connection (Optional):** If using a microphone, insert the microphone cable into the designated MIC input port on the speaker.

5. Operating Instructions

5.1. Basic Controls

- **Power Button:** Press and hold to turn on/off.
- **Volume Control:** Rotate the volume knob or use '+' / '-' buttons to adjust volume.
- **Play/Pause:** Press the Play/Pause button to start or stop audio playback.
- **Next/Previous Track:** Use the 'Next' and 'Previous' buttons to skip tracks.
- **Mode Button:** Press to switch between Bluetooth, FM Radio, and AUX modes.

5.2. Bluetooth Mode

Once paired, your speaker will automatically connect to the last paired device when in Bluetooth mode. If not, manually select the speaker from your device's Bluetooth settings.

5.3. FM Radio Mode

To use the built-in FM radio:

1. Press the Mode button to switch to FM Radio.
2. Press the Play/Pause button to auto-scan and save available stations.
3. Use the Next/Previous buttons to navigate through saved stations.

5.4. LED Color Changing Lights

The speaker features dynamic LED lights. These lights typically activate automatically when the speaker is on. Some models may have a dedicated button to cycle through light modes or turn them off.

6. Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or high humidity.

7. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or depleted.	Charge the speaker fully.
No sound.	Volume is too low; device not paired; incorrect mode.	Increase volume; re-pair Bluetooth device; ensure correct mode (Bluetooth/AUX/FM).
Bluetooth connection unstable.	Device too far; interference; low speaker battery.	Move device closer; avoid obstacles; charge speaker.
FM radio static.	Weak signal; no antenna.	Relocate speaker for better reception; ensure auxiliary cable is connected (often acts as antenna).

8. Specifications

Feature	Detail
Package Dimensions	43.1 x 18.5 x 17.9 cm; 2.23 kg
Date First Available	19 Oct. 2020
ASIN	B08L6QXTH7
Guaranteed software updates until	unknown
Brand	IJOY
Speaker maximum output power	20 Watts
Connectivity technology	Bluetooth
Audio output mode	Stereo
Mounting type	Tabletop
Model name	Banger
Speaker type	Bluetooth
Special feature	Bluetooth
Recommended uses for product	Radio

Feature	Detail
Compatible devices	Tablet, Smartphone

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official IJOY website. Keep your proof of purchase for any warranty claims.
Manufacturer: IJOY
Model: Banger
ASIN: B08L6QXTH7

© 2023 IJOY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08L6QXTH7

More documents and user manuals: **https://manuals.plus/**