Home Accents Holiday Fantasleigh Outdoor Christmas Deer Family

Home Accents Holiday 3-Piece Fantasleigh Outdoor Christmas Deer Family with LED Cool White Lights Instruction Manual

Model: Fantasleigh Outdoor Christmas Deer Family

Introduction

Thank you for choosing the Home Accents Holiday 3-Piece Fantasleigh Outdoor Christmas Deer Family. This manual provides essential instructions for the safe assembly, operation, and maintenance of your lighted deer display. Please read all instructions carefully before setup and retain this manual for future reference.



Image 1: The complete Home Accents Holiday 3-Piece Fantasleigh Outdoor Christmas Deer Family display.

Important Safety Information

- This product is designed for outdoor use only in fair weather conditions.
- Always unplug the display during inclement weather, such as heavy rain, snow, or strong winds.
- Keep the display away from flammable materials.
- Do not allow children to play on or near the display.
- Always follow electrical safety guidelines when handling bulbs and fuses.
- Ensure all electrical connections are dry and protected from moisture.

Setup Instructions

Careful assembly is required. It is recommended to have a helper, a step stool or ladder, needle-nose pliers, and additional zip ties on hand.

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all connecting rods, frames, lights, and accessories (bows, stakes, anchor strings, extra bulbs/fuses) are present.
2. **Assemble Body Sections:** Begin by connecting the main body sections of each deer using the provided rods. There are typically two main rods per deer body. Some force or a lubricant may be needed for easier insertion. Minor frame misalignments may occur but generally do not affect the display's overall appearance.
3. **Attach Legs:** Connect the legs to the assembled body frames. If rod alignment is challenging, needle-nose pliers can assist in guiding the rods into place.
4. **Outdoor Placement for Head/Antlers:** It is advisable to move the deer frames outdoors before attaching the head and antlers due to their increased height and width once fully assembled.
5. **Attach Head and Antlers:**
    - Locate the attachment points for the head. These may be partially obscured by the decorative string and may require gentle searching.
    - Secure the head to the body. Use zip ties for additional reinforcement to prevent detachment.
    - Attach the antlers to the top of the head. A ladder or step stool will be necessary for the taller deer. If any antler attachment points are damaged, use zip ties to secure the antlers firmly.
    - Attach the ears after the antlers.
6. **Secure Connections:** Throughout assembly, use additional zip ties to reinforce any connections, especially for the head and legs, to enhance stability.
7. **Attach Decorative Bows:** Secure the decorative bows to each deer as desired.
8. **Ground Staking and Anchoring:**
    - Position the deer family in your desired outdoor location.
    - Use the provided ground stakes to secure the base of each deer to the ground. For enhanced stability, especially in areas prone to wind, consider using additional or stronger ground anchors.
    - Untangle and attach the anchor strings to the deer frames and secure them to the ground using additional stakes, pulling taut to prevent tipping.
9. **Electrical Connection:** The display requires two separate power connections. Connect the power cords to suitable outdoor-rated extension cords (not included) and plug them into a GFCI-protected outdoor outlet. Ensure all connections are dry and protected from moisture.



Image 2: The deer family display positioned in an outdoor setting, illustrating proper placement.



Image 3: Detail of the illuminated antlers, showing the intricate design.



Image 4: Detail of the festive decorative bow, which attaches to the deer's body.

Operating Instructions

Once fully assembled and secured, and all electrical connections are safely made:

- **Power On:** Plug the extension cords into a GFCI-protected outdoor electrical outlet. The LED lights will illuminate.
- **Power Off:** Unplug the extension cords from the electrical outlet to turn off the display.
- **Timer Use (Optional):** For automated operation, you may use an external outdoor-rated timer (not included) connected to your GFCI outlet.

Maintenance

- **Cleaning:** To clean the display, unplug it from the power source. Gently wipe the surfaces with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Bulb Replacement:** This display uses long-lasting LED bulbs. In the event of a bulb failure, extra bulbs are included. Refer to the small instruction sheet provided with the extra bulbs for specific replacement procedures. Always unplug the unit before attempting any bulb replacement.
- **Fuse Replacement:** Extra fuses are included. If the entire display or a section of lights does not illuminate, check the fuse in the plug. Always unplug the unit before checking or replacing fuses.
- **Storage:** Before storing, ensure the display is clean and completely dry. Disassemble the deer family in reverse order of assembly. Store all components, including stakes, anchor strings, and spare parts, in their original packaging or a suitable container in a cool, dry place away from direct sunlight.

Troubleshooting

Display does not light up:

- Ensure the power cords are securely plugged into a working GFCI-protected outdoor outlet.
- Check the fuses in the plugs. Replace if blown (extra fuses are included).
- Inspect the entire length of the light strings for any damaged or loose bulbs. Replace any faulty bulbs.
- Verify that all connections within the display are secure.

Display is unstable or tips over:

- Ensure all ground stakes are fully inserted into the ground.
- Verify that anchor strings are properly attached and taut.
- Consider using additional or stronger ground anchors, especially in soft soil or windy conditions.
- Check that all frame connections are secure, reinforced with zip ties if necessary.

Parts do not align during assembly:

- Minor misalignments can occur. Gentle force or the use of pliers for rod insertion may be necessary.
- Ensure you are assembling the correct parts for each deer.
- Reinforce connections with zip ties to hold parts together securely despite minor gaps.

Specifications

Brand:	Home Accents Holiday
Model:	Fantasleigh Outdoor Christmas Deer Family
Number of Pieces:	3
Light Type:	LED
Light Color:	Cool White
Number of Lights:	295

Power Source:	Corded Electric (requires 2 outlets)
Material:	Metal Frame
Item Weight:	21.1 pounds
Package Dimensions:	35.12 x 26.93 x 15.43 inches
UPC:	029944578475
ASIN:	B08L7LMHJN

Warranty and Support

This product typically comes with a limited warranty, often for a period of 90 days from the date of purchase. Please refer to your purchase receipt or contact the retailer for specific warranty terms and conditions.
For technical assistance or inquiries regarding your Home Accents Holiday product, please contact the retailer where the item was purchased or the manufacturer directly.

© 2023 Home Accents Holiday. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question