Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Uvital Desktop Corded Telephone

Uvital Desktop Corded Telephone User Manual

Model: Desktop Corded Telephone

1. Introduction

Thank you for choosing the Uvital Desktop Corded Telephone. This manual provides detailed instructions for the proper installation, operation, and maintenance of your new telephone. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. Package Contents

- Uvital Desktop Corded Telephone Unit
- Handset
- Coiled Handset Cord
- Telephone Line Cord
- Two (2) Telephone Cord Detanglers
- Mechanical Lock Key (integrated with the unit)

3. Product Overview

The Uvital Desktop Corded Telephone is designed for reliable communication with essential features. Below is an overview of the main unit and included accessories.



Image 3.1: The Uvital Desktop Corded Telephone unit shown with its handset and two included telephone cord detanglers.



Image 3.2: Top view of the telephone unit, highlighting the keypad, function buttons (Mute, Pause, Flash, Redial), and the ringer switch.



Image 3.3: A close-up view of the two telephone cord detanglers, designed to prevent handset cord tangles.

4. Setup

4.1 Connecting the Telephone

1. Connect one end of the coiled handset cord to the handset and the other end to the designated port on the telephone base unit.
2. Connect one end of the telephone line cord to the "LINE" port on the telephone base unit.
3. Connect the other end of the telephone line cord to your wall telephone jack.



Image 4.1: Side view of the telephone, illustrating the connection points for the handset cord and the telephone line cord.

4.2 Connecting the Cord Detangler

The included cord detanglers prevent the handset cord from twisting and tangling. They are compatible with standard RJ9 telephone lines and 4P4C Gague handset coiled cords.

1. Unplug the coiled handset cord from the telephone base unit.
2. Plug one end of the cord detangler into the handset port on the telephone base unit.
3. Plug the coiled handset cord into the other end of the cord detangler.
4. The detangler will automatically rotate 360 degrees to prevent tangles during use.



Image 4.2: A close-up demonstrating how to connect the RJ9 4P4C Gague detangler between the telephone base and the handset cord.



Image 4.3: Diagram illustrating the function of the cord detangler in preventing the handset cord from twisting and tangling during telephone use.

Note: The cord detangler is not suitable for VOIP phones or RJ45 modular plugs.

5. Operating Instructions

5.1 Making a Call

1. Lift the handset.
2. Listen for a dial tone.

3. Dial the desired telephone number using the keypad.

5.2 Receiving a Call

- When the telephone rings, lift the handset to answer the call.
- To end the call, place the handset back on the cradle.

5.3 Mute Function

- During a call, press the **MUTE** button to temporarily disable your microphone. The other party will not hear you.
- Press the **MUTE** button again to resume the conversation.

5.4 Pause Function

- The **PAUSE** button inserts a brief pause in the dialing sequence. This is useful when dialing numbers that require a pause, such as accessing an extension after dialing a main number.
- Press **PAUSE** at the desired point during dialing.

5.5 Flash Function

- The **FLASH** button is used to access network services such as call waiting or three-way calling.
- Press **FLASH** during a call to activate these services, as provided by your telephone service provider.

5.6 Redial Function

- To redial the last number called, lift the handset and press the **REDIAL** button.

5.7 P/T Mode Selection

- The telephone supports both Pulse (P) and Tone (T) dialing modes.
- A switch, typically located on the side or bottom of the phone, allows you to select between P (Pulse) and T (Tone) dialing. Choose the mode compatible with your telephone line service.

5.8 Ringer Adjustment (Hi/Low/Off)

- The ringer volume can be adjusted using the switch located on the telephone base.
- Set the switch to 'Hi' for high volume, 'Lo' for low volume, or 'OFF' to disable the ringer.

5.9 Mechanical Lock

The mechanical lock feature prevents unauthorized outgoing calls.

- The locking key is located on the bottom of the phone.
- To disable the lock (allowing all calls), ensure the key is in the **green** position.
- To enable the lock (preventing outgoing calls), move the key to the **red** position. Incoming calls can still be received when the lock is enabled.

6. Maintenance

- Clean the telephone unit with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- Keep the telephone away from excessive moisture, dust, and direct sunlight.
- Ensure all cords are securely connected and free from damage.

7. Troubleshooting

Problem	Possible Cause	Solution
No dial tone	Telephone line cord is disconnected or faulty.	Check all cord connections. Try connecting another phone to the wall jack to verify line service.
Cannot make outgoing calls	Mechanical lock is engaged (key in red position).	Move the mechanical lock key to the green position.
Ringer does not sound	Ringer switch is set to 'OFF'.	Adjust the ringer switch to 'Hi' or 'Lo'.
Handset cord is tangled	Cord detangler is not installed or is faulty.	Ensure the cord detangler is correctly installed. Replace if damaged.

8. Specifications

- **Brand:** Uvital
- **Model:** Desktop Corded Telephone
- **Color:** Black
- **Telephone Type:** Corded
- **Power Source:** Corded Electric (Line Powered)
- **Dialer Type:** Single Keypad
- **Dialing Modes:** Pulse (P) / Tone (T) selectable
- **Included Accessories:** 2x Telephone Cord Detanglers (RJ9 4P4C Gague compatible)

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Uvital customer service directly. Contact details can typically be found on the manufacturer's website or through your point of purchase. Please retain your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08L8SLDSQ

More documents and user manuals: **https://manuals.plus/**