ALLIMITY BN59-01266A

ALLIMITY BN59-01266A Voice Remote Control User Manual

Model: BN59-01266A

Brand: ALLIMITY

Introduction

This manual provides instructions for the ALLIMITY BN59-01266A Voice Remote Control. This remote is designed as a replacement for various Samsung Smart TV models, offering both standard control and voice command capabilities. Please read this manual carefully to ensure proper setup and operation.

Setup

1. Battery Installation

The remote control requires two (2) AAA batteries for operation. Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, matching the (+) and (-) terminals as indicated inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.





Image: Rear view of the remote control, illustrating the open battery compartment for AAA battery insertion.

2. Initial Pairing (for Voice Functionality)

For basic functions, the remote may work directly with compatible Samsung TVs. However, to utilize the voice command feature, pairing with your TV might be required. Refer to your Samsung TV's user manual for specific pairing instructions for a new voice remote. Typically, this involves:

1. Ensure your TV is powered on.
2. Point the remote at the TV.
3. Press and hold the **Return** and **Play**/**Pause** buttons simultaneously for 3-5 seconds until a pairing message appears on your TV screen.
4. Follow any on-screen prompts to complete the pairing process.

Operating Instructions

Basic Functions

The remote control features standard buttons for navigating your Samsung Smart TV.



Image: Front view of the remote control, displaying all functional buttons.

- **Power Button** (🔪): Turns the TV on or off.
- **Navigation Pad** (Circular button): Use the directional arrows to move through menus and select items. The center button confirms selections.
- **Home Button** (🔪): Accesses the Smart Hub or home screen.
- **Back Button** (🔪): Returns to the previous screen or menu.
- **Volume Button** (VOL): Press up or down to adjust the volume. Press the center to mute/unmute.
- **Channel Button** (CH): Press up or down to change channels.
- **Play/Pause Button** (🔪): Controls media playback.
- **123 Button**: Accesses the on-screen numeric keypad.

Voice Command Function

The BN59-01266A remote features voice control for convenient operation.



Image: Remote control highlighting the voice control feature with a microphone icon.

- **Voice Button** (🎤): Press and hold this button to activate the voice command feature.
- While holding the button, speak your command clearly into the remote.
- Release the button when you have finished speaking.
- Examples of commands include: "Change to Channel 5", "Open Netflix", "Search for [movie title]", "Volume up".

Compatible TV Models

This ALLIMITY BN59-01266A Voice Remote Control is compatible with the following Samsung Smart TV models:

- UN55MU8500F, UN55MU850DF, UN65MU8500F, UN65MU850D, UN65MU850DF
- UN55MU9000F, UN55MU9000FXZA, UN65MU9000F, UN65MU9000FXZA, UN75MU9000FXZA
- QN55Q7CAMFXZA, QN65Q7CAMFXZA, QN65Q7FD, QN75Q9FAMFXZA
- UN40MU6300F, UN40MU6300FXZA, UN43MU6300F, UN43MU6300FXZA, UN43MU630D
- UN50MU6300F, UN50MU6300FXZA, UN50MU630D, UN55MU6300F, UN55MU6300FXZA, UN55MU630D
- UN65MU6300F, UN65MU6300FXZA, UN65MU630D, UN75MU6300FXZA, UN75MU630D

If your specific model is not listed, please contact customer support for compatibility verification.

Specifications

PRODUCT SIZE

≈ 3.5 cm
≈ 1.38 in

≈ 16.5 cm
≈ 6.5 in



Image: Product dimensions diagram for the remote control.

Feature	Detail
Product Dimensions	6 x 2 x 0.7 inches (approx. 15.2 x 5.1 x 1.8 cm)
Item Weight	1.41 ounces (approx. 40 grams)
Batteries Required	2 AAA batteries
Connectivity Technology	Bluetooth
Special Feature	Voice Control, Ergonomic Design
Compatible Devices	Samsung Televisions

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly and are not depleted. Replace if necessary.
  - Ensure there are no obstructions between the remote and the TV's sensor.
  - Re-pair the remote with the TV if voice commands or specific functions are not working (refer to "Initial Pairing" section).
- **Voice commands not working:**
  - Ensure the remote is properly paired for voice functionality.
  - Speak clearly and hold the voice button while speaking.
  - Check your TV's settings to ensure voice control is enabled.
- **Intermittent functionality:**
  - Weak batteries can cause inconsistent performance. Replace batteries.
  - Ensure the remote is within effective range of the TV.

Warranty and Support

For warranty information or further assistance, please refer to the documentation provided with your purchase or contact the seller directly. When contacting support, please have your product model number (BN59-01266A) and TV model number available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question